

PN: GR18GEC14T

01~04 Chrysler Town & Country – Main Upper Mesh Grille

Hardware

8 -- 6-32×1" Screws

8 -- Flat Tabs

8 -- 6-32 K-Lock Nuts

- (1) Inspect product and check components with items.
- (2) Pop Hood, remove plastic shroud at the top and set fasteners aside.
- (3) Thread a screw in each nut welded to the grille. From the rear, place a flat tab on each screw. Now thread a nut on each screw.
- (4) Make sure the insert is centered and tighten the hardware.
- (5) Reinstall the plastic shroud with the fasteners removed in Step 2.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!