

## Grille Installation Instruction

Part#	GR18GGH08T					Application		For 2004-2008 Chrysler Crossfire						
		ltem	Part Name		QTY	Description		ltem	Item Part Name			QTY	Description	
Parts L	ist	1 Mesh Grille		3	Stainless steel		2	Plastic Retainers		4				
			Flat Brackets		4	<sup>1</sup> / <sub>2</sub> "			Nylon Lock Nuts		4	6-32		
			Flat Washers 4 #10											
Install N	Notes: Overlay 🔀 Rep				Repla	acement	$\checkmark$	Dril		Cut	×			
Step	Description						illustration							
1	Identify the grille & hardware with parts list.													
2	Start with the upper section. Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.													
3	Center the grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille.Be sure the bolts are through the OEM grille shell.													
4	Secure grille using the Plastic Retainers from the back side of the OEM grille shell.													
5	Make sure the grille is centered and tighten the fasteners, but do not over-tighten.													
6	Move on to the lower section. Test fit the bumper inserts into the bumper to identify the correct locations. Remove the factory bumper inserts. On the outer end of each insert is a hole to access the molded retaining clips; this side must be removed first. Slide a slotted screwdriver into the access hole; depress the molded clip; remove the insert by pulling the insert forward. Repeat on other side.													
7	Once the inserts are removed. Center the corresponding grilles over the factory bumper inserts. Slide a 1/2 " flat bracket and flat washer over each mounting stud; use the lock nuts to secure the grille (3). Reinstall the bumper inserts with the grilles attached.													
8	Rei	Reinstall the black plastic cover which was removed in step 2.												
9	Inst	Installation completed!!!												

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!