





Part#	GR20GEI88T/H	Application	<b>For 2014-2018 Toyota Tundra</b>
-------	--------------	-------------	------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless Steel	3	Nylon Lock Nuts	4	6-32
	2	Bone Brackets	2		4	stud	4	6-32 1.5"

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Place the mesh grille into the factory bumper opening (Fig 1). Push the mesh grille inward until it is seated flush in the factory bumper opening.	 Fig 1
4	From underneath the front of the vehicle, reach up behind the factory bumper opening and locate the four threaded studs on the back of the mesh grille, place the two bone brackets onto the threaded studs as indicated on (Fig 2). One bone bracket will be installed on each side of the mesh grille.	 Fig 2
5	With the bone brackets placed on the threaded studs take the four nylon lock nuts and install them onto the threaded studs, tighten with a socket and ratchet (Fig 3).	 Fig 3
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!