

Grille Installation Instruction

Rev. 180501

Part# GR20GFH52T/H Application For 2011-2013 Scion XB

| | | Item | Part Name | QTY | Descript | ion | Item | Part Name | QTY | Description | |
|--|---|-------------|-------------|-----|---------------|-----|--------------|-------------|-----|-------------|--|
| Parts Li | ist | 1 | Mesh Grille | 1 | Stainless ste | eel | 3 | Studs | 4 | 6-32×1″ | |
| | | 2 Washers | | 4 | | | 4 | K-Lock Nuts | 4 | 6-32 | |
| Install Notes: Overlay $\boxed{\hspace{1em}}$ Replacement $\boxed{\hspace{1em}}\times$ Drill $\boxed{\hspace{1em}}\times$ Cut $\boxed{\hspace{1em}}\times$ | | | | | | | | | | | |
| Step | | Description | | | | | illustration | | | | |
| 1 | Identify the grille & hardware with parts list. | | | | | 6 | | | | | |
| 2 | Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. | | | | | | | | | | |
| 3 | Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered. | | | | | | | | | | |
| 4 | Thread a stud in each nut welded to the grille. Then thread a nut and a washer on each stud. | | | | | | | | | | |
| 5 | Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten. | | | | | | | | | | |
| 6 | Reinstall the black plastic cover which was removed in step 2. | | | | | | | | | | |
| 7 | Inst | allation | completed. | | | | | | | | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!