

Grille Installation Instruction

Rev. 190401

Part#		GR22GEE13T/H		Application		For 2003-2007 VW Volkswagen Touareg V6						
		Item	Part Name		QTY	Desc	cription	Item	Part Name	QTY	Description	
Parts L	ict	1	Mesh Grille		6	Stainless steel		4	K-Lock Nut	20	6-32	
Parts L	ısı	2	Stud		2	10-24×1 1/4"		5	Stud	20	6-32×1.5″	
		3	Nylon Lock Nuts		2	10-24		6	Washers	22		
Install Notes: Overlay												
Step	Description							illustration				
1	Identify the grille & hardware with parts list.											
2	Optional (for vehicles with black plastic cover under hood). Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.											
3	Secure the stud to the threaded holes on the rear of the grille.											
4	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell											
5	Secure grille using the washers and lock nuts from the back side of the OEM grille shell.											
6	Make sure the grille is centered and tighten the fasteners.											
7	Reinstall the black plastic cover which was removed in step 2.											
8	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!