

PN: GR25GFG96T

2011 Hyundai Sonata Lower Bumper

Hardware

8 -- 6-32×1 1/2" Studs

8 -- Washers

8 -- 6-32 K-Lock Nuts

- (1) Inspect product and check components with items.
- (2) Pop Hood, remove plastic shroud at the top and set fasteners aside.
- (3) Thread a stud in each nut welded to the grille. From the rear, place a washer on each stud. Now thread a nut on each stud.
- (4) Make sure the insert is centered and tighten the hardware.
- (5) Reinstall the plastic shroud with the fasteners removed in Step 2.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!