



Part#	GR25GGB17T/H	Application	For 2009-2010 Hyundai Sonata			
7	Align the factory emblem remove in step 6 onto the emblem mounting plate and through the partial holes lasered in the mesh section. The factory emblem studs will push through the partial holes in the mesh for a tight fit.					
8	Install the supplied #8×1/2" truss head screws into the hollow mounting studs to secure the emblem mounting plate and emblem to the mesh grille. (Fig 6)					
			Fig 5			
9	Use masking tape to cover the fins on the small cooler located on the passenger side near the bottom of the radiator. Be careful while installing the mounting hardware on the lower mesh grille as the pins are fairly sharp. (Fig 7)					
10	Install the lower grille section first, accessing the mounting hardware from the top. The rectangular 3-hole mounting brackets install over the top studs and the black washers install on the bottom studs. Snug the hardware but do not over tighten as you will indent the lower grille frame where the studs are located. (Fig 8)					
	tape		Fig 7			
11	Apply additional masking tape 1/4" inside the line taped in step 2 around the upper grille opening. (Fig 9)					
12	Apply flat or semi-gloss black paint to everything that will be visible through the grille once it is installed. On vehicles painted colors other than dark blue or black, use a scotch brite pad to scuff the paint around the grille opening and paint the return edge of the grille opening inside the mounting pin holes as well. (Fig 10)					
	tape		Fig 9			

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Part#		GR25GGB17T/H	Application	For 2009	9-2010 Hyundai Sonata		
13	Cut out and align the supplied hole location template onto the bumper cover, making sure that the center notch in the template line up with the center recessed area in the bumper cover. (Fig 11)						
14	Use an awl or similar pointed tool to mark all hole locations onto the bumper cover, then remove the template.						
15	Use a 1/8" drill bit to drill through the marks made in the previous step, then using the drill bit, connect the holes to from a small slot for left to right grille adjustment. Remove all plastic shavings from the bumper cover. (Fig 12)						
			mark	Fig 11	drill Fig 12		
16	Align the mounting pins on the bottom of the mesh grille into the slots made in step 15. (Fig 13)						
17	Lift up on the hood release lever to allow the top plate to rotate back into position against the core support.						
18	Carefully remove the protective masking tape from around the grille opening. The tape could get caught under the grille. If it does, lift up slightly on the grille while removing the tape. (Fig 14)						
		align pins	F	Fig 13	remove tape		
19	the gril gril	ke sure that the mesh g n reinstall the factory up le top plate to the core s le when tightening the s nten. You could strip out	oper screws to s support (press d screw but do not	ecure the own on the over	factory screws		
20	Peel off the protective cover from the stainless steel surrounds. Thoroughly clean the grilles to finish the installation.						

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Page 3 of 3

Looking for dependable car and truck custom grilles? Rely on APG for quality and long-lasting products.