



For 2004-2019 Nissan Titan Crew Cab /2004-2019 Nissan Armada/
2016-2019 Nissan Titan XD Crew Cab

Installation Instructions for IA14SJE0B by APS Auto Parts Specialist Inc.

Application: For 2004-2019 Nissan Titan Crew Cab /2004-2019 Nissan Armada/
2016-2019 Nissan Titan XD Crew Cab


Estimated Time: 1 to 2 hours



The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

PARTS LIST:

Item	QTY	Description	Item	QTY	Description
#1	2	Driver/ Passenger Side Bar	#7	6	M8 Lock Washer
#2	3	Driver Front Mounting Bracket (DFM/DCM/PRM)	#8	6	2-Hole Support Bracket
#3	3	Passenger Front Mounting Bracket (PFM/PCM/DRM)	#9	12	M10 Flat Washer
#4	6	M8X1.25 - 25mm Hex Bolts	#10	12	M10 Lock Washer
#5	6	M8X1.25 Flange Nut	#11	12	M10X1.5 Hex Nuts
#6	6	M8 Flat Washers	#12	12	M10X1.5-75 Carriage Bolts



PROCEDURE:

1. Verify all parts are present. Read and understand instruction before beginning.
2. Install mounting brackets as shown.(See Figure 1 & 2)
3. Select the Driver Side Bar. Slip (2) M10X1.5-75 Carriage Bolts into each 2-Hole Support Brackets ,and insert the 2-Hole support bracket into the Driver Side Bar.(Fig 3). Carefully position the Bar onto the (3) Mounting Brackets. **IMPORTANT:** Do not slide the Bar on the Brackets or damage to the finish may result. Attach the Driver Side Bar to the Mounting Brackets with (2) M10 Hex Nuts,(2)M10 lock washers and (2)M10 flat washers, (Fig 4). Do not tighten hardware.
4. Level and adjust the Bar properly and tighten all hardware. **NOTE: Torque all M10 X1.5-75 Carriage Bolts to 22~25 lb-ft. Don't over tighten,or the aluminum square bars will be damaged by the brackets.**
5. Repeat Step 2-4 for the other side installation. Installation completed!!! (See Fig 5)
6. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

Products have a high quality finish that must be cared for like any other exposed finish on the vehicle. Protect the finish with a non-abrasive automotive wax, (e.g.Pure Carnauba) on a regular basis. The use of any soap, polish or wax that contains an abrasive is detrimental, as the compounds scratch the finish and open it to corrosion.

Driver/Passenger Side Installation Pictured

