



## iRunning Board Installation Instruction

**Part#: IB06RJJ3**

**Application: For 1999-2016 Ford F-250/F-350 Super Duty Super Cab**

### **PARTS LIST:**

Item	QTY	Description	Item	QTY	Description
#01	2	STEP BOARD( Driver+Passenger)	#07	2	ST6.3x22 Self Tapping Screw
#02	8	Main Bracket	#08	6	M8X1.25-25 Hex Bolt
#03	8	M8x1.25-20 Hex Head Bolt	#09	16	M6X1.25-20 Square Hex Bolt
#04	22	M8 Flat Washers	#10	16	M6 Flat Washers
#05	8	M8X1.25mm Nylon Lock Nuts	#11	16	M6X1 Nylon Lock Nuts
#06	6	M8 Clip Nut			



### **INSTALLATION INSTRUCTION:**

**REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**

1. Remove contents from box and check for damage. Verify all parts are present. Read and understand instructions before beginning.
2. Attach front mounting brackets as shown. Hand tighten **(See Figure 1 & 2)**.
3. Install nut clips as shown **(See Figure 3)**.
4. Attach mounting brackets as shown. Hand tighten.**(See Figure 4 & 5)**.
5. Insert square head bolts as shown (4 per slot, 8 per Step board/Running board) **(See Figure 6)**.
6. Attach Step board to brackets as shown. **(SEE FIGURE 7)**.Make sure step board and brackets are properly aligned and tighten fasteners.
7. Repeat Installation for passenger side.
8. **INSTALLATION IS COMPLETE, SEE FIGURE 8.**

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For Polished Finishes:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

**For black finishes:** Mild soap may be used to clean the Running Board.

# iRunning Board Installation Instruction

Part#: IB06RJJ3

Application: For 1999-2016 Ford F-250/F-350 Super Duty Super Cab

## Driver/left Side Installation Pictured

