



iRunning Board Installation Instruction

Part#: IB20RJE4

Application: For 1995-2004 Toyota TACOMA Extended Cab(4WD Or Prerunner 2/4WD)

PARTS LIST:

Item	QTY	Description	Item	QTY	Description
#01	2	Step Board (Used for left and right)	#06	8	M8 Nylon Lock Nut
#02	8	Mounting Brackets	#07	16	M6 Square Head Bolt
#03	8	M8x20mm Hex Bolt	#08	16	M6 Nylon Lock Nut
#04	16	ST 6.3-22 Self Tapping Screw	#09	16	M6 Flat Washer
#05	16	M8 Flat Washer			



Mounting Brackets

INSTALLATION INSTRUCTION:

- 1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.(Fig 1).**
- 2. Drill 8mm holes in pinch weld as shown(Fig 1).**
- 3. Attach mounting brackets as shown(Fig 2,3 and 4).**
- 4. Insert square head bolts as shown (4 per slot,8 per Step board/Running board)(Fig 5).**
- 5. Attach Step board/Running board to brackets as shown.Align and tighten(Fig 6).**
- 6. Repeat Installation for other side.**
- 7. INSTALLATION IS COMPLETE.**

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For Polished Finishes: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

For black finishes: Mild soap may be used to clean the Running Board.

iRunning Board Installation Instruction

Part#: IB20RJE4

Application: For 1995-2004 Toyota TACOMA Extended Cab(4WD Or Prerunner 2/4WD)

