



## iRunning Board Installation Instruction

Part#: IB20RJE8

Application: For 2005-2018 Toyota Tacoma Double/Crew Cab

### PARTS LIST:

Item	QTY	Description	Item	QTY	Description
#01	1	Passenger Step Board	#07	12	M8 x 25mm Hex Bolts
#02	1	Driver Step Board	#08	12	M6 Square head Bolts
#03	1	Passenger Front Mounting Bracket (PFM)	#09	12	M6 Flat Washers
#04	1	Driver Front Mounting Bracket(DFM)	#10	12	M8 Flat Washers
#05	2	Passenger Center/Rear Mounting Bracket(PCM/PRM)	#11	12	M6 Nylon Lock Nuts
#06	2	Driver Center/Rear Mounting Bracket(DCM/DRM)	#12	12	M8 Lock Washers



DCM/DRM



DFM



PRM



PCM/PRM

### INSTALLATION INSTRUCTION:

**REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**

1. Remove contents from box and check for damage. Verify all parts are present. Read and understand instructions before beginning.

**NOTE:** We does not recommend using closure strip for this application.

2. Attach mounting brackets as shown. Hand tighten (**See Figure 1 and 2**).
3. Insert square head bolts as shown (3 per slot, 6 per board) (**See Figure 3**).
4. Attach board to brackets as shown. Make sure board and brackets are properly aligned and tighten fasteners. (**See Figure 4**).
5. Repeat Installation for other side.
6. **INSTALLATION IS COMPLETE!(SEE FIGURE 5).**

**To protect your investment**, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

**For Polished Finishes:** Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

**For black finishes:** Mild soap may be used to clean the Running Board.

# iRunning Board Installation Instruction

Part#: IB20RJE8

Application: For 2005-2018 Toyota Tacoma Double/Crew Cab

## Driver/Left Side Installation Pictured

