

iRunning Board Installation Instruction

Application: For 2000-2006 Toyota Tundra Extended Cab

PARTS LIST:

Item	QTY	Description	Item	QTY	Description
#01	2	Driver Front Mounting Bracket(DFM/PFM)	#06	8	M8 Nylon Lock Nuts
#02	6	Center/Rear Mounting Brackets	#07	16	ST6x25 Self Tapping Screw
#03	8	M8 x1.25-20mm Hex Bolts	#08	16	M6 Square head Bolts
#04	2	Step Board(Driver side & Passenger Side)	#09	16	M6 Flat Washers
#05	16	M8 Flat Washers	#10	16	M6 Nylon Lock Nuts



DFM/PFM

INSTALLATION INSTRUCTION:

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

1. Drill 5/16" holes in pinch weld as show (See Fig 1).
2. Attach mounting brackets as shown (See Fig 2,3,4 and 5).
3. Insert square head bolts as shown (4 per slot, 8 per board) (See Fig 6).
4. Attach board to brackets as shown. Make sure board and brackets are properly aligned and tighten fasteners. **NOTE: Torque all M6 nylon lock nuts to 7 lb-ft. (See Fig 7).**
5. Repeat Installation for other side.
6. **INSTALLATION IS COMPLETE!(See Fig 8).**

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For Polished Finishes: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

For black finishes: Mild soap may be used to clean the Running Board.

iRunning Board Installation Instruction

Application: For 2000-2006 Toyota Tundra Extended Cab
Driver/Left Side Installation Pictured

Rev. 20181201

