



iRunning Board Installation Instruction

Part#: IB20RJI7/IB20RJI8

Application: For 2007-2018 Toyota Tundra Double/ CrewMax Cab

PARTS LIST:

Item	QTY	Description	Item	QTY	Description
#01	1	Passenger Step Board	#07	16	M8x 30mm Hex Head Bolts
#02	1	Driver Step Board	#08	16	M8 Flat Washers
#03	2	Front Bracket(DFM/PFM)	#09	16	M8 Lock Washers
#04	2	Front /Center Bracket(DCM/PCM)	#10	16	M6 Square Head Bolt
#05	2	Rear/Center Bracket(DCM1/PCM1)	#11	16	M6 Flat Washers
#06	2	Rear Bracket(DRM/PRM)	#12	16	M6 Nylon Lock Nuts



DFM/PF



DRM/PRM



DCM1/PCM1



DCM/PCM

PROCEDURE:

1. Remove contents from box and check for damage. Verify all parts are present. Read and understand instructions before beginning.
2. Determine front, front center, rear center and rear brackets. Rear/center bracket has 1 identification hole and rear bracket has 2 identification holes. **(Figures 1).**
3. Attach drivers side brackets to underside of body panel using two M8x 30mm hex head bolts, M8 flat washers, and M8 lock washers per bracket. Hand tighten. **(Figures 1).**
4. Repeat **Step 3** for center and rear Mounting Bracket installation. **(Figures 1).**
5. Insert square head bolts as shown (4 per slot, 8 per Step board/Running board).**(Figures 2).**
6. Attach Step board to brackets as shown. **(Figures 3).** Make sure step board and brackets are properly aligned and tighten fasteners.
7. Repeat Installation for other side.
8. **INSTALLATION IS COMPLETE! (Figures 4).**

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For Polished Finishes: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

For black finishes: Mild soap may be used to clean the Running Board.

iRunning Board Installation Instruction

Part#: IB20RJI7/IB20RJI8

Application: For 2007-2018 Toyota Tundra Double/ CrewMax Cab

Driver/left Side Installation Pictured

