

1110311

Parts List

Light mounting bracket	
Hex bolt, M8	
Flat washer, M8	
Lock washer, M8	
Hex nut, M8	
Nut plate, M8	

Level of Difficulty

Easy

Product Image





Tools Required			
Torque wrench	Socket, 13mm		
Extension			

Torque Specifications			
0	M6 bolt	3 ftIbs.	
METRIC	M8 bolt	7 ftIbs.	
ΝEΙ	M10 bolt	16 ftlbs.	
	M12 bolt	28 ftIbs.	
	1/4" bolt	3 ftIbs.	
	5/16" bolt	7 ftlbs.	
SAE	3/8" bolt	16 ftlbs.	
•	7/16" bolt	20 ftIbs.	
	1/2" bolt	28 ftIbs.	


Notes and Maintenance
Before you begin installation, read all instructions thoroughly.
Proper tools will improve the quality of installation and reduce the time required.
For black finishes, mild soap may be used to clean the product.
Refer to the table to the left when securing hardware during the installation process to help prevent damage to the product or vehicle.

Step 1 - Mounting Style 1

Hold the nut plate up to the desired mounting location on the back of the headache rack mesh.


Attach the mounting bracket using an M8 hex bolt, flat washer and lock washer.

Skip to step 3.




Step 1 - Mounting Style 2

Insert an M8 hex bolt into the top track on the headache rack and slide the bolt to the desired position.



Step 2 - Mounting Style 2

Place the light mounting bracket on top of the M8 hex bolt and secure the bracket using an M8 flat washer, lock washer and hex nut.



Step 3


Using the hardware provided with the light, attach the light to the mounting bracket.

Tighten all hardware to the recommended torque specifications listed in the table on the first page.

With the mounting bracket installed, periodic inspections should be performed to ensure all mounting hardware remains tight.

Congratulations on the installation of your new ARIES light mounting brackets.





Mounting Style 1

Mounting Style 2

Learn more about grille guards and bull bars we have.