

INSTALLATION INSTRUCTIONS

1999-00 SILVERADO/SIERRA 1500 / 2500 LD EXT CAB 3 DR

2000-13 SILVERADO/SIERRA 1500 / 2500 LD EXT CAB 4 DR



2001-13 SILVERADO/SIERRA 2500HD / 3500 EXT CAB

(Including Diesel models with Def. tanks)

PART# 4493

PARTS LIST:

1	Passenger Side Bar	1	Driver Middle Support Brackets
1	Driver Side Bar	4	6mm Bolt Plates (2) studs per
1	Passenger Side Front Mounting Bracket	2	6mm Bolt Plates (4) studs per
1	Driver Side Front Mounting Bracket	16	6mm Flat Washers
1	Passenger Side Middle Mounting Bracket	16	6mm Lock Nut
1	Driver Side Middle Mounting Bracket	2	10mm x 30mm Hex bolts
1	Passenger Side Rear Mounting Bracket	2	10mm Flat washers
1	Driver Side Rear Mounting Bracket	6	10mm Nuts
1	Passenger Middle Support Bracket	2	10mm U bolts




(4) 2 Bolt plates



(2) 4 Bolt plates

(2) 10mm U Bolts



PROCEDURE:

1. **REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.**
2. Starting on the Drivers left side front: from underside of vehicle remove the front body mount bolts. Do not remove bushings, select the driver's side front bracket from the list of parts above and attach the bracket with the factory body bolt as seen in **(Fig 1)**. Snug but do not tighten at this time.
3. Locate and remove the Drivers side middle body mount bolt, Do not remove bushings, select the driver's side middle bracket from the list of parts above and attach the bracket with the factory body bolt, Snug but do not tighten at this time.
4. On the inner rocker panel insert the U bolt through the upper oval hole and back down through the round hole, attach the driver's side brace bracket to the U bolt with the (2) 10mm nuts, attach the lower part of bracket to the middle mount bracket with (1) 10mm x 30mm hex bolt (1) 10mm flat washer & (1) 10mm nut, Snug but do not tighten at this time. **(Fig 2 & 2A)** shows location for U bolt and brace bracket placement.
5. Moving to the driver's side rear remove the body mount bolt, do not remove bushing, select the driver's side rear mount bracket and secure it with the factory body mount bolt as done in steps 2 & 3 Snug but do not tighten at this time.
6. Next select driver side bar and begin to secure the brackets to the bar with the, (2) 2 bolt plates & (1) 4 bolt plates. Place the (2) 2 bolt plates inside of the tubes with the studs facing downward one at each end of tube and the (1) 4 bolt plate in the middle (**Note:** the bolt plates slide along the inside for alignment to mount brackets) next lay the sidebar onto the mount brackets and line-up the (3) bolt plates with the mount brackets secure each bolt plate to the mount brackets with 6mm flat washer & 6mm lock nuts, as seen in **(Fig 3)** Snug but do not tighten hardware at this time.
7. Level and adjust Side Bar, then tighten all hardware at this time.
8. Repeat steps 2-7 for Passenger Side Bar.
9. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Sidebar.

For gloss black finishes: Mild soap may be used to clean the Sidebar.

Driver Side Installation Pictured

