



2043 Lexus LX470 Landcruiser
Installation

Parts List

- 1 – **Front Aries Bar**
- 2 – Frame Brackets
- 6 – 7/16" x 1 1/4" Hex bolts
- 6 – 7/16" Hex nuts
- 12 – 7/16" Flat washers

Installation of Bottom Frame Bracket

Remove tow hooks from the front of the vehicle.

Using the bolts that held the tow hooks in place attach the mounting brackets as the diagram below. (two bolts per hook) Do not fasten bolts too tightly to allow you to adjust the alignment.

Installation of the Front Bar

Line up the three holes on the lower portion of the front bar with the three holes on the frame mounting brackets (outer edge). Using 7/16" Hex bolts nuts and washers, fasten the front bar mounting brackets, leaving it loose for adjustment.

Once the front bar is attached to the mounting brackets, align until satisfied with fit and balance and tighten all fasteners.

NOTE: it is advisable to re-check all fasteners for tightness after one week.

