



99/02 Chevy Silverado 1500; 00/05 Tahoe; 00/05 Suburban

---

---

#### Parts List

---

1 – Driver Side Bracket

10 – ½ x 1 ½ Bolts

2 – M12 x 1.75 x 40mm Bolts

20 – ½ USS Washers

1 – Passenger Side Bracket

10 – ½ Lock nuts

2 – ½ x 5 ½ Bolts

---

#### Installing the Frame Brackets

---

Remove factory tow hooks from front section of vehicle. **NOTE:** If reusing tow hooks, you must switch driver side for passenger and vice versa. Some models do not align completely. You must trim off small portion off the tow hook. Attach the frame brackets as shown in illustration. Using bolts supplied in kit, hand-tighten in case you have to

adjust the front bar to align it.

#### Installing the Front Bar

Line up the three holes on the lower portion of the bar with the three holes in the frame brackets (outer edge). Attach bar to the frame brackets using the ½ x 1 ½ bolts and nuts. When you are satisfied the bar is aligned, tighten the three bolts supporting the bar. Tighten the bolts holding the frame brackets to the vehicle.

DIAGRAM

