

INSTALLATION INSTRUCTIONS

GRILLE GUARD
2011 GMC SIERRA HD2500/3500
4082/4082-2

PARTS LIST:

1	Grille Guard	6	12mm Lock Washers
1	Driver/Left Mounting Bracket	12	12mm ID x 30mm OD x 3mm Flat Washers
1	Passenger/Right Mounting Bracket	6	12mm Nut
1	Driver/Left Upper Top Brace Bracket	6	10-1.50mm x 30mm Hex Head Bolts
1	Driver Top Bracket support	2	10mm-1.50mm x 30mm Button Head bolts
1	Passenger/Right Upper Top Brace Bracket	2	10mm Nuts
1	Passenger Top Bracket support	10	10mm ID x 26mm OD x 3mm Flat Washers
6	12-1.75mm x 35m Hex Head Bolts	8	10mm Lock Washers

Driver/ left
Mount bracket



Top bracket
Supports



Passenger/ right
Mount bracket



Driver/ left
Upper Top brace
bracket



Passenger/ right
Upper Top brace
bracket



PROCEDURE:

1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.
2. Starting with the driver/left side from underside of vehicle, remove the two bolts holding the driver factory tow hook, then remove tow hook from vehicle and set aside.
3. Determine driver side Mounting Brackets. **NOTE:** Refer to Figure above for bracket configuration. With the tow hook removed, from behind factory bumper, slide driver side Mounting Bracket through factory tow hook cavity, as shown in **(Fig 1)** Insert factory tow hook back into frame. Secure Driver Mounting Bracket to frame using the same bolts to install the tow hook as shown in **(Fig 2)**. Snug but do not tighten at this time.
4. Repeat step 1-3 for Passenger/right side Mounting Bracket.
5. Open the hood and using a flat screw driver remove the ten push pin fasteners from plastic shroud located on top of the radiator. Passenger/right side shown in **(Fig 2)** Remove plastic shroud and set aside. With the shroud removed locate the tab of the bumper on the bottom inner of the grill as shown in **(Fig 4)**
6. Select the top bracket support, Position top bracket support through the bumper and grill opening, secure each side using the (2) 10mm Hex bolt (2) 10mm flat washers and (2) 10mm lock washer to the factory bumper tab as shown in **(Fig 5)** snug but do not tighten at this time.
7. With help position Grille Guard on the outer side of Mounting Brackets. Align holes on the Mounting Brackets with holes on the Grille Guard. Attach Grille Guard to Mounting Bracket using the included (6) 12mm x 35mm Hex Head Bolts, (6) 12mm Nuts, and (12) 12mm Flat Washers and (6) 12mm lock washers **(Fig 6)**. Snug but do not tighten at this time.
8. Select the driver side Upper top brace bracket and slide the brace brackets through the grill securing it to top brace supports with (1) 10mm bolt, (1) 10mm flat washer and (1) 10mm lock washer as shown in **(Fig 7)** Snug but do not tighten at this time.
9. Secure grille guard to Top Brace Brackets using the included (2) 10mm x 30mm Button Head Bolts, (2) 10mm Nuts, (2) 10mm lock washers and (4) 10mm Flat Washers as shown in **(Fig 8)**. Snug but do not tighten at this time.
10. Level and adjust Grille Guard, then tighten all hardware at this time.
11. Reinstall the plastic shroud back onto vehicle with the plastic push pins.
12. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For stainless steel: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Product.

For gloss black finishes: Mild soap may be used to clean the Product.

