



Part Number: 102-2501

Application: NISSAN 2.6L (RB26) INLINE 6

Installation Instructions

1. Due to the high torque value required, we recommend the use of a flywheel locking tool to prevent the crankshaft from rotating while torquing the damper bolt.
2. Clean and inspect all hardware prior to installation. Look for obvious defects or shipping damages.
3. To ensure proper engagement and accurate torque readings, clean the female threads in the crankshaft.
4. Lubricate the bolt threads and underside of the bolt head with ARP Ultra-Torque Fastener Assembly Lubricant. Place the washer on the bolt then install into the crankshaft.
5. Confirm crankshaft is secure then torque the bolt to:

325 - 345 ft-lbs