

## Part Number: 200-2906 Application: CHEVY W/ 1PC. REAR SEAL

## **Flexplate Bolt - Installation**

- [1] Please check the part-number(s) for your application against the part-number(s) listed on the instruction sheet.
- [2] **DO NOT USE ANY WASHERS** with ARP Flexplate Bolts. They are designed to be installed without them. **Note:** ARP will NOT be responsible for any failures resulting from using a washer with this kit.
- [3] Make sure there is an adequate chamfer around the bolt holes on the flexplate to clear the radius under the head of the bolt.
- [4] Lubricate the threads of the bolt with LOCTITE 242 and the under head of the bolt with ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT. Then install the flexplate onto the crankshaft and tighten the bolts hand tight.
- [5] Using an alternating or criss cross pattern, torque the bolts to <u>85</u> ft lbs using the specified lubricants in Step 4.