


ASSENMACHER SPECIALTY TOOLS

CELEBRATING 40 YEARS | 1978-2018



















PRODUCT CATALOG | 2019 - 2020




About Our Company

We manufacture and distribute a full line of specialty tools, cooling system adapters, oil change products, cam alignment tools and disconnect tools for Asian, Domestic and European vehicles. Located in Boulder, Colorado, AST was founded in 1978 by Gerhard Assenmacher and has remained at the forefront of independently owned tool companies since our beginning. Many decades of hands-on industry experience is what makes our team stand above the rest. We build relationships, we know our customers and we know our products. We take pride in the fact that our customers can simply pick up the phone and we are there to help-that's the personal service you'll find at AST.

Many products from AST are Made in the U.S.A. — including our Cooling System Adapters, Engine Oil Funnels and many Special application tools. Those that work in U.S. manufacturing are consumers in our local states and cities. If these people continue to manufacture goods, they will continue to make local purchases and support their local economies. As long as businesses thrive, they will require goods and services that meet their daily needs. Independence as a society requires the skill, ability and knowledge to make things ourselves.







Las Vegas Location!

Assenmacher Specialty Tools has a Southwest location in Las Vegas, Nevada!

Our Las Vegas location gives us the ability to get shipments to more states on the west coast much faster. States like like California, Nevada, Utah and Arizona will see shipments arrive a day earlier than in the past. Most of Southern California will even get their shipments the next day.



Tas Vegas

TOOL	SI	=()	R
		\sim	11

ASIAN MODELS	7-20
ACURA / HONDA	8-9
HYUNDAI / KIA	10
MAZDA	11-12
NISSAN / INFINITI	13-14
LEXUS / SCION / TOYOTA	15-17
SUBARU	18-20
OOLS FOR DOMESTIC MODELS	21-32
CHRYSLER / DODGE / JEEP / RAM	22-24
FORD	25-30
GENERAL MOTORS	31-32
TESLA	107
TOOLS FOR EUROPEAN MODELS	33-72
BMW / MINI	34-46
JAGUAR / LAND ROVER	47-49
MERCEDES	50-54
VOLVO	55-56
VW / AUDI / PORSCHE	57-72
FOOLS FOR HEAVY TRUCK	73-77
CUMMINS / DETROIT DIESEL / FREIGHTLINER / INTERNATIONAL / MACK / VOLVO	73-77
TOOLS LISTED BY SPECIALTY AND APPLICATION	78-123
PLIERS	80
GENERAL TOOLS	81-83
FLUID EXCHANGE	84-87
FUNNELS	88-91
OIL FILTER SOCKETS & WRENCHES	92-94
DIPSTICKS / OIL & TRANSMISSION	95
SPECIALTY SOCKETS	96-101
STUD PULLERS	102-103
BODY / RADIO / ELECTRICAL	104-105
MOTORCYLCE / ATV / MARINE	106
ELECTRIC / HYBRID VEHICLES	107-108
	109-123
APPENDIX	
APPENDIX APPLICATION CHARTS	108-124
APPENDIX APPLICATION CHARTS CALIFORNIA PROP 65 WARNINGS	108-124 125



Copyright© 2019 Assenmacher Specialty Tools $^{\!@}$, Inc.

All Rights Reserved. No part of this catalog covered by the copyrights herein may be reproduced or copied in any form or by any means—graphic, electronic or mechanical, including photocopying, taping, or information storage and retrieval systems—without written permission from Assenmacher Specialty Tools®.

Exact product specifications may vary depending upon date of purchase and / or date of manufacture. In order to provide a cost efficient tool with superior quality, AST manufactures many tools in the U.S., some overseas & some are imported from Germany.

Printed in the USA on paper made in the USA!

Acura, Audi, BMW, Cadillac, Chevrolet, Chrysler, Cummins, Detroit Diesel, Dodge, Ford, GMC, Honda, Hyundai, Infiniti, Jaguar, Jeep, Kia, Land Rover, Lexus, Mazda, Mercedes, Mini, Nissan, Porsche, Ram, Scion, Subaru, Tesla, Toyota, Volkswagen and Volvo are all registered trademarks.

Warranty Information

AST tools are warrantied against defects in WORKMANSHIP or MATERIALS for a period of five years, unless they are wear items. Warranty durations run from the date of documented purchase (the day of purchase by the end user). All returns must be accompanied by original sales receipt. Excluded are: Hazet and Stahlwille products, Hammer Nuts (TM #'s) and copper hammers.

Include name, address, telephone number and a short description of the problem. All items returned will be inspected and if found defective, will be either repaired or replaced at the option of the manufacturer. If an item has already been discontinued, it can only be replaced if stock exists.

AST tools are designed for HAND USE ONLY! AST impact sockets with black finish are the exception. The use of impact tools will automatically void warranty.

#312 #375 #437 #500 #562 #625

ASTtool Products carry a 5-year warranty with the exceptions stipulated below:

Stud Removers: Stud removers are warrantied for 10 years.

- Internal parts: DO NOT send in your stud remover that only needs the internal parts replaced. Simply call for assistance and we will send out a replacement parts kit [at no charge while under warranty]. The table above indicates replacement numbers for the internal parts.
- External body: The production year is stamped on the stud remover. Only if the external body is damaged, should the stud puller be sent in, if it is within the 10 year warranty.



The AST Production Year is stamped on the stud remover.

Stud removers are warrantied for 10 years from this date.

Sockets marked "For Hand Use Only", will not be warranted if damaged by use with a Power/Impact Tool.

Hazet and Stahlwille carry a one year warranty. Currently AST only carries 2-3 products from Hazet & Stahlwille.

Sets and Kits: If only one item is defective, that item will be replaced, not the entire set. If only a part on a tool is defective, (i.e. gasket, rubber band, etc.) only the part will be replaced. Cooling system adapters with plastic tester attachment piece may be repairable for a \$25.00 fee.

Cooling System Adapters with plastic tester attachment piece may be repairable for a nominal fee.

Copper Hammer #T314 and Hammer Nuts (TM #'s): there is no warranty on these items as they are intended to wear.

Defective Products: Send freight prepaid, by the customer, to AST for inspection. Warranty is handled by replacing the defective item, or the defective part on the item. AST will only cover UPS/Ground return shipping, to the customer, for warranty items.



Are you tired of hearing this when you call other companies?

"Our offices are located at..."

(Like you called to find out where they are!)

"Thank you for calling, if you know your party's extension..."

(Yea, right, I have my party's extension saved on a napkin from yesterday!)

"All of our agents are currently assisting other customers..."

(Does this mean I will wait 10 minutes, for a call center off shore to answer?)


"If you know the first or last name of the person you wish to speak to..."

(I see 150 customers on my tool route every week, and don't have time for this!)

At AST there are real people answering our phones!

People at a company can spend hours on bureaucracy, flow charts, excel sheets, engineering data, conformance, compliance, etc. At some point, you need to truly test the product on the job it was designed for and manufacture it correctly. Then it must be sold and serviced in a manner that is as simple as possible for the consumer.









ASIAN MODELS ACURA / HONDA HYUNDAI / KIA MAZDA NISSAN / INFINITI LEXUS / SCION / TOYOTA SUBARU 7-20 1-20 10 11-12 13-14 15-17 18-20



#HON37517

Serpentine Belt Wrench



Serpentine belt wrench equipped with dual 17mm 12-point sockets. One side a shallow, secured 17mm, 12-point and the other a 3/8" drive with removable long 17mm, 12-point for engagement every 30 degrees. Applicable: Acura MDX [2014-2016], Honda Accord 4-cyl. [2014] , CR-V [2015– 2016], Crosstour [2014–2015], Odyssey [2016– 2018] and Pilot [2016].



#HON1419

Serpentine Belt Wrench



#FZ13818 **Tank Adapter**




Used for pressurizing cooling system. For Honda models with small, shallow necks. Applicable to Roura MDX [2018]; Honda Accord [1994–2016], Civic [1994–2015], Clarity [2018], CR-V [2014-2016], Element [2008], Odyssey [1999–2018], Pilot [2003– 2016] and S2000 [2008].



#HONBC26 **Brake Fluid Adapter**



Used in conjunction with pressure bleeder. 1/4-18 NPT fitting is not included. Applicable: Honda Accord, Civic, Odyssey and Pilot.





• DO NOT USE BRAKE CLEAN

#0FH0N1033.

California Residents: Proposition 65 WARNING. See page 125 for info.



#3035

3.5mm Socket

Used for R & R of the Proximity (Radar) Sensors and any place a 3.5mm socket is needed.

- 1/4" Drive
- 25mm Length



#JAS6514

Oil Filter Wrench

Applicable to various Honda models [1987-2018] and Honda Powersports vehicles that utilize "HF303" oil filters.

- 65mm 14 Flats
- 3/8" Drive



#HO10PT

10-Point Socket

Applicable to Acura RSX and Honda Civic [2001–2006] rear lower control

- 16mm
- 1/2" Drive
- 40mm Length





#OFH33

Funnel Extension





Oil funnel extension for #0FH0N1033 and OFH0N33 oil funnels. Adds coverage and access where normal funnels do not fit. Applicable to ACURA MDX, ZDX; Honda Odyssey, Pilot, and Ridgeline.

• DO NOT USE BRAKE CLEAN

NOTE: USED IN CONJUNCTION WITH #OFHON1033 OR #OFHON33 FUNNEL.

California Residents: Proposition 65 WARNING. See page 125 for info.

#TM12125

Ball Joint Hammer Nut




Used for breaking free steering knuckle/suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/suspension joints threaded shafts.

- M12 x 1.25 Threads
- 22mm 7/8" Hex



NOTE: FOR THE COMPLETE 4PC. SET, PURCHASE THE #TM20194 CONTAINING M12X1.25, M12X1.5, M14X1.5 AND M16X1.5.






#OFGMRD08

Engine Oil Funnel



Attaches directly to the engine oil filler neck. Applicable to Hyundai Santa Fe 2.4L [2001– 2006], Sonata [2002–2005], Tiburon [2006–2010] and Tucson [2004–2010].

- DO NOT USE BRAKE CLEAN
- . Made of strong polycarbonate
- · No more messes






#OFHD35

Engine Oil Funnel



Oil funnel threads on and seals. Applicable to Kia Forte [2013–2018], Optima [2016-2018], Rio [2013–2018], Sedona [2015-2018], Sorento [2011-2016], Soul [2013-2018] and Sportage [2014-2018].

 DO NOT USE BRAKE CLEAN







#ATFSU100

Universal ATF Attachment



Used with our ATF driveline filler. This flexible adapter is used to fit into hard to reach applications where there is at least a 10mm internal diameter opening to fit into. Great for automatic transmission fill on Kia models with restricted access to transmission fill tube.

#6300T-50 Torx Socket

NEW!

Used in conjunction with #ALT34018 on KIA Alternator Pulley Bolts.

- T-50
- 3/8" Drive
- 70mm Length



#ALT34018

Alternator Pulley Socket

NEW!

Used for R and R of the free-wheel pulley on the alternator on Bosch Alternators. Used in conjunction with #6300T-50.



#2127 Oil Filter Socket



Used on various Hyundai and Kia models. Applicable to Hyundai Azera [2009–2012], Equus [2011–2013], Genesis [2008–2013], Santa Fe 3.3L [2009], Sonata 3.3L [2009], Veracruz [2007–2013]; Kia Amanti [2007–2009], Borrego [2009–2012], Cadenza [2014-2018], Sedona [2016-2018] and Sorento [2007-2018].

- 27mm 6 Flats
- 3/8" Drive

#SU8015

Oil Filter Wrench

Applicable to Hyundai S Coupe [1992–1994], Accent [1995–2013], Elantra [1992–2013], Excel [1986–1994], Genesis Coupe 2.0L [2008–2012], Santa Fe [2000–2009], Sonata [1992-2012], Tiburon [2001–2008], Tucson [2004–2012], Veloster [2011–2013], XG300 [2000–2005], XG350 [2000–2005], KIA Amanti [2004–2006], Forte [2010–2018], Niro [2017-2018], Optima [2001–2018], Rio [2006–2018], Rondo [2007–2009], Sorento [2003–2018], Soul [2010–2018], Spectra [2004–2009] and Sportage [2005–2018].

- 80mm 15 Flats
- 3/8" Drive







#FM2330 3-Piece Timing Set

Used on all Mazda 2.0L MZR, 2.3L (turbo and naturally aspirated) and 2.5L engines. *[2004-older] 2.0L engines use the FM 2303 crank pin. Applicable to Mazda 3 [2004-2013], 5 [2006-2013], 6 [2003-2013], 7 [2007-2012], Mazdaspeed 3 [2007-2013], Mazdaspeed 6 [2006-2007], and MX-5 Miata [2006-2013].

COMPARABLE: #303-507, #303-465 AND #303-1061.





#FZ13818 Radiator Adapter



For pressurizing cooling system. Applicable to Mazda 5 [2007], Protege (manual) [2000–2001], Protege 5 [2003].

#FZ47 Tank Adapter



M49 x 2.5 threads



#F1248

Camshaft Timing Set

Camshaft Holding Fixtures and Chain tensioner hold down tool for Mazda CX-9 [2007-2015].

COMPARABLE: #303-1248 AND #303-1530.









#OFFM2012

Engine Oil Funnel



Used on newer Mazda 4 cylinder engines and attaches directly to engine oil filler neck or valve cover. Applicable to Mazda 3 [2006-2018], 5 [2005-2015], CX-5 [2013-2018], CX-9 [2016-2018], Mazdaspeed 3 [2007-2015], Mazdaspeed 6 [2005] and MX-5 Miata [2006-2018].

- DO NOT USE BRAKE CLEAN
- . Made of durable ABS plastic
- · May not fit some applications where the fire wall cowl doesn't provide clearance for attachment of funnel.

California Residents: Proposition 65 WARNING. See page 125 for info.





#OFHON1033 Engine Oil Funnel



Threads and seals just like the cap. Used on Mazda 2 [2011-2014].

• DO NOT USE BRAKE CLEAN

California Residents: Proposition 65 WARNING. See page 125 for info.



#M0219 Oil Filter Wrench



Applicable to Mazda 3 [2004-2009], 5 [2006-2011], 6 [2003-2009] and CX-7 [2007-2009].

- 74mm 14 Flats
- Uses 22mm Socket
- California Residents: Proposition 65 WARNING. See page 125 for info.



#JAS6514

Oil Filter Wrench

Applicable to Mazda 3 [2012-2018], 6 [2014-2018], CX-3 [2016-2018], CX-5 [2013-2018] and MX-5 Miata [2016-2018].

- 65mm 14 Flats
- 3/8" Drive



#OFGMRD08





Attaches directly to the oil filler neck. Applicable to Mazda CX-9 [2007-2015].

- DO NOT USE **BRAKE CLEAN**
- Made of strong polycarbonate



California Residents: Proposition 65 WARNING. See page 125 for info.



#V450 **Brake Caliper**



Used for turning in the rear brake caliper piston on Mazda 3.

• 3/8" Drive





#MSP1412 **Magnetic Spark** Plug Socket



Used to remove spark plugs on Nissan 1.8L engines and Pathfinder [2015].

- 14mm 12 Point
- 3/8" Drive
- · Strong internal magnet holds spark plug firmly



#SP1412 **Spark Plug Socket**



Used to remove spark plugs on Nissan 1.8L engines and Pathfinder [2015].

- 14mm 12 Point
- 3/8" Drive
- · Rubber boot to hold spark plug



#FZ32A **Tank Adapter**





For pressurizing cooling system. Applicable to Nissan Armada [2005-2016] and Titan [2004-2016].

• M52 x 2.5 threads

#FZ36 **Cap Adapter**





For testing pressure relief valve in cooling system cap. Applicable to Nissan Armada [2005–2015] and Titan [2004–2015].

• M52 x 2.5 threads

#8026 **Fuel Line Disconnect Tool**




#OFHON1033

Engine Oil Funnel



Fits various Nissan models. Threads and seals just like the cap. Applicable to Nissan Altima [2016-2018], Maxima [2008-2018], Pathfinder [2010-2018] Rouge [2012-2018] and Sentra [2013-2018].

 DO NOT USE BRAKE CLEAN





#JAS6514

Oil Filter Wrench

Applicable to Infiniti most models [2004-2018]; Nissan 350Z [2002-2009], 370Z [2010-2018], Altima [1997-2018], Armada [2004-2018], Cube [2009-2014], Frontier [1997-2018], GT-R [2008-2018], Juke [2011-2016], Maxima [1994-2018], Murano [2002-2018], Path nder [1995-2018], Quest [2006-2016], Rogue [2008-2018], Sentra [2001-2018], Titan [2003-2018], Versa [2006-2018] and Xterra [2002-2015].

- 65mm 14 Flats
- 3/8" Drive



#ATF180

Transmission Filling Adapter



For use with our ATF Driveline Filler Sets. Applicable to Infiniti models with 7-speed automatic transmissions. Applicable to Infiniti EX35 [2008 – 2012], EX37 [2013–2013], FX35 [2010–2012], FX37 [2013–2013], FX35 [2010–2012], FX37 [2013–2013], G37X [2010–2013], G37X [2010–2013], M35H [2012–2013], M37 [2011–2013], M37X [2011–2013], M56 [2011–2013], M56X [2011–2013], Q50 [2014–2017], Q70 [2014–2017], Q70 [2014–2017], Q70 [2014–2017], QX56 [2011–2013], QX50 [2014–2017], NX50 [2014–2017], NX50 [2014–2017], NX50 [2014–2017], NX50 [2014–2017], NX50 [2017–2017], NV2500 HD [2017–2017], NV3500 HD [2017–2017], NV3500 HD [2017–2017], NV3500 HD [2017–2017], NV3500 HD [2017–2017].



#ATFBASIC

Basic Driveline Filler

Used for filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Individual manufacturer sets are available as well as the individual adapters. U.S. made container, made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pump—saving both time and clean up afterwards. Used to fill Nissan Leaf gear reduction assembly.

- Used only to Fill, Not to Drain— So Clean Fluid Stays Clean
- 8 Liter Capacity
- Quick Attachment Adapters
- · Pump Dispenses Efficiently
- On/Off Ball Valve
- Hose Length: 4ft 10in



#ATF125NIS Transmission Filling Adapter



Used with #ATFBASIC or any of our other ATF filling set to fill the new Nissan CV transmission. Applicable to Infiniti QX60 [2014–2017], Nissan Altima [2014–2017], Murano [2015 –2017], NV200 [2015 – 2017], Pathfinder [2013–2017], Quest [2015 –2017], Rouge [2014-2017], Sentra [2013–2017] and Versa [2013–2017].







#TOY647LG

Oil Filter Wrench

NEW!

Applicable to Toyota V6 and V8 engines with canister style filter cartridge [2005-2019]. Does not fit on Sequoia.

- 64mm 14 Flats
- 3/8" Drive




#T0Y730

Oil Filter Wrench

Applicable to Lexus ES 250 [1990–1991], ES 300 [1992–2003], ES 300h [2013], ES 330 [2004–2006], GS 300 [1993–2005], GS 400 [1998–2000], GS 430 [2001–2004], GX 470 [2004–2009], IS 300 [2001–2005], LS 400 [1990–2000], LS 430 [2001–2006], LX 450 [1996–1997], LX 470 [1998–2007], RX 300 [1999–2003], RX 330 [2004–2006], RX 400h [2006–2008], SC 300 [1992–2000], SC 400 [1992–2000], SC 430 [2002–2010]; Toyota 4Runner [2003–2009], FJ Cruiser [2007–2009], Land Cruiser [1993–2007], Sequoia [2001–2009], Tacoma [2005–2013] and Tundra [2000–2010].

- 73mm 14 Flats
- 3/8" Drive 24mm or 15/16" Socket





#M0219

Oil Filter Wrench

California Residents: Proposition 65
WARNING. See page 125 for info.

Includes: #T0Y640, #T0Y730, and #M0219,

With the #TOY300 you have every gas engine

Toyota and Lexus model covered [1980-2019].

Applicable to Toyota 4Runner [1985–2002], Avalon [1995–2002], Camry V6 [1988–2004], Highlander V6 [2001–2010], Previa [1991–1997], Sienna [1998–2007], Solara V6 [1999–2009], Supra [1979–1998], T100 [1993–1998], Tacoma [1995–2012] and Tundra [2000–2004].



- 74mm 14 Flats
- Used with 22mm socket
- California Residents: Proposition 65 WARNING. See page 125 for info.


#TOY640

Oil Filter Wrench



Applicable to all models with paper cartridge-style filter in Lexus CT 200h [2011-2016], ES 350 [2007-2018], GS 300 [2006-2018], GS 350 [2007-2018], GS 450h [2007-2018], GS 460 [2008-2011], GX 460 [2010-2018], HS 250h [2010–2013], IS 250 [2006-2010], IS 250 C [2010–2016], IS 350 [2006-2018], IS 350 C [2010-2016], IS F [2008-2014], LS 460 [2007-2016], LS 600h [2008-2016], LX 570 [2008-2018], RX 350 [2007-2018], RX 450h [2010-2018]; Scion tC [2005-2016], xA [2004-2006], xB [2004-2016], xD [2008-2013]; Toyota 4Runner [1985-2019], Avalon [1995-2019], Camry [1983-2019], Corolla [1983-2019], Echo [2000-2005], FJ Cruiser [2010-2014], Highlander [2001-2019], Prius [2001-2019], Matrix [2003-2014], MR2 [1985-2005], Paseo [1992–1997], RAV4 [1996–2019], Sequoia [2009–2016], Sienna [2007–2019], Solara [1999-2009], Tundra [2007-2019], Venza [2009-2016] and Yaris [2006-2019].

- 64mm 14 Flats
- Used with 24mm or 15/16" Socket







#TOY18B Brake Bleeder Adapter for Toyota

Fits quickly onto brake master cylinder reservoirs on most Toyota vehicles. Used in conjunction with pressure bleeder and 1/4-18 NPT fitting (NOT INCLUDED) to flush brake fluid on a wide range of vehicles. The tool's design reduces time and effort when flushing the brake system. Applicable to most Lexus, Scion and Toyota models.

#8026

Fuel Line Disconnect Tool





#TM1215

Ball Joint Hammer Nut

NEW!

Used for breaking free steering knuckle/suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/suspension joints threaded shafts. Can also be used to remove wheel studs.

- M12 x 1.5 Threads
- 22mm -7/8" Hex

#TM1415


Ball Joint Hammer Nut

NEW!

Used for breaking free steering knuckle/ suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts.

- M14 x 1.5 Threads
- 22mm 7/8" Hex





Hammer Nut

NOTE: FOR THE COMPLETE 4PC. SET, PURCHASE THE #TM20194 CONTAINING M12X1.25, M12X1.5, M14X1.5 AND M16X1.5.

Air Hammer Punch

Ball Joint/Tie Rod

#OFTOY1038

Engine Oil Funnel



Applicable to All Toyota and Lexus models with a threaded oil cap. For Toyota and Lexus 1/4-turn style oil caps see #0FT0Y1001.

DO NOT USE BRAKE CLEAN

NOTE: FOR TOYOTA PRIUS AND YARIS, THE FUNNEL NEEDS TO BE USED IN CONJUNCTION WITH OUR #0FT38 OR #0FA38 EXTENSION.



#TOY1914

Serpentine Belt Wrench for Toyota



Equipped with 14mm and 19mm, 12 point secured attachments. Works on most Toyota applications (except Hybrids). Applicable to Scion FR-S [2014]; Toyota Corolla [1998-2005], Highlander [2008], Matrix [2004], RAV4 [2002],



#OFT38

Funnel Extension for Toyota

Adds coverage and access where normal funnels do not fit. Applicable to Toyota Prius and Yaris. Only used in conjunction with #0FT0Y1038 or #0FT0Y38 funnels.

DO NOT USE BRAKE CLEAN

California Residents: Proposition 65
WARNING. See page 125 for info.






Sequoia [2008] and Tundra [2008].



#ATFTOY118

ATF Adapter for Toyota



M18 x 1.5 Threads

COMPARABLE: #00002-11103-02



#TOY288

Front Hub Nut Socket



Used for R & R of the front hub lock nut on Toyota 2WD trucks [2007-Newer]. Applicable to Sequoia [2008-2014] and Tundra [2007-2014].

• 3/4" Drive

COMPARABLE: #09602-60010



#TOY105 **Head Bolt Socket**



Used for newer Toyota Yaris, Prius that use a special #8 bi-hexagon socket. Applicable to Toyota Paseo, Prius [2001–2009], Tercel and Yaris [2006–2013].

- #8 BI-HEXAGON
- 1/2" Drive
- 100mm Length







Used for removing line clamps found on Toyota Tacoma [2015-2018]. Fits both high and low side clamps.

- Manufactured from 304 Stainless Steel
- 5" length
- Appropriate chamfer opens clamps



Camshaft Pulley Holder

Fits Toyota models. Includes 3 sets of interchangeable pins. Pins may be threaded in two different locations, based on application access. Overall length 18". 12" spread between pins at tip of arms, when pivot arm is at 90 degrees. Holding pins are made in USA.

#100-30A **Axle Nut Socket**




Thin-walled Applicable to Toyota models with 30mm 12-point axle nuts.

- 30mm
- 1/2" Drive
- 85mm Length

#TOY200

A/C Clamp Remover



- For Tacoma [2015-2018], see #T0Y211.
- · Stainless steel release pins.

COMPARABLE: #09870-00015 AND #09870-00025



#\$3054X-10 **Head Bolt Socket**



Used for R & R of cylinder head bolts on Toyota Matrix [2003-2007].

- 10mm
- 1/2" Drive
- 140mm Length



#FZ13818


Coolant Adapter

For pressurizing cooling system. Works with many different Toyota models with small, shallow necks, **Including Toyota Camry** [1992-2019], Highlander [2019], Sienna [2010-2019], Tacoma [2006-2019] and Tundra [2000-2019].



#FZ148

Tank Adapter



• M34 x 3 Threads



#S3054X-12 **Head Bolt Socket**

• 140mm Length



#TOV185

Wheel Bearing Nut Socket



Used for R & R of wheel bearing nut located on inboard side of wheel hub on 2WD Toyota 4Runner [1995-2006], T100 [1995-1998] and Tacoma [1995-2006].

• 1/2" Drive

COMPARABLE: #09318-12010-SOCK




#SU8252

Crankshaft Socket

NEW!





Used to align crank to T.D.C. while working with the timing chain. Also works on older 3.0L 6 cylinder DOHC engines. Applicable to Subaru BRZ [2013-2017], Forester [2012-2017], Impreza [2012-2017], Impreza WRX [2015-2017], Legacy [2013-2015], Outback [2013-2015], Tribeca B9 and Crosstrek [2013-2017].

COMPARABLE: #18252AA000

#SU7500 **Crankshaft Socket**



Crankshaft Socket for Subaru used to align crank to T.D.C. while working with the timing belt on Subaru Baja [2003–2006], Forester [1998–2013], Impreza [1997–2011], Impreza WRX [2002–2014], Impreza WRX STI [2004–2014], Legacy [1996–2012] and Outback [1996-2012].

• 1/2" Drive

COMPARABLE: #499987500

#SU3625

Camshaft Sprocket Holder



NOTE: 2.5L DOHC TURBO ENGINES WILL ALSO REQUIRE THE USE OF THE #SU 200T IN CONJUNCTION WITH #SU 3625.

COMPARABLE: #499977500



#SU200T Camshaft **Pulley Holder**

Used to hold the camshaft pulley for removal on 2.0L Turbo, 2.5L Turbo and 2.5L SOHC engines. Applicable to Subaru Baja [2004-2006], Forester [1999-2013], Impreza [1999-2011], Impreza WRX [2002-2014], Impreza WRX STI [2004-2015], Legacy [1999-2012] and

NOTE: 2.5L DOHC TURBO ENGINES WILL ALSO REQUIRE THE USE OF THE #SU 3625 IN





#SU7250

Cam Pulley Holder



Used to hold the crankshaft pulley on 2.5L engines. This tool works on models with crank pulley Subaru part #12305AA251 on Baja [2003–2006], Forester [1999–2013], Impreza [1999–2014], Impreza WRX [2002–2014], Legacy [1999–2012] and Outback [2002–2012].

• 1/2" Drive

COMPARABLE: #499977100. IF YOUR CAR IS EQUIPPED WITH PULLEY #12305AA242, PLEASE SEE #SU499977400.

IMPORTANT NOTE: IN SOME CASES, VARIOUS REPAIR MANUALS AND SERVICES CALL FOR THE #499977100, BUT IS NOT THE CORRECT TOOL NEEDED. VERIFY YOUR VIN# WITH A DEALERSHIP TO FIND OUT WHICH PULLEY YOU HAVE FOR SURE.



#SU250

Camshaft Gear Holder


Camshaft gear holding tool is only used for holding the pulley while breaking the camshaft gear nut loose Subaru 2.5L DOHC (non-turbo) engines [1996-1999]. Applicable to Subaru Forester [1998], Impreza RS [1998], Legacy [1997-1999] and Outback [1996-1997].

NOTE: THIS IS NOT USED FOR SETTING THE TIMING.

COMPARABLE: #499207300








#OFSU42Funnel Adapter






For use only in conjunction with our #FUN14KIT or #OFKIT. Fits all Subaru models with threaded oil cap (except Tribeca). Also fits the Subaru BRZ and Scion FR-S.

- DO NOT USE BRAKE CLEAN
- We left space in the #FUN14KIT to accommodate this adapter.
- · Purchase separately





#SU6514

Oil Filter Wrench

Used on Subaru factory oil filter #15208AA12A [2000-2018].

- 65mm 14 Flats
- 3/8" Drive



#GM245

GM Fuel Injector Seal Set



Used for replacing the fuel injector seals on Subaru 2.0L Turbo and 2.4L Turbo engines [2014-2019].



#SU8015

Oil Filter Wrench

Applicable to Subaru BRZ [2013-2017], Forester [2016+], Impreza WRX [2016+], Legacy (6- cyl.), Outback and Tribeca.

- 80mm 15 Flats
- 3/8" Drive

FITS NAPA GOLD OIL FILTER #1334




#TM12125

Ball Joint Hammer Nut

NEW!

Used for breaking free steering knuckle/ suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts. Can also be used to remove wheel studs.

- M12 x 1.25 Threads
- 22mm 7/8" Hex



NOTE: FOR THE COMPLETE 4PC. SET, PURCHASE THE #TM20194 CONTAINING M12X1.25, M12X1.5, M14X1.5 AND M16X1.5.






#FZ13818Tank Adapter

For pressurizing cooling system in Subaru vehicles with small, shallow necks. Applicable to Subaru Ascent [2019], BRZ [2013-2017], Forester [2016], Impreza [2006-2018], legacy [2016], Outback [2005-2018], Tribeca B9 [2006] and Crosstrek [2013-2018].





#MSP1412

Magnetic Spark Plug Socket



Applicable to Subaru BRZ [2013-2018] and Forester [2013-2018].

- 14mm 12 Point
- 3/8" Drive
- Strong internal magnet holds sparkplug firmly



#SP1412 **Spark Plug Socket**



Applicable to Subaru BRZ [2013-2018] and Forester [2013-2018].

- 14mm 12 Point
- 3/8" Drive
- · Rubber boot to hold spark plug



#ATFSU100

Universal ATF Attachment



Used with our ATF driveline fillers. This flexible adapter is used to fit into hard to reach applications where there is at least a 10mm internal diameter opening to fit into. Applicable to newer Subaru automatic turbo models where the intercooler is blocking access to transmission fill tube.

RECOMMENDATION: USE WITH #ATFBASIC.



#8028

Fuel Line Disconnect Tool

Applicable to Subaru Forester [2004-2014], Impreza [2004-2011], Impreza WRX [2004-2014], Impreza WRX STI [2004-2014] (except 2006), Legacy [2004-2014], Outback [2004-2014]





#SU070

Drain Plug Socket



#ATFSU118

Filling Adapter

NEW!

Used for filling the front Differential. Applicable to Subaru Cross Trax [2012-2017], Forester (non turbo) [2014-2017], Impreza (non turbo) [2012-2017], Legacy (4 cyl.) [2013-2017] and Outback (4 cyl.) [2013-2017]. Used in conjunction with our ATF BASIC and our other ATF Filling Sets.


M18 x 1.5 Threads











TOOLS FOR

TESLA

DOMESTIC MODELS	21-32
CHRYSLER / DODGE /	
JEEP / RAM	22-24
FORD	25-30
GENERAL MOTORS	31-32

107





#8016

1/2" Oil Cooler Line Remover

For removing both oil cooler lines from fitting on automatic transmission and oil coolers. Applicable: Dodge Ram trucks with V10 or Cummins turbo diesel [1995-2016].



#2124

Oil Filter Socket

Applicable to Chrysler 200 [2011-2016], 300 [2011-2013], Town & Country [2011-2016]; Dodge Avenger, Challenger, Charger, Durango, Grand Caravan and Journey [2011-2016].

- 24mm 6 Flats
- 3/8" Drive



#2127

Oil Filter Socket

Applicable to Dodge Dart [2012-2013].

- 27mm 6 Flats
- 3/8" Drive



#2175


Oil Filter Socket





Applicable to Dodge Sprinter 2.7L [2003-2006].

- 74.5mm 14 Flats
- Used with 22mm socket






#M0284 Oil Filter Wrench

Used on 3.0L CRD (Common Rail Diesel) V6 engines in Dodge Sprinter [2007-2013] and Jeep Grand Cherokee [2007-2008].

- 84mm 14 Flats
- · Used with 22mm socket





#M0219 Oil Filter Wrench



Used on Dodge Avenger [2012-2013], Caliber [2012-2013], Dart [2012-2013] & Sprinter (gas) [2003-2012].

- 74mm 14 Flats
- Used with 22mm socket

California Residents: Proposition 65 WARNING. See page 125 for info.




Oil Filter Wrench





Used to remove and install the transmission cooling return line filter on 45RFE and 545RFE automatic transmissions found in Chrysler, Dodge and Jeep vehicles.

- 64mm 14 Flats
- Used with 22mm socket





#OFCRY36

Engine Oil Funnel



Used for Chrysler and Dodge models equipped with the 3.6L engine. Applicable to Chrysler Town & Country; Dodge Avenger, Challenger, Charger, Dart, Durango, Grand Caravan, Journey and Jeep Wrangler [2011–2017].

- DO NOT USE BRAKE CLEAN
- Made of strong polycarbonate
- Creates a custom fit to valve covers and filler necks

California Residents: Proposition 65 WARNING. See page 125 for info.



#FUNCRY36 **Funnel Adapter**





Oil funnel adapter for Chrysler/Dodge models equipped with the 3.6L engine. This is to be used with our #FUN14KIT. Applicable to Chrysler Town & Country; Dodge Avenger, Challenger, Charger, Dart, Durango, Grand Caravan, Journey and Jeep Wrangler [2011–2017].

- DO NOT USE BRAKE CLEAN
- Made of strong polycarbonate
- Creates a custom fit to valve covers and filler necks

California Residents: Proposition 65
WARNING. See page 125 for info.


#OFHON1033

Engine Oil Funnel



Engine oil Funnel. Threads and seals just like the cap. Applicable: Dodge Caravan 3.8L, Challenger, Charger and RAM Trucks equipped with 5.7L Hemi engines [2010-2018] and Jeep Wrangler [2002-2011].

• DO NOT USE BRAKE CLEAN





#FZ55 **Tank Adapter**





Cooling system pressure tester adapter. Applicable to Dodge / Freightliner / Mercedes Sprinter vans [2007–2019].

M46 x 2.5 Threads



#FZ25 **Tank Adapter**





For pressurizing cooling systems of Ram Trucks Promaster Van [2014-2018].

• M47 x 3 Threads

#FZ35A **Tank Adapter**



For pressurizing cooling system. Works with many different domestic vehicles. Applicable to Chrysler 200 [2015], Pacifica [2017]; Jeep Grand Cherokee [2016-2017] and RAM 3.6L, 3.0L EcoDiesel [2014-2018] and 6.7L Cummins [2013-2018].


• M52 x 2.5 Threads



#SPR0558

Glow Plug Pliers

For disconnecting the electrical connector that is attached to the glow plug used on Dodge Sprinters.



#M1020

Glow Plug Socket

Applicable to Dodge Sprinter.

- 10mm
- 3/8" Drive



#M820

Glow Plug Socket

Applicable to Dodge Sprinter.

- 8mm
- 3/8" Drive



#7200

Camshaft Pulley Holder

Fits multiple Chevrolet, Dodge, Ford and GMC models. Includes 3 sets of interchangeable pins. Pins may be threaded in two different locations, based on application access. Overall length 18". 12" spread between pins at tip of arms, when pivot arm is at 90 degrees. Holding pins are made in USA.

FOR DODGE OR GM COVERAGE, YOU WILL ALSO NEED TO PURCHASE TWO #7200-4 PINS



#**7200-4**Pins



For use with #7200 camshaft pulley holder. Holds camshaft gears on Dodge Durango 4.7L [2000–2009].

• Must purchase '2' (two) to make a pair.

NOTE: AVAILABLE SEPARATELY, NOT INCLUDED IN #7200



#SPR886

Transmission Dipstick

Used on Dodge / Freightliner Sprinter [2002-2009] and Chrysler Crossfire [2004-2008].

COMPARABLE: #8863B





#CRY933

Transmission Dipstick



Used on all vehicles equipped with a NAG1, 42RLE, 62TE and CVT transmission. Applicable to Chrysler 200 [2011–2014], 300 [2006–2014], Aspen [2008–2009], Pacifica [2007–2008] Sebring [2007–2013], Town & Country [2008–2017]; Dodge Avenger [2007–2014], Caliber [2007–2012], Challenger [2008-2014], Charger [2006-2014], Dakota [2008-2011], Durango [2008-2013], Grand Caravan [2008-2017], Journey [2009-2014], Magnum [2006-2013], Nitro [2007-2011], Promaster [2014–2017], Ram [2007-2013], Jeep Commander [2006-2010], Grand Cherokee [2006-2013], Liberty [2006-2012], Patriot [2007-2013] and Volkswagen Routan [2009-2014].

COMPARABLE: #9336 AND #9336A



#ATF101 ATF Adapter



Adapter used in conjunction with the ATF Filler System for Ford Explorer [2004–2010], Mustang [2005–2010] and Thunderbird [2002-2005].

- 1/8-27 NPT Threads
- Does not include pump, container, hose, or shut-off valve.
- NOTE: FOR THE COMPLETE FORD SET, SEE TOOL #ATF FORD

#FZ32A **Tank Adapter**



#FZ35A **Tank Adapter**



For pressurizing cooling system. Applicable to Ford Edge 3.5L [2013], Escape [2010-2012], Excursion [2002-2004], Explorer [2014-2016], F150 [2004-2014], F250 [2002-2016], Five Hundred [2005], Fusion [2010-2012], Mustang [2011-2014] and Taurus [1996-2006].

For pressurizing cooling system. Offers the same Ford coverage as the #FZ32A.





• M52 x 2.5 Threads





Used to test coolant pressure cap. Works with many domestic vehicles.

• M52 x 2.5 Threads



#FZ47 **Tank Adapter**




For pressurizing the cooling system. Applicable to Ford C-Max [2014-2016], EcoSport [2018], Edge [2013–2018], Escape [2014–2018], Expedition [2015-2018], F-150 [2015-2018], Fiesta [2011-2018], Focus [2012–2018], Fusion [2013–2018], Mustang [2016-2018], Transit 150/250 [2015-2016] and Transit Connect [2014-2015].

M49 x 2.5 Threads





#ATFFORD Driveline Filler



Used for filling Ford Explorer [2004-2010], Mustang [2005–2010] and Thunderbird [2002–2005] automatic transmissions.

- 8 Liter capacity
- Hose length: 4' 10"
- #ATF101 adapter included.
- U.S. made container, made of UHDP (ultra high density polyethylene).



#F1616T

Engine Timing Set





Used to set timing on the 1.6L Naturally Aspirated and 1.5L/1.6L EcoBoost Turbocharged engines on Ford Escape [2013-2018], Fiesta [2011-2018], Fusion [2013-2018] and Transit Connect [2014-2017].

COMPARABLE: #303-748, #303-1097 AND #303-1550.







#F1616-1552

Camshaft **Alignment Tool**

NEW!

Used to align the rear camshafts on 1.6L Ecoboost engines when the VCT (Variable Camshaft Timing) Phasers have been removed from the front of the camshafts on Ford Escape [2013-2015], Fiesta [2014-2016], Fusion [2013-2014] and Transit Connect [2014-2016].

COMPARABLE: #303-1552



#F1616-376B

Camshaft Alignment Tool

NEW!

Used to align the rear camshafts on 1.6L (non-turbo) engines when the VCT (Variable Camshaft Timing) Phasers have been removed from the front of the camshafts. Applicable

to Ford Fiesta [2013-2017]. COMPARABLE: #303-376B



#F16393

Flywheel Lock

NEW!

Used to hold the flywheel on 1.5L / 1.6L Ford engines. Applicable to Ford Escape [2013-2018], Fiesta [2011-2018], Fusion [2013-

COMPARABLE: #303-393A PLATE AND #303-393-02

[2014-2017].



#F20T

Engine Timing Set



For Ford models with 2.0L turbo EcoBoost engine. Includes the T.D.C. crank timing pin, cam locking plate and the crank position sensor (CPS) alignment block. Applicable: Ford Edge [2013–2015], Escape [2013-2015], Explorer [2012–2015], Focus [2012-2015], Fusion [2013-2015] and Taurus [2013-2015].

COMPARABLE: #303-507, #303-1521, AND #303-1565







#FM2330 3-Piece Timing Set

Used on all Ford 2.0L, 2.3L (turbo and naturally aspirated) and 2.5L engines.
*[2004-older] 2.0L engines use the FM 2303 crank pin. Applicable to Ford Escape [2005–2013], Focus [2005–2013], Fusion 2006–2013] and Ranger [2001–2011].

COMPARABLE: #303-507, #303-465 AND #303-1061.



#FM2303 Crank Locking Pin



Used in conjunction with #FM2330 Ford and Mazda timing set. Applicable to Ford Contour [1998–2000], Escape [2001–2004], Escort ZX2 [1998–2003], Focus [2000–2004]; Mercury Cougar [1999–2002] and Mystique [1998–2000].

COMPARABLE: #303-574

#F1248

Camshaft Timing Set

Camshaft Holding Fixtures and Chain tensioner hold down tool for Ford/Lincoln models with 3.5L, 3.5L Eco-boost and 3.7L in Ford Edge [2007–2015], Explorer [2011–2015], F-150 [2011-2015], Flex [2009–2015], Fusion [2010–2012], Mustang [2011-2015], Police Interceptor [2014–2015], Taurus [2008–2015]; Lincoln MKS [2009–2015], MKT [2010–2015] , MKX [2007–2015], MKZ [2007–2015] and Navigator [2015].

COMPARABLE: #303-1248 AND #303-1530.









#1018

10pc. Line Disconnect Set

NEW!

For R&R of transmission oil cooler lines, fuel filters and fuel lines. This new set includes GM Duramax injector line tool and Subaru fuel line disconnect tool.





#8021

3/8" Oil Cooler Line Remover

For disconnecting transmission oil cooler lines. Flares on the cooler lines near the fittings prevent access with original style tools. The locking clip used in the fitting is different than the standard 'tabs' used on most other applications. #8021 clears the flare and disconnects the new style clips with ease. Applicable: Ford Explorer [2003–2004], F-150 [2003–2008], Expedition [2005] and Cadillac CTS [2003–2004].



#8012 5/16" Fuel Filter Remover



Made of red-anodized aluminum. For R & R of the fuel filter and 5/16" return line from the fuel pump-sending unit. Applicable: Ford Areostar [1990–2006], Bronco, Explorer, E-Series vans [1991–2006], F Series trucks and Ranger [1992–2006].

#8024

1/2" Oil Cooler Line Remover

For R & R of transmission oil cooler lines on Ford Explorer [2007], Sport Trac, Ranger, various other Ford models.



#8023

#8014

1/2" Oil Cooler Line Remover

Used to disconnect 1/2" transmission oil cooler lines on Ford Escape with 6F transmission [2009], Edge [2012], Excursion/ F -250/ F-350 with 6.0L turbo diesel [2005] and Explorer V8 [2008].



5/16" Special Line Remover

For removing both oil cooler lines from the fittings on automatic transmissions on Ford Taurus/Escorts with the AXOD and ATX transmissions.



#8013 3/8" Fuel Line Remover



For removing 3/8" fuel lines and feed lines from the fuel pump-sending unit on Ford Areostar [1990–2006], Bronco, Explorer, E Series vans [1991–2006], F-Series trucks and Ranger [1992–2006].


#OFGMRD08

Engine Oil Funnel

Attaches directly to the oil filler neck on E-Series Van, Edge, Escape [2011], Expedition, Explorer, F-150 [2013-2016], F-250 6.7L Powerstroke [2016-2018], Flex, Mustang [2005-2016], Ranger, Taurus [2011] and Transit [2016].

- DO NOT USE BRAKE CLEAN
- Made of strong polycarbonate

NOTE: FOR FORD POWER STROKE DIESEL ENGINES (6.9L, 7.3L, 6.0L AND 6.4L), SEE #OFHON1033



#OFFM2012Engine Oil Funnel



Used on newer Ford 4 cylinder engines and Attaches directly to engine oil filler neck or valve cover. Applicable to Ford EcoSport [2018], Edge [2012-2018], Escape [2008–2016], Expedition [2016-2018], Explorer [2012–2016], F-150 [2016-2018], Focus [2007–2018], Fusion [2013–2018] and Mustang [2018].

- DO NOT USE BRAKE CLEAN
- Made of durable ABS plastic
- May not fit some applications where the fire wall cowl doesn't provide clearance for attachment of funnel.

California Residents: Proposition 65 WARNING. See page 125 for info.





#OFHON1033 Engine Oil Funnel



and 6.4L).

• DO NOT USE
BRAKE CLEAN

6.0L (turbo diesel), also fits Ford power stroke engines (6.9L, 7.3L, 6.0L

California Residents: Proposition 65
WARNING. See page 125 for info.



#OFAAGMAngled Funnel Extension



Oil Funnel Extension for our #0FGMRD08 Oil Funnel. Adds coverage and access where normal funnels do not fit. Applicable to Ford F-150 and F-250 [2015-2016].

- DO NOT USE BRAKE CLEAN
- Made of durable ABS plastic

California Residents: Proposition 65 WARNING. See page 125 for info.







#MSP1412 Magnetic Spark Plug Socket



Used to remove spark plugs on Ford 4.6L and 5.4L engines.

- 14mm 12 Point
- 3/8" Drive
- Strong internal magnet holds spark plug firmly.



#V450 Brake Caliper Piston Adapter





Used for turning in the rear brake caliper piston on Ford Fusion and Lincoln MKZ.

• 3/8" Drive

#SP1412 Spark Plug Socket



Used to remove spark plugs on Ford 4.6L and 5.4L engines.

- 14mm 12 Point
- 3/8" Drive
- Rubber boot to hold spark plug

NOTE: SPARK PLUG SOCKET IS SLENDER IN DESIGN TO FIT APPLICATION.



#BFLT60



This special machined, long T60 Torx socket is machined for clearance to access the rear wheel bearing bolts without hitting the ABS rotor sensor on Ford Edge / Lincoln MKX [2007-2013].

- 1/2" Drive
- 140mm Length







Applicable to Ford F-250 and F-350 6.0L turbo diesel [2004].

- 36mm 6 Flats
- 3/8" Drive

#M0219 Oil Filter Wrench





Applicable to Ford Escape [2006-2008], Focus [2004-2007] and Fusion [2006-2008].

- 74mm 14 Flats
- Used with 22mm socket

California Residents: Proposition 65
WARNING. See page 125 for info.









#GM140 Engine Timing Set



Used to set the Timing on GM 1.4L Ecotec in Buick Encore [2013-2018]; Chevy Cruze [2011-2018], Sonic [2011-2018] and Trax [2013-2018].

 Comes in plastic storage case




#OFGMRD08Engine Oil Funnel



Attaches directly to the oil filler neck. Applicable to Cadillac, Chevrolet and GMC vehicles.

- DO NOT USE BRAKE CLEAN
- Made of strong polycarbonate









GENERAL MOTORS

#8021

3/8" Oil Cooler Line Remover



For disconnecting transmission oil cooler lines. Flares on the cooler lines near the fittings prevent access with original style tools. The locking clip used in the fitting is different than the standard 'tabs' used on most other applications. #8021 clears the flare and disconnects the new style clips with ease. Applicable to Cadillac CTS [2003-2004] and Chevrolet Corvette [1997-2004].

#8022 **Fuel Filter Removal Tool for GM**

For the R & R of the fuel filter on Chevy Suburban and Tahoes [2002-2004].



#8027

3/16" Fuel Line Release Tool

Used for R & R of fuel lines. Made of orange anodized aluminum. Applicable to Express Van, Sierra and Silverado with 6.6L V8 Duramax engine [2011-2016].



#7200-4 **Pins**







Must purchase '2' (two) to make a pair. For use with #7200 camshaft pulley holder. Used to hold GM water pump pulley on 4.2L straight-6 Vortec engine.

NOTE: AVAILABLE SEPARATELY, NOT INCLUDED IN #7200

#ATF175GM Transmission Filling Adapter





Used on GM vehicles equipped with 6L80/6L90 6-speed automatic transmission. Used in conjunction with our ATF Driveline Filler Sets. Applicable to Cadillac CTS-V [2009], Escalade [2009], STS, XLR-V [2006]; Chevrolet Camaro [2010], Caprice [2011], Corvette [2006], Silverado 1500 [2009]; GMC Yukon Denali [2007]; Pontiac G8 [2008].

• M12 x 1.75 Threads

NOTE: FOR USE WITH #ATF BASIC

#FZ13818 **Radiator Adapter** For pressurizing cooling system. Application to vehicles with small, shallow necks. Used on Chevrolet Metro, Prizm and Tracker [1998].















TOOLS FOR

EUROPEAN MODELS 33-72

BMW / MINI	34-46
JAGUAR / LAND ROVER	47-49
MERCEDES	50-54
VOLVO	55-56
VW / AUDI / PORSCHE	57-72



#BMW0062

A/C Stretch Belt Tool

Used for installing the stretch belt (no belt tensioner is used) on N62 engines [2004-2010].

COMPARABLE: #641040 & #83800494518





#BMW124052 A/C Stretch Belt Tool



Used for installing the stretch belt (no belt tensioner is used) on BMW X5 3.0L gas engines [2007-2010].

• 1/2" Drive

COMPARABLE: #111240

#BMW124057

A/C Stretch **Belt Tool**



Used for installing the stretch belt on M57Y dieselengines in 335d & X5 35d [2009-2013].

• 1/2" Drive

COMPARABLE: #110330

#FZ25 **Tank Adapter**



• M47 x 3 threads







Used to pressurize most BMW coolant reservoirs [1996-2006]. For 5 & 6 series cars [2004-2005], see #BMW350.

M51 x 4 threads





#BMW350 **Tank Adapter**

Used to pressurize BMW coolant reservoirs [2006-2019]. See application chart for model years.

. M52 x 3 threads







#BMW5532 **Fuel Injector Tool**

Used to remove and install injectors on N20 and N55 engines.



#8032 **Fan Clutch Wrench**

Used for R & R of any 32mm fan clutch nuts.





#BMW4622 **Fuel Level Sensor Lock Ring Tool**



Used to remove the fuel level lock ring on BMW/Mini E31, E34, E36, E38, E39, E46, E53, E60, E63, E64, E65, E83, E85, E90, R50, R52, R53, R55, R56 and R57 chassis.

• 1/2" Drive

#BMW7080SAC

Self-Adjusting Clutch Tool

Locating ring and clutch tensioner set used on BMW manual transmissions with Self-Adjusting clutch.

COMPARABLE: #212170 & #212180





#BMW6119F

Fuel Tank Lid Wrench

NEW!

Used to remove and install the metal fuel tank lid on BMW F01, F02, F25 & F30 Chassis.

• 1/2" Drive

COMPARABLE: #161190







Used to set timing on BMW N62, N62TU & N73 engines in BMW 545 [2004-2005], 550 [2006-2007], 550i [2008-2010], 645Ci [2004-2005], 650i [2006-2010], 745i [2003-2005], 745Li [2003-2005], 750i [2006-2008], 750Li [2006-2008], 760i [2005-2006], 760Li [2003-2008], Alpina B7 [2007-2008], X5 [2004-2010].

COMPARABLE: #119190, #119340, #119461, #119462 AND #119463.



#BMW9054 **Fuel Injector** Seal Set



Set used to install new seals onto the injectors on BMW/ Mini N14, N18, N54, N63 & N74 engines. Applicable to BMW 135is [2008-2010], 335i [2007-2010], 335xi [2007-2010], 535i [2008-2010], 535xi [2008-2010], 550i GT [2010-2013], 750i [2009-2013], 750Li [2009-2013], 760Li [2010-2014], X3 [2007-2010], X5 [2008-2013], X6 [2008-2013] and Mini Cooper [2007-2012].

COMPARABLE: #130192, #130193, #130194 AND #130195.

#BMWMC280

Crankshaft Holder

Used for crankshaft when releasing or tightening the central bolt on BMW N51/N52, Mini N12, N14, N16 and N18 engines.

COMPARABLE: #119280 & #83300493940



Used on 3 of the head bolts on BMW N52, N54 and N55 engines. For all of the remaining head bolts on these

- T-50
- 1/2" Drive



#BMW11860

Head Bolt Socket

Used on BMW N51, N52, N54 & N55 engines. Used in conjunction with #BMW11850.

- T-60
- 1/2" Drive
- 195mm Length

COMPARABLE: #118580





#BMW3028

Engine Timing Set

Engine alignment tools for newer BMW N51, N52 and N54 engine [2006-2012]. For N55 engines [2011-2018], use of #BMW5585 is required. Applicable to BMW 128i [2008-2012], 135i [2008-2012], 325i [2006], 325xi [2006], 328Cic [2007-2012], 328i [2007-2012], 328xi [2007-2012], 330i [2006], 330xi [2006], 335Cic [2007-2012], 335i [2007-2012], 335is [2011-2012], 335xi [2007-2012], 525i [2006-2007], 525xi [2006-2007], 528xi [2008-2010], 530i [2006-2007], 530xi [2006-2007], 535i [2008-2012], 535xi [2008-2010], X3 [2007-2012], X5 [2007-2012], X6 [2008-2012] and Z4 [2006-2012].





engines. Applicable to BMW 335Cic [2011-2012], 335i [2011-2013], 335xi [2011-2012], 435i [2014-2016], 535i [2011-2017], 640i [2012-2018], 650i [2012-2013], 740i [2014-2015], 740Li [2014-2015], M235i [2014-2016], X1 xDrive 35i [2013-2013], X3 xDrive 35i [2011-2017], X4 xDrive M40i [2016-2018], X5 xDrive 35i [2011-2018] and X6 xDrive 35i [2011-2018].

COMPARABLE: #114285


California Residents: Proposition 65 WARNING. See page 125 for info.

#BMW2755

Intermediate Spring Tool

Used for removing and installing the pressure spring for the intermediate levers on BMW N20/N26/N52/N55 engines in BMW 135i [2011-2013], 135is [2013], 325i [2006], 325xi [2006], 330i [2006], 330xi [2006], 335Cic [2011-2012], 335i [2011-2014], 335xi [2011-2012], 525i [2006-2007], 525xi [2006-2007], 530i [2006-2007], 530xi [2006-2007], 535i [2011-2014], 640i [2012-2014], X1 35i [2013-2014], X3 35i [2011-2014], X5 35i [2011-2014], X5 35i [2011-2014], Z4 [2006-2008], 228i [2014-2016], 320i [2013-2018], 328i [2013-2016], 428i [2015-2016], 528i [2013-2016], X1 xDrive 28i [2013-2015], X3 xDrive 28i [2013-2015] and Z4 sDrive 28i [2012-2016].





#BMW2026

Engine Timing Set

Used for setting the timing on N20 & N26 2.0L turbo engines in BMW 228i [2014-2016], 320i [2013-2018], 328i [2013-2016], 428i [2015-2016], 528i [2013-2016], X1 xDrive 28i [2013-2015], X3 xDrive 28i [2013-2015] and Z4 sDrive 28i [2012-2016].

COMPARABLE: #2219548, #2212831, #2212830 AND #110300.





#BMW5254

Front Crank Seal Tool Set



Used to loosen the seal for removal & installation of new front crank seals on BMW N52 & N54 engines [2006-2013]. When used in conjunction with #BMW9235 (Sold Separately), this set will also work for N55 engines [2011-2018].

COMPARABLE: #110370, #119220 AND #119230.

#BMW9235

Front Crankshaft Seal Adapter



Used to guide front crankshaft seal on N55 engines. Used in conjunction with #BMW5254.

COMPARABLE: #119235

NOTE: ONLY TWO BOLTS ARE USED

#BMW400-1

T.D.C. Locking Pin



Used for setting crankshaft T.D.C. in M21, M40, M41, M42, M43, M43TU, M44, M47, M47TU, M50, M51, M52, M52TU, M54, M56, M57, M57TU, M60, M62, M62TU, M70, M73, S50B30, S50B32, S54 & S62 engines.

COMPARABLE: #112300

#BMW6222

Chain Tensioner Tool



Used for tensioning the timing chain when adjusting the engine timing. Applicable to BMW/Mini N12, N14, N16, N18, N40, N42, N45, N46, N52, N54 and N62 engines.

COMPARABLE: #119340

#BMW400

Camshaft Alignment Set



Used for setting camshaft timing on M42, M44, M50, M52, M52TU, M54, M56, S50US & S52US engines [1991-2005].

COMPARABLE: #113240 AND #112300.



#BMW575190

Diesel HP Injection Pump Tool

NEW!



Used for removing camshaft sprocket from pump shaft when dismantling the injection pump VP44 and high-pressure pump common rail on BMW M57 engines [2009-2013].





#VW93005 **Wire Terminal Extractor**

Used to remove flat terminals with two tangs from the electrical connector plug (1mm Wide, 2.5mm Apart & 16mm Length).



#BMW2510 **Brake Caliper** Piston Tool

Used to reset the rear EMF adjustment unit and piston to the starting position. Must be used with standard 3/8" extension and ratchet. Applicable to BMW 528i [2011-2016], 535i [2011-2016], 550i [2011-2017], 640i [2012-2017], 650i [2012-2017], X3 [2011-2017] and Z4 [2010-2016].

• 3/8" Drive



#OFAUD1000

Euro 1/4 Turn Oil Funnel







Attaches directly to the valve cover, so when you're adding oil to the engine you don't have to worry about making a big mess due to the internal baffle of the valve cover of BMW engines [1993-2018].

 On some BMWs air intake may need to be removed.

#M0219

Oil Filter Wrench





Used on BMW motorcycles F650, F800, K100, K1100, K1200GT [2003–2004], K1200LT, K1200R, K1200RS [1996–2004], K1200S, K1300, K75, R1100, R1150, R1200C, R1200CL, R1200GSW [2013–2014], R850 and S1000RR.

- 74mm 14 Flats
- Used with 22mm socket

California Residents: Proposition 65 WARNING. See page 125 for info.



#FUN14EURO

FUN14KIT Euro Adapter



Used in conjunction with #FUN14KIT. Attaches directly to the valve cover and so when you're adding oil to the engine you don't have to worry about making a big mess due to the internal baffle of the valve cover of BMW engines [1993-2018].





#BM1276

Oil Filter Wrench

Used on oil filters for BMW i3 "Range Extender" engine [2014-2018] and motorcycles F650F, F800GS, HP2, K 1600 GTL/GT [2007-2016]; K1200GT; K1200R/SP0RT, K1200S, R 1200 ST, R1200GS, R1200R, R1200RT, R1200S, S 1000 RR [2006-2008] with oil filter #11 42 7 673 541.

- 76mm 12 Flutes
- 3/8" Drive



#H2760 Oil Drain Plug Wrench



Used for the R and R of the differential oil filler plug on many BMW models.



#V410 Oil Filter Wrench



Applicable to BMW models with N52, N54, N55 and N63 engines [2006–2017].

- 86.5mm 16 Flats
- Used with 22mm socket

COMPARABLE: #119240

California Residents: Proposition 65 WARNING. See page 125 for info.



#ATF102

Universal ATF Adapter



Adapter used in conjunction with our ATF Filler System and is used on various BMW models.

#23236 32/36mm




cylinder engines [1994-2005].


- . Built Stocky for Better Access to Oil Filter Caps
- Stout Steel Construction
- 32mm x 36mm
- 3/8" Drive




Oil Filter Wrench



- 74.5mm 14 Flats
- Used with 22mm hex








[2017 & Newer]. • 32mm - 6 Flats

530i, 740i, M240i & X1

• 3/8" Drive

#2132





Used for filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Individual manufacturer sets are available as well as the individual adapters. Container made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pump—saving both time and clean up afterwards.

> For many domestic and foreign applications. The 27mm, 32mm, 36mm hex sizes and the four, cup-style wrenches cover many BMW engines.

California Residents: Proposition 65 WARNING. See page 125 for info.

#2101



#V410

#2136 **Oil Filter Socket**

Used for R & R of oil filter housing caps on M52, M54, M60, M62, M70 and M73 engines and Mini Cooper S [2002-2006].

36mm - 6 Flats

• 3/8" Drive





#2124 Oil Filter Socket

#M0219

Used for R & R of the oil filter housing cap of N62/ N62TU engines [2002-2010].



#M0284

#MSP1412

Magnetic Spark Plug Socket



Used to remove spark plugs on BMW engines N20, N26, N54, N55 and N63 [2007-2018] and turbocharged Mini Cooper engines [2007-2015].

- 14mm 12 Point
- 3/8" Drive
- · Strong internal magnet holds spark plug firmly



#SP1412 **Spark Plug Socket**



Used to remove spark plugs on BMW engines N20, N26, N54, N55 and N63 [2007-2018] and turbocharged Mini Cooper engines [2007-2015].

- 14mm 12 Point
- 3/8" Drive
- · Rubber boot to hold spark plug



#H2223LGT-30

Torx Socket Insert



- T-30
- 70mm Length



#6500TL-80 **Torx Socket**

NEW!

Used on BMW for R & R of driver's side wiper arm on E31, E38 and E39 chassis. Also fits Lamborghini wheel lug bolts on Gallardo models.


- T-80 Tamper-proof
- 1/2" Drive
- 100mm Length



#201-7

5-Piece Metric Stud Puller Set

5-Piece metric stud remover set. Ideal for BMW manifold studs. Includes 6mm, 7mm, 8mm, 10mm and 12mm stud remover tools.






#BMW377 Allen Socket

Used for easy removal of the rear brake caliper slide bolts on BMW E36, E46, E39 and E31 models.

- 7mm
- 3/8" Drive
- 32mm Length

7mm Stud Remover and Installer

7mm Stud remover and installer. Ideal for BMW manifold studs.





#BMW4053-1

PDC Drill Bit

NEW!

Used for drilling starting holes for the #BMW4053-2



#BMW4053-2

PDC Punching Tool

NEW!

Used for cutting holes for the Parking Distance Control sensors into BMW replacement bumpers.

COMPARABLE: #83302334055







#BMW11845

Torx Socket

Used for BMW VANOS housing bolts.

- T-45 Tamper-proof
- 3/8" Drive
- 100mm Length



#BMW432

VANOS Solenoid Socket

Used for removing and installing the VANOS solenoid valves on M52TU, M54 & M62TU engines [1999–2005].

- 32mm 6 point
- 1/2" Drive

COMPARABLE: #116420.



#MC560

Rear Caliper Brake Piston Tool





Used with a universal 3/8" brake caliper piston tool. Used on all Mini Cooper models [2007–2013] (except Countryman). For [2002–2006] Mini Cooper, see #V450.

• 3/8" Drive

COMPARABLE: #346309

#BFLT60

Flywheel Socket Tool



For R & R of flywheel bolts. Applicable to E34 and E39 V8 4.0L, 4.4L and 5.0L with standard transmission.

- T-60
- 1/2" Drive
- 140mm Length

COMPARABLE: #114180

#100-30A

12-Point Deep Socket

Used for R & R of transmission drive shaft flange nut and pinion shaft flange nut of differential. Applicable to many BMW models including E90 325 (RWD) 30mm axle nuts.

- 30mm
- 1/2" Drive
- 85mm Length
- Thin-walled



#V450

Brake Caliper Piston Adapter





Used for turning in the rear brake caliper piston on Mini Cooper [2002–2006].

• 3/8" Drive

COMPARABLE: #346301.


#MC240 Window Wrench





Hook wrench used for adjusting the door window glass to fit BMW and Mini [2002–2013].

COMPARABLE: #513240



#BMW10160

Extra Long 10mm Socket





Used for R and R of the ground connector screw for the injector on BMW N54 engines.

- 1/4" Drive
- 160mm Length

#MC1400-1

Mini Flywheel Locking Pin

Used for locating the crankshaft in T.D.C. position. Included in #MC1216SET, #MC1400 and #MC1800 timing set. Applicable to Mini [2007–2015].





#ATF105 ATF Adapter

Used on Mini Cooper with "AISIN" transmission in conjunction with the #ATFBASIC. (This will not thread into the CVT Transmission.)

• M10 x 1.0 Threads



#ATFSU100 **Universal ATF Attachment** Used on Mini Cooper CVT models with restricted access to transmission fill tube. Used in conjunction with the #ATFBASIC.

#MCB4648 Engine Timing Set

NEW!





Used for setting engine timing for BMW and Mini new B38, B46 and B48 engines. Applicable to BMW models [2016-2018] and Mini Cooper models [2014-2018].

COMPARABLE: #116480, #118580, #119340, #2358122, #2288380, #2360895, AND #2365488.





#MC1216SET Camshaft **Alignment Tool**



Used to set timing on N12 and N16 (non-turbo) engines in Mini Cooper [2007-2013], Clubman [2008-2014], Convertible [2009-2015], Countryman [2011-2016], Paceman [2014-2016], Roadster [2013-2015], Coupe [2012-2015] and Coupe JCW [2012-2012].

COMPARABLE: #119540, #119340 AND #119590

#MC1800 **Engine Timing Set**



Used to set timing on Mini Cooper N18 turbo charged engines in Cooper JCW [2013-2013], Cooper JCW Clubman [2013-2014], Cooper JCW Convertible [2013-2015], Cooper JCW Countryman [2013-2016], Cooper JCW Paceman [2014-2016], Cooper JCW Roadster [2013-2015], Cooper S [2011-2013], Cooper S Clubman [2011-2014], Cooper S Convertible [2011-2015], Cooper S Countryman [2011-2016], Cooper S Countryman ALL4 [2013-2016], Cooper S Paceman [2014-2016], Cooper S Paceman ALL4 [2014-2016], Cooper S Roadster [2013-2015], Coupe JCW [2013-2015] and Coupe S [2012-2015].

COMPARABLE: #117440, #119340 AND #119590





#MC1400

Engine Timing Set

Used to set the timing on N14 turbocharged engines in Mini Cooper JCW [2009-2012], Cooper JCW Clubman [2009-2012], Cooper JCW Convertible [2009-2012], Cooper S [2007-2010], Cooper S Clubman [2008-2010] and Cooper S Convertible [2009-2010].

COMPARABLE: #119550 AND #119590





#MC9570

Intermediate Lever Tools



Used for removing and installing the

#TM1215

Ball Joint Hammer Nut

NEW!


Used for breaking free steering knuckle/ suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts.

- M12 x 1.5 Threads
- 22mm 7/8" Hex



AND M16X1.5. Ball Joint/Tie Bod

NOTE: FOR THE COMPLETE 4PC. SET, PURCHASE THE #TM20194 CONTAINING M12X1.25, M12X1.5, M14X1.5



#TM1415

Ball Joint Hammer Nut

NEW!

Used for breaking free steering knuckle/suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts.

- M14 x 1.5 Threads
- 22mm 7/8" Hex





#2127

Oil Filter Socket

Used to remove oil filters on BMW 535d [2014-2015], 740Ld xDrive [2015-2015], X5 35d xDrive [2014-2015] and Mini Cooper models [2007-2015].

- 27mm 6 Flats
- 3/8" Drive





Serpentine belt wrenches for Mini models equipped with N12, N14, N16 and N18 engines. Each set comes with one large and one small 12-point wrench. If needed, you can use 1/2" drive ratchet to help with indexing the wrench onto the tensioner and for compressing the tensioner back.

COMPARABLE: #116210

Only sold as a pair

California Residents: Proposition 65 WARNING. See page 125 for info.

#MC100

Serpentine Belt Tool

Serpentine belt tool used for relieving tension on belt tensioner on [2002-2006] Mini Cooper "S" Supercharger equipped models.









Used on Jaguar / Land Rover models with the 3.0L & 5.0L engines in Jaguar F-Type [2014-2016], XE [2016-2016], XF [2010-2016], XJ [2010-2016], XK [2010-2015]; Land Rover LR4 [2010-2016], Range Rover [2010-2016] and Range Rover Sport [2010-2016].

COMPARABLE: #303-1447, #303-1452, #303-1445, #303-1482, #303-1448 AND #JLR-303-1303.

#JLR20T

Timing Tools





#V3032 **Engine Timing Set**

Used for setting timing of Land Rover LR2 [2008-2012].

COMPARABLE: #9997257, #9997261, #9997263, #9997264, #9997271 AND #9997272.



#F20T


Engine Timing Set

Set includes the T.D.C. crank timing pin, cam locking plate and the crank position sensor (CPS) alignment block for Land Rover Evoque and Jaguar XF RWD [2013-2017].

. Must be used in conjunction with #JLR20T.









#JLR5037

Crankshaft **Holding Tool**

Used on Jaguar / Land Rover models with the 3.0L & 5.0L engines [2010-2017].

· Must be used in conjunction with #JLR5038.

COMPARABLE: #303-1437



#JLR5038

Crankshaft **Bolt Socket**

Used on Jaguar / Land Rover models with the 3.0L & 5.0L engines [2010-2017].

- · Must be used in conjunction with #JLR 5037
- 24mm 6 point
- 3/4" Drive

COMPARABLE: #303-1438



Oil Filter Wrench

#JA19015




Applicable to Jaguar XF [2010-2017], XFR [2010-2016], XJ[2010-2017], XJL [2010-2016], XK [2010-2016], XKR [2010-2016]; Land Rover LR4 [2010-2017], Range Rover [2010-2017], Range Rover Sport [2010-2017] and Range Rover Velar [2018] with the 3.0L v6 and 5.0L v8 engines [2010-2017].


- 90mm 15 Flats
- 3/8" Drive

#M0219

Oil Filter Wrench



- 74mm 14 Flats
- · Used with 22mm socket







Used on Jaguar 2.0L

Diesel [2017-2018];

Land Rover Evoque

• 65mm - 14 Flats

[2018] and Range Rover

#JAS6514

Oil Filter Wrench

• 3/8" Drive

Velar [2018].

#2132

Oil Filter Socket

Used on Land Rover Range Rover 3.0L Diesel engine [2016-2017].

- 32mm 6 Flats
- 3/8" Drive



#OFFM2012

Engine Oil Funnel



Attaches directly to the engine oil filler neck or valve cover. Used on Jaguar XF [2013-2017] and Land Rover Evoque [2012-2017] and LR2 [2013-2015]. Made of durable ABS.

• DO NOT USE BRAKE CLEAN

California Residents: Proposition 65 WARNING. See page 125 for info.

#OFGMRD08 Engine Oil Funnel





Used on Jaguar S Type, X-Type [2000-2008], F-Type, XF, XFR, XJ, XJR, XK, XKR [2010-2017]; Land Rover LR4, Range **Rover and Range Rover**



California Residents: Proposition 65 WARNING. See page 125 for info.


#OFHON1033 **Engine Oil Funnel**






with the 4.2L V8 engine [2002-2009]. DO NOT USE

- Made of durable ABS plastic
- Attaches directly to the engine oil filler neck or valve cover











#BMW345

Tank Adapter

Used to pressurize coolant reservoirs in **Land Rover Discovery** [1999-2004] and Range Rover [1995-2004].

• M51 x 4 threads



#FZ36

Cap Adapter



Used to test coolant tank cap. Applicable to Jaguar F-Type, S-Type, X-Type, XF, XJ, XK [2003-2017]; Land Rover Discovery Sport, Range Rover, Freelander, LR3, Range Rover Sport [2005-2017].

• M52 x 2.5 threads



#FZ25

Tank Adapter

Applicable to Land Rover Freelander [2002-2004].

• M47 x 3 threads



#V450

Brake Caliper Piston Adapter

Used for turning in the rear brake caliper piston on Jaguar S-Type.

• 3/8" Drive



#FZ32A

Tank Adapter

Applicable to Jaguar F-Type, S-Type, X-Type, XF, XJ, XK [2003–2017]; Land Rover Discovery Sport, Range Rover, Freelander, LR3, Range Rover Sport [2005-2017].


• M52 x 2.5 threads



#JLR9899

Fuel Injector Seal Tools





• Use #JLR0197 to remove the injectors

COMPARABLE: #310-198 AND #310-199



#FZ47 **Tank Adapter**



Applicable to Land Rover Evoque [2012-2017] and LR2 [2007-2015].

M49 x 2.5 threads



#JLR0197

Fuel Injector Puller

Used to remove the fuel injectors on Jaguar and Land Rover models with the 3.0L v6 and 5.0L v8 engines. [2010-2017].

• Must be used in conjunction with #JLR9899 if replacing the seals.

COMPARABLE: #310-0197

California Residents: Proposition 65



#M7226

Transmission Dipstick



Used in Jaguar models with W5A580, Jaguar XKR [2000-2002].

COMPARABLE: #307-379



#100-30A

12-Point **Deep Socket**

Used for R and R of transmission drive shaft flange nut and pinion shaft flange nut of differential on Mercedes models.

- 30mm
- 1/2" Drive
- 85mm Length
- Thin-walled



#M8160 Long 8mm Socket





Used for R&R of rear tail light assembly on Mercedes [2017-2018].

- 1/4" Drive
- 160mm Length

#M17XLWS **Lug Nut Socket**

Used to R &R the "Flower Shaped" lug nut on Maybach and Mercedes 221 S-class and late model CL-class.

- 1/2" Drive
- 86mm length

FITS LUG BOLT #000 990 5407



#M0E24

E24 Impact Socket

Used on front axle nut on Mercedes C 230, C 300, C 350 [2008-2009], C 250, C 300, C 350 [2010-2011], C 300, C 350 [2012-2014], C 350 [2015], E 350, E 550 [2010-2014], E 350 [2015-2016] and S 550 [2007-2013].

- 1/2" Drive
- 78mm Length

#BMW10160

Long 10mm Socket





Used to remove Mercedes rear bumper securing nuts.

- 1/4" Drive
- 160mm Length

#M17WLS

Lug Nut Socket

Used to R & R the "Flower Shaped" lug bolt on Maybach and Mercedes 221 S-class and late model CL class.

- 1/2" Drive
- 50mm Length

FITS LUG BOLT #000 990 5407.



#ALT34018

Alternator **Pulley Socket**

Used for R and R of the free-wheel pulley on the alternator on newer Bosch Alternators.

COMPARABLE: #602589001000





#M2039

Shock **Crown Socket**

Used for the R and R of shock absorber nut on Mercedes C-Class & CLK [2001-2009].

COMPARABLE:



#H2223LGT-30

Torx Bit





Used for the R & R of the airbag from the steering wheel on various Mercedes models [1998-2002].

- T-30
- 70mm Length

#6500TPT-100

Torx Socket

Used to remove and replace the camshaft adjuster central valve on Mercedes 274, 276, 270, 278 and 271 engines [2012-2016].

- T-100 Tamper-proof
- 1/2" Drive
- 95mm Length

COMPARABLE: #271589001000



#6500T-100

Torx Socket

Used to remove the plug for accessing the parking pawl detent on the 722.9 Mercedes transmissions.

- T-100
- 3/4" Drive
- 60mm Length



#6300T-50

Torx Socket

Used on Mercedes alternator pulley bolts.

- T-50
- 3/8" Drive
- 73mm Length



#M820

Glow Plug Socket

Applicable to glow plugs on Mercedes and Sprinter.

- 8mm
- 3/8" Drive





7-Piece Oil Filter

applications.

Wrench Socket Set

Includes oil filter wrench sockets

This set covers all Mercedes applications by using 2127, 2136, M0219 and M0284.

for many domestic and foreign

#2127 Oil Filter Socket

Used on Mercedes C 300 [2015].

- 27mm 6 Flats
- 3/8" Drive



#2136

Oil Filter Socket

Used on Mercedes diesel engines OM604, OM605 and OM606.

- 36mm 6 Flats
- 3/8" Drive

#M0284



#M0219

Oil Filter Wrench

#M0219




Used for Mercedes engines M113, M276, M285, M120, M104, M155, M112, M273, M275, M119, M137, M111, M272 and Sprinter (gas engine) [1998-2015].

- 74mm 14 Flats
- Used with 22mm socket

COMPARABLE: #103589020900

#V410

#2175



California Residents: Proposition 65 WARNING. See page 125 for info.



Oil Filter Wrench

Used for Mercedes vehicles equipped with 3.0L V6 CRD (Common Rail Diesel)

• 84mm - 14 Flats

#2175

Oil Filter

Wrench


Used with 22mm socket





Used to remove oil filter on Mercedes C 350, C 400, E 250, GLK 250, ML 250 [2014-2016], Sprinter 2.7L [2003-2006] and Sprinter 2.1L [2014–2016].

- 74.5mm 14 Flats
- Use with 22mm socket





#MB4517

Injection Line Wrench



Used on Mercedes Diesel fuel injection lines.

3/8" Drive

#M1620

Motor Mount Wrench



Used to loosen bolt on the motor mount Mercedes 272 and 273 engines [2002-2008].

• 3/8" Drive

#H2760

Oil Drain & Plug Wrench



Used for the R and R of the differential oil filler plug on many Mercedes-Benz models.

#MVW2050F

Fuel Line Pliers



Mercedes ML 320 and ML 430 [1998-2005] fuel filters.

MERCEDES

#TM1215


Ball Joint Hammer Nut

NEW!

Used for breaking free steering knuckle/suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts.

- M12 x 1.5 Threads
- 22mm 7/8" Hex






NOTE: FOR THE COMPLETE 4PC. SET, PURCHASE THE #TM20194 CONTAINING M12X1.25, M12X1.5, M14X1.5 AND M16X1.5.



an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts.

- M14 x 1.5 Threads
- 22mm 7/8" Hex





#FZ32A **Tank Adapter**





For pressurizing cooling system on Mercedes ML 320 and ML 430 [1998-2005].

• M52 x 2.5 Threads


#MB164251


Fuel Pump Wrench

Used for R & R of the fuel pump on Mercedes 164 and 251 chassis [2006-2014].

• 1/2" Drive

COMPARABLE: #164589010700







#FZ55

Tank Adapter



Cooling system pressure tester adapter. Applicable: Dodge / Freigtliner / Mercedes Sprinter vans [2007-2019].

M46 x 2.5 Threads



#FZ36

Cap Adapter





Used to test coolant tank cap on Mercedes ML 320 and ML 430 [1998-2005].

• M52 x 2.5 Threads

#M034919

Tank Adapter



Used for pressurizing the cooling system on various Mercedes models [1996 - 2019].

- M62 x 4 Threads
- For ML models [1998-2005], see #FZ32A.



#FUN14EURO

FUN14KIT Euro Adapter



Used in conjunction with #FUN14KIT. It attaches directly to the valve cover, so when you're adding oil to the engine you don't have to worry about making a big mess due to the internal baffle of the valve cover of Mercedes engines [1993-2016].

. May not fit applications where cowl causes interference.





#OFAUD1000 Euro 1/4 Turn Oil Funnel



Attaches directly to the valve cover, so when you're adding oil to the engine you don't have to worry about making a big mess due to the internal baffle of the valve cover of Mercedes engines [1993-2016].

• May not fit applications where cowl causes interference.










Used for checking engine oil level on Mercedes models with 112,113, 137 and 271 engines that do not have an engine dipstick.



#M7226

Transmission Dipstick



#M21250

Transmission Dipstick



MERCEDES

#ATFMB

Driveline Filler

Used for filling transmission fluid in Mercedes 722.9 automatic [2004-2018].

- For 724 transmission, see #M21250.
- For 725 transmission, see #ATFMB725.

NOT SUITABLE FOR USE WITH FUELS OR SOLVENTS.



#ATF129 **ATF Filling Adapter**





Used for filling transmission fluid in Mercedes 722.9 automatic [2003-2018].

• For 725 Transmissions, see #ATFMB725

#S3054X-10

Head Bolt Socket

Used for R and R of cylinder head bolts. Applicable to Mercedes OM 601, OM 602 and OM 603 engines.

- 10mm
- 1/2" Drive
- 140mm Length

COMPARABLE: #601589001000



#S3054X-12 **Head Bolt** Socket

Applicable to Mercedes head bolts on OM 6 15, 616, 617, M 102 and M 103 engines.

- 12mm
- 1/2" Drive
- 140mm Length

COMPARABLE: #617589001000



#ATFMB725

Transmission Filling Adapter Set

NEW!

Used for filling the Mercedes 725 transmissions [2014-2019]. Used in conjunction with #ATF129 adapter and one of our ATF Filling Units.



#M0333

Instrument Cluster Puller

Used for R and R of the instrument cluster on Mercedes 107, 116, 123, 124, 126, 129, 140, 168, 170, 201, 202, 208, 210 and 463 chassis.

COMPARABLE: #110589005900



#M27161

Camshaft Alignment Fixture

Camshaft alignment fixture for Mercedes C 230 [2003-2005], C 250 [2012 - 2015] and SLK 250

COMPARABLE: #271589006100



#3206

Door, Trim and **Molding Tool Set**

Set includes a T-25 long Torx screwdriver Shank Length 10 inches for accessing door handles on various Mercedes models. One trim spoon and one light duty hook is included for various interior jobs. Includes one pair of trim and cluster hooks. Three soft wedges are also included for various trim and molding jobs both for interior and exterior applications. Includes carrying pouch.







#OFAUD1000

Euro 1/4 Turn Oil Funnel

Specifically designed to attach to the valve covers. When adding oil to the engine you don't have to worry about making a mess due to the internal baffle of the valve cover. Applicable: Volvo 2.5L engines.



#CVB15 CV Clamp Crimping Tool

Used to crimp on clamps for CV boots on all Volvo models with crimp style CV boots. Instead of squeezing together, drive the #CVB15 with your 3/8" drive ratchet to crimp these clamps.





CAMSHAFT AND CRANKSHAFT TIMING FIXTURES MADE IN USA

Used for the alignment of the camshafts and crankshafts on all in-line (4, 5 and 6-cyl.) twin cam motors through 2011, except the 3.0L and 3.2L. May also be used to align the camshafts with the cam cover.

COMPARABLE: #9995451, #9995452, #9995453 AND #9995454.

#MSP1412

Magnetic Spark Plug Socket



Applicable to Volvo models S60 [2016-2018], S60 Inscription [2016-2018], S60 Cross Country [2017-2018], S60 Polestar [2017-2018], S60 R Design [2017-2018], S80 [2016], S90[2017-2018], V60 [2016-2018], V60 Cross Country [2017-2018], V60 Polestar [2017-2018], V60 R Design [2017], V90 [2017-2018], V90 Cross Country [2017-2018], XC60 [2016-2018], XC60 R Design [2016-2018], XC70 [2016] and XC90 [2016-2018].



#SP1412

Spark Plug Socket



Applicable to Volvo models S60 [2016-2018], S60 Inscription [2016-2018], S60 Cross Country [2017-2018], S60 Polestar [2017-2018]. S60 R Design [2017-2018], S80 [2016], S90 [2017-2018], V60 [2016-2018], V60 Cross Country [2017-2018], V60 Polestar [2017-2018], V60 R Design [2017], V90 [2017-2018], V90 Cross Country [2017-2018], XC60 [2016-2018], XC60 R Design [2016-2018], XC70 [2016] and XC90 [2016-2018].

- 14mm 12 Point
- 3/8" Drive
- Rubber boot to hold spark plug








Used to set timing on 3.0L /3.2L engines in Volvo S60 [2011-2013], S60 R [2012-2013], S80 [2007-2013], V70 [2008-2010], XC60 [2010-2013], XC60 R [2012-2012], XC70 [2008-2013], XC90 [2007-2013], XC90 R [2012-2013]. Crankshaft alignment disc made in USA.

COMPARABLE: #9997257, #9997261, #9997263, #9997264, #9997271 AND #9997272.





#VB414

Oil Filter Wrench



Fits Volvo 2.0L turbo models. Applicable: Volvo S60. S80, V60, XC60 and XC70 [2015-2019].

- 16 Flats
- · Use with 22mm socket





Applicable: [2007-2014] Volvo models with 36mm hex molded into the oil cap.

Oil Filter Socket

• 36mm - 6 Flats

#ALT34018

Used for R & R of the free-wheel

pulley on the alternator. Used

in conj. with #S 3054 X-10 or

#6300 T-50 sockets. Applicable:

Volvo C70, S40, S60, S70, S80,

V50, V60, V70, V70 XC, XC60,

COMPARABLE: #9995760

Alternator **Pulley Socket**

• 3/8" Drive

#2136



NEW!

Tank Adapter





For pressurizing cooling system. Applications: Volvo trucks with M48 x 3 threads on filler neck. Applicable to [2005] Volvo V670 and VN430.

• M48 x 3 Threads

#FZ25

Tank Adapter








#V410

Oil Filter Wrench

Used for all Volvo models [1999-2006] (except 2005 40 & 50 Series).


- 86.5mm 16 Flats
- · Use with 22mm socket

COMPARABLE: #9995679






ATF Adapter





#ATF108V



XC70, XC90.

• 5/16-24 Threads



#EU2090

Allen Socket

Brake caliper socket Applicable to Volvo front caliper slide bolts [2010-2015].

- 9mm
- 3/8" Drive
- 52mm Length



#V450

Brake Caliper Piston Adapter



• 3/8" Drive



#FZ47

Tank Adapter

• M47 x 3 Threads

For pressurizing cooling system. Applicable:

secondary filler neck (except S40 and V50).

neck and Volvo trucks with M47 x 3 threads on

[1978-2007] Volvo passenger vehicles with threaded



Used for pressurizing the coolant system on Volvo \$40 [2004.5-2010], S60 [2010-2018], S80 [2008-2016], S90 [2018], V50 [2005-2012], V60 [2015-2018], XC60 [2010-2018], XC70 [2008-2016] and XC90 [2016-2018].

M49 x 2.5 threads





Applicable: Volvo V70 [2000-newer], S80, XC90, S60, V70 XC (2001-newer) / XC70. Used on the following engines: B5204T5, B5234T3, B5244S, B5244S6, B5244SG, B5244SG2, B5244T3, B5244T5, B5254T2, B5254T4, B5254T9, B6284T, B6294S, B6294S2, B6294T, B6304S3, B6324S, B6324S5, B8444S, D5244T, D5244T18, D5244T4 and D5244T5.

• 1/2" Drive

COMPARABLE: #9995720





Fuel Tank Locking Ring Tool



#T10389

Assembly Tool

For removal and installation of the lock cylinder housing on doors with no lock cylinder. Applicable: VW Tiguan [2009-2016]. Included in #3206 set.

#3035

3.5mm Socket

Used for R & R of the Proximity (Radar)Sensors and any place a 3.5mm socket is needed.


- 1/4" Drive
- 25mm Length





#VW93005

Connector Release Tool



#T10518A

Grab Handle Release Tool

Used to remove the roof grab handle of the Golf [2013-2017] and Tiguan [2016-2017] without causing damage.



Radio Removal Keys



For removing the factory-installed radio. Applicable: new body style VW Passat [1999–2005] and Jetta and Golf [1999-2005] with vertically aligned key slots.

#3344A

Radio Removal Tool





For radio removal on Audi A4, A6, A8 and VW new Beetle models with horizontally aligned key slots. Two pair required in most cases.

#VW20T

Engine Timing Set

For VW/Audi models with 2.0L (turbo) [2009–2017] . COMPARABLE: #T10352, #T10352-1, #T10355, #T10368, #T40011, #T40196, #T40267 AND #T40271.

• Sometimes requires the use of additional tool #T 40243





#T4306

Engine Timing Set







TDI Injector Pump Locking Pin



Used on VW TDI engines [1999–2014] . Locks cam on 1.9L (BEW and BRM). Also used on newer VW 2.0L turbo diesel (CBEA, CKRA and CJAA).

For 2009-Newer, two #3359 pins are required.



#6814TDI

TDI Timing Belt Tools

Used on VW TDI engines [1999–2014]. Locks cam on 1.9L (BEW and BRM). Also used on newer VW 2.0L turbo diesel (CBEA, CKRA and CJAA).

• Set includes 2 of the #3359.





#3428









For locking the camshaft on VW TDI without removing the valve cover [1999–2003] . Replaces the old style #3418. Used in conjunction with #3359.


COMPARABLE: #T10098A

#T40079

Timing Chain Adjuster

Used to tension the Timing Chain via the Camshaft Adjuster on 3.0L V6 Supercharged (CGXB & CTUA) and 4.2L V8 4v (BAR, BNS, BVJ, CAUA) engines in Audi A7 [2012-2015], A8/A8L [2007-2009], Q7 [2007-2009], RS4 [2007-2008] and S5 [2008-2009].

• Use with 24mm or 15/16" socket





#3366

Bracket for Chain Adjuster

For removing and installing the timing chain adjuster. Applicable: VW/Audi 4-cyl., 6-cyl. and 8-cyl. (5v) engines.



#T40243

Chain Tensioner Lever



Used for slackening the Chain Tensioner when detaching the Timing Chain from the Camshaft. Applicable to 2.0L 4-Cylinder turbo TFSI (CAEB) engine.

• Used in conjunction with #VW20T.

#T40267 **Locking Clips**



Locking clips for chain tensioner. Applicable to 2.0L 4-cyl. (4v) turbo TFSI (CAEB) engine (Generation III).



#VW87-2

Timing Belt Spanner Wrench



#VW87-1

Timing Belt Spanner Wrench



#H2587

Spanner Wrench



For adjusting the tension of the timing belt. Applicable: [through 1998] 4-cyl. VW Golf and Jetta, [through 1997] 4-cyl. VW Passat, Corrado, 1.9 liter TDI models; and Audi 4-cyl. diesel models.



#T40011

3-Piece Locking Pin Set

Used to lock the timing belt tensioner while relieving pressure from the belt. Applicable: VW/Audi 3.0L V6 (5v), some 1.8L 4-cyl. (5v) turbo and 4.2L V8 (5v) with timing belt.



#3242

Crankshaft Locking Pin

Used to lock the crankshaft at TDC position in the VW/Audi engines: 2.7L V6 (APB), 2.8L V6 (except VR6) (AAH, AFC), 2.8L (AHA, ATQ), 4.0L W8 (BDP), 4.2L V8 (BAR, BNS, BVJ, BYH, CAUA), 4.2L V8 (AKB, AUX, AYS, AXQ, BAS, BFM, BGK, BHF, BNK), 5.2L V10 (BSM, BXA) and 6.0L W12 (BAP, BHT, BRP, BSB).



#T40069

Crankshaft Locking Pin

Locking pin to lock crankshaft at TDC in VW/ Audi engines 2.5L (BGP, BGQ, BPR, BPS, CBTA and CBUA), 3.0L Supercharged (CGXB, CTUA, CJWB, CJWC, CJWE, CTWA and CTWB) and 3.2L (BKH and CALA). Applicable: Audi A4 [2005–2009], A5 [2008–2009], A6 [2009–2013], A7 [2012-2015], Q7 [2011-2015]; W Jetta [2005–2012] and Rabbit [2006–2009].



#T10115

Tensioner Locking Pins

Used to hold the timing belt tensioner in place while removing and installing the timing belt on VW Golf, Jetta and Beetle with 1.9L TDI Pumpe-Duse (BEW) and 2.0L turbo (BPY) engine [2004–newer].



#T40026

Crankshaft Locking Pin

Used to lock the crankshaft at TDC position when replacing the timing belt on Audi 3.0L [2002-2005]. Used in Conjunction with #T40011, #T40028, #T40030. See #T4306 for complete set.



#T10368

Crankshaft Thrust Piece



Used when removing and installing lower timing chain cover on VW/ Audi 2.0L (4v) turbo with chain (CAEB) in A3 [2008–2009], A4 [2009–2010], EOS [2009], GTI [2008–2009], Jetta, Tiguan [2009–2015] and TT [2009].

#T40009

Tensioner Spanner Wrench

Used when adjusting the toothed belt tensioner eccentric to the proper pretension torque on VW/Audi V8 5v per cylinder.





#3299A

Tensioner Release Tool





Fits VW/Audi 1.8L, 2.0L turbo, 2.0L (BBW), 2.5L and 3.2L. Comes with 3 sets of interchangeable pins. Pins may be threaded in two different locations, based on application access. Overall length 18". 12" spread between pins at tip of arms, when pivot arm is at 90 degrees. Holding pins are made in USA.

COMPARABLE: #T10172

#T10252 **Camshaft**



#T10050

Crankshaft Stop

Used for locking the crankshaft in place during timing belt replacement on VW TDI Pumpe-Duse engines [2004-2014] (BEW, BHW, BRM, CBEA, CJAA and CKRA) equipped with round pulley #038105263F and #045105263A. On the VW Jetta 1.9L BRM engine [2005-2006], it may need the #T10100 crankshaft stop instead if equipped with oval pulley number #038105263H. Also used on newer VW 2.0L TDI (BHW, CBEA and CJAA).





#T10100

Crankshaft Stop

Used to lock the crankshaft in place during timing belt replacement. (*TDC marking at 1 o'clock). Applicable: VW Jetta 1.9L BRM with oval pulley part #038105263H [2005-2007].





#VW10352 **Assembly Tool**



Used for R & R of 4/3 way central valve for camshaft adjustment. Applicable to 2.0L 4-cyl. 4v turbo TFSI (CAEB) engine.

• 3/8" Drive

COMPARABLE: #T10352 AND #T10352-1



#T40028

Camshaft **Adjusting Socket**

Used to adjust variable valve timing on the exhaust side camshaft to basic position. Applicable to 3.0L V6 in A4 [2002-2005] and A6 [2002-2004].

• 3/8" Drive





#T 40028 SHOWN HERE IN USE. RATCHET NOT INCLUDED



Puller used to remove cam sprockets. Applicable: VW 4-cyl. TDI, VW/Audi V6 5v and Audi V8 40v. Also includes both arms for 2.0L turbo direct injection engines (BPY, BPG and BWT). Includes: 18mm, 23mm and 25mm pulling arms.

COMPARABLE: #T40001, #T40001-6 AND #T40001-7



#T40058

Crankshaft Socket

For turning the crankshaft. Applicable: VW/Audi engines 3.2L V6 (BKH and CALA), 4.2L V8 (BAR, BNS, BVJ and CAUA), 4.2L V8 (BNK) and 5.2L V10 (BSM and BXA). Applicable: Audi A4, A6 [2005-2009]; A8, Q7, S6, S8 [2007-2009] and S5 [2008-2009].



#VW5220

Camshaft **Adjuster Socket**

Used for camshaft adjuster bolt on VW/Audi 2.0L turbo (BPG & BPY) engines.

- #10 Polydrive
- 1/2" Drive
- 53mm Length

COMPARABLE: #T40080



#T40001-6 **Puller Claw**

Used to remove camshaft gear/wheel on VW/Audi 2.0L (BPY, BPG and BWT) engines. **Used in conjunction** with #T40001 and #T40001-7. Included with #VW4006 set.



#T40001-7

Puller Claw

Used to remove camshaft gear/wheel on VW/ Audi 2.0L (BPY, BPG and BWT) engines. Used in conjunction with #T40001 and #T40001-6. Included with #VW4006 set.





#T10531

Vibration Damper Assembly Tool

Used to dismantle & assemble the vibration damper on 1.8L and 2.0L 4v TFSI Direct Injection Engines. Applicable to VW/ Audi A4 [2010-2015], A5 [2010-2015], Beetle [2014-2015], CC [2014-2015], EOS [2012-2015], GTI [2014-2015], Passat [2014-2015], Tiguan [2012-2015] and TT [2010-2015].



#T10068A

Camshaft Alignment Fixtures

Used in VW/Audi 2.8L VR6 4v (AXK and BDF), 3.2L VR6 4v (BAA, BJS, BMX, BUB and CBRA), 3.6L VR6 4v (BHK, BHL and BLV) and 6.0L V12 (BAP, BRP and BSB). Applicable to Audi A3 [2006 - 2009], A8 [2005 - 2009], A8 [2005 - 2009], Q7 [2007 - 2009], TT [2004 - 2009]; Porsche Cayenne 3.6L [2008 - 2016]; Volkswagen CC [2009 - 2009], EOS [2007 - 2009], Eurovan [2001 - 2003], Golf [2004 - 2004], GTI [2002 - 2006], Phaeton [2004 - 2006], R32 [2004 - 2008] and Touareg [2004 - 2009].



#3391

Camshaft Alignment Tool



Used to align both camshafts in VW/Audi V6 2.8L and 2.7L 5v engines (APB, AHA, ATQ and BEL) in Audi A4, A4 Avant [1998–2001], A6 [1998–2004], A6 Avant [1999–2001], Allroad Quattro [2001-2005], S4 [2000–2002], S4 Avant [2001–2002]. Used in conjunction with #3242.



#T40196

Drift for Camshaft Slide Pieces

Used to set basic setting of cam slide adjuster on camshaft on 2.0L 4v (CAEB) turbo engines in Audi A4 [2008–2013] and Q5 [2009–2013].



#T10355

Crank Counter Hold Tool



#T40271

Camshaft Clamp

Used to lock camshaft sprockets in TDC position when installing timing chain on 2.0L turbo TFSI (CAEB) engines [2009– newer]. Essential for Generation III, very helpful for Generation I and II.



#ATF103

ATF Adapter



For filling the VW Touareg transmission. Used in conjunction with ATF Filler System. Does not include pump, container, hose, or shut-off valve.

COMPARABLE: #VAG1924/1

#ATF104

ATF Adapter



Long, angled VW/Audi adapter Used in conjunction with ATF Filler System.. Does not include pump, container, hose, or shut-off valve.

COMPARABLE: #VAG1924

#ATF105 **ATF Adapter**



Used on VW/Audi transmissions. Used in conjunction with ATF Filler System.

• M10 x 1.0 Thread

COMPARABLE: #VAS6262/2

#ATF16DSG

"DSG" ATF Adapter

VW/Audi DSG driveline adapter used with the ATF Filler System.

M24 x 1.5 Thread



#ATFVW5

5-Piece Driveline Filler

Used for filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Container made of UHDP (ultra high density polyethylene). Individual manufacturer sets are available as well as the individual adapters. Newly designed drum features a second port for filling or dumping fluids without having to remove the pump-saving both time and clean up afterwards. Applicable to Audi, Porsche and Volkswagen models [1999-2018]



#ATF17CVT

"CVT" ATF Adapter

VW/Audi CVT driveline adapter used with the ATF Filler System.

• M22 x 1.5 Thread

COMPARABLE: #VAS5162



TO SEE OUR COMPLETE LINE OF DRIVELINE FILLERS AND ADAPTERS. **SEE PAGES 84-87.**





#VW133SI

Injector/Chamber Tool Set





Used to remove and install high pressure injectors and combustion chamber seal in WW/Audi models with 1.8L, 2.0L turbo, 3.2L V6 4v and 4.2L V8 4v. Applicable to Audi A3 [2006–2016], A4 [2005– 2015], A5 [2008– 2015], A6 [2005– 2015], A7 [2012-2015], A8 [2007– 2015], Q5 [2010-2017], Q7 [2007– 2015], R84 [2007–2008], S4 [2005–2015], S5 [2008–2015], S6 [2007–2015], S8 [2007–2015], GV [2008–2015], WB Beetle [2012-2015], CC [2009-2015], EOS [2007–2016], Golf [2006–2016], GTI [2006–2017], Jetta [2005–2016], Passat [2008-2015], Tiguan [2009-2015] and Touareg [2007–2015].

COMPARABLE: #T10133



SHOWN HERE WITH HERE CODES FUEL LINE SHOWN HERE WITH AUDI FUEL FILTER #MVW2O5OF Fuel Line Pliers Used for fuel lines with plastic snap-together connectors found on VW Golf [1999–2005].

For R & R of the fuel pump on various VW/Audi models: Audi A4 [2002–2004], A6 [1999–2004]. California Residents: Proposition 65 WARNING. See page 125 for info.

#3217

Fuel Sender Spanner

Used to remove and install the fuel gauge sending unit. Applicable to Porsche Boxster (986) [1997–2004] and 911 Carrera, Turbo, GT2 and GT3 (996) [1999–2005]; VW Passat (FWD) [1998–2005].

- 1/2" Drive
- 139mm

California Residents: Proposition 65 WARNING. See page 125 for info.





Cooling System Adapter

For pressurizing cooling system. Applicable to Porsche Cayman [2005-2013] and Boxster [2007-2012].






A/C Coupler Release Tools



Used to disconnect the A/C coupler on Audi A4, A5 and Q5 [2007-Newer].





#TA18

Adapter

For brake master cyl. or clutch master cyl. reservoirs. Used in conj. with pressure bleeder. (1/4-18 NPT). Fits most European cars.

- M46 x 3.5 Threads
- 1/4-18 NPT Air fitting not included



For pressurizing cooling system. Fits VW/Audi [1978-1993] models with male threads on filler neck of expansion tank. Applicable: Audi A8 and S8.

• M48 X 3 Threads





#FZ41

Tank Adapter



For pressurizing cooling system on VW/Audi models (except older A8 and S8) [1999-2018]; Porsche 911 (991 body) [2012-2015] and Cayenne [2004-2013].

• M63 X 3 Threads






#OFVW2013

Oil Funnel

VW/Audi engine oil funnel for 1.8L, 2.0L Turbo and 2.0L diesel engines. Applicable to Audi A3 TDI [2015-Newer], Q3, S3 [2016-Newer]; VW Beetle, Convertible, EOS, Golf, Jetta, Jetta Sportwagon, **Passat and Tiguan** [2014-2018].






#T40057

Oil Filter Housing Drain

For draining the oil filter housing on VW/ Audi with 2.0L turbo (BPG, BPY & BWT) [2006-2008] and 2.5L inline 5- cyl. engine [2005-2014]. Prevents spillage during oil filter change and allows for drainage of oil from the filter housing.





#VW10549

Drain Plug Tool



Used to remove and install the oil drain plug on VW/ Audi with 1.8L and 2.0L Turbo engines [2015-2019]. Applicable engines: CPKA, CPRA, CPPA, CBFA, CCTA, CBEA, CNTA, CXCA, CXBB, CXBA, CPKA, CNSB and CNSA.



#OFAUD1000

Euro 1/4 turn Oil Funnel



No more mess, attaches directly to the valve cover and seals just like the factory cap. Fits VW/Audi 1.4L turbo, 1.8L turbo, 1.9L TDI, 2.0L turbo, 2.8L 5v, 3.0L 5v, 3.2L, 3.6L and 4.2L 5v and Tiguan 2.0L [2016]. For newer TDI and 2.0 turbo engine [2014-2018], see funnel #0FVW2013.






#AU40178





Applicable to Audi A4 [2009-2017], A5 [2009-2015], A6 [2009-2015], A8 [2011-2014], Q5 [2013-2015], RS5 [2013-2015], S4 [2010-2015], S5 [2009-2012], S6 [2013-2015], S7 [2013-2015]; Porsche Cayenne S Hybrid [2011-2014], Panamera S Hybrid [2012-2014]; Volkswagen Touareg [2011-2014]. COMPARABLE: #T40178





#FUN14EURO FUN14KIT

Euro Adapter

For use with our #FUN14KIT. Specifically designed to attach to the valve covers. When you're adding oil to the engine you don't have to worry about making a big mess due to the internal baffle of the valve cover. *May not fit applications where cowl causes interference. Fits VW/Audi 1.4L turbo, 1.8L turbo, 1.9L TDI, 2.0 turbo, 2.8L (30v), 3.0L (30v), 3.2L, 3.6L and 4.2L (40v).





#M0219 Oil Filter Wrench



Applicable to Audi A4 [2009-2016], Q5 [2012-2016] 2.0L Turbo engines; VW CC, EOS, Tiguan [2009-2013], Golf [1999–2005], GTI [2008], Jetta [2005–2013], Jetta 1.4T [2016], Beetle 2.5L [2005–2014]; Porsche 911 [1999– 2008], Boxter [1997-2008] and Caymen [2005-2008].

- 74mm 14 Flats
- Use with 22mm socket





#2175

Oil Filter Wrench



Applicable to Golf, Jetta and Rabbit with 2.5L engines.

- 74.5mm 14 Flats
- Use with 22mm socket

California Residents: Proposition 65 WARNING. See page 125 for info.



#2132

Oil Filter Socket

Applicable to Audi Q3 & S3 2.0L Turbo, [2015-2016] and VW Golf and Jetta 2.0L TDI [2011-2016].

- 32mm 6 Flats
- 3/8" Drive
- #23236 Double-sided Socket may be purchased instead, and adds more coverage



#2136 **Oil Filter Socket**

Applicable to Audi Q7 3.6L, A6 3.0 L SC [2014-2016], Q7 3.0L SC [2011-2016]; VW Corrado VR6 [1993], Eurovan VR6 and Golf R32 3.2L VR6 [2004], Jetta 2.0L turbo [2006]; Jetta 2.8L VR6, Passat 2.8L VR6, Touareg Porsche 911, Boxster, Cayenne and Panamera [2009-2016].

- 36mm 6 Flats
- 3/8" Drive
- #23236 Double-sided Socket may be purchased instead, and adds more coverage



32 x 36mm Oil Filter Socket

Double sided 3/8" drive. Applicable to Audi Q3 and S3 2.0L Turbo [2015-2016], A6 3.0L [2014-2016], Q7 3.0L [2011-2016], Q7 3.6L [2007-2010]; Volkswagen TDI [2011-2016], Touareg [2009-2016] and VR6 motors.





#3462 **Head Bolt Socket**



- 155mm Length

COMPARABLE: #3452, #3452A AND #T10070

#ALT34018 Alternator **Pulley Socket**

For R & R of the free-wheel pulley on the alternator. Used in conjunction with #S3054X-10 or the #S1054TXT-50 sockets.

COMPARABLE: #3400



#6355X-14

12-Point Socket

Ideal for use on rear brake caliper bolts on VW Jetta and Passat



#S3054X-10

Head Bolt Socket

Used on VW/Audi head bolts that are 10mm, 12-pt. Most [1998-later] VW/Audi applications require the #3462 head bolt socket.

- 10mm
- 1/2" Drive
- 140mm Length

COMPARABLE: #3410





#T10107B

Long Allen Socket


Fits right hand stub shaft on 6-speed manual, OA5 and O2N. Also applicable to VW 2.5L I5 (4v) intake manifold bolts, Jetta (BGP & BGQ) [2005-2007], Jetta (CBTA & CBUA) [2008-2014], Rabbit (BGP & BGQ) [2006-2007], Rabbit (CBTA & CBUA) [2008-2009], Beetle (BPR & BPS) [2006-2010] and Beetle (CBTA & CBUA) [2012-2014].

- 6mm
- 3/8" Drive
- 325mm Length

COMPARABLE: #T10107A









Spreader



For the R & R of the front shock absorber tube from the wheel bearing housing on Audi A3 [2006–2008], TT [2000–2008] and A5 [2008–2009]; Volkswagen Golf, Beetle [1999–2008], Rabbit, GTI, Passat [2006–2008], Jetta [1999–2006], Tiguan [2008].



• 3/8" Drive

#6300X-12

12mm, 12-Point Socket Bit

For the R & R of axle shaft bolts on newer VW Jetta and rear toe adjustment on Audi A6 [1999–newer]. Used for bell housing bolts with tight clearance on various VW models.



#6300X-14

14mm, 12-Point Socket Bit

For R & R of Audi TT differential bracket and for bell housing bolts with tight clearance on various VW models.



#6300X-16 12-Point Socket

Used for R & R of manual transmission drain plug. Applicable to Audi Q7, Porsche Cayenne and VW Touareg brake caliper bolts.

- 16mm Tamper-proof
- 1/2" Drive
- 60mm Length

COMPARABLE: #3357



#6300

12-point Socket Bit Set



7-Piece set includes sockets:

- #6300XL-14 (long 14mm)
- #6300XL-8 (long 8mm)
- #6300XL-10 (long 10mm)
- #6300X-16 (16mm tamper-proof)
- #6300X-12 (12mm bit)
- #6300X-14 (14mm bit)
- #3424 (Spreader)











#6300XL-8 12-Point

Long Socket

Used for R & R of axle shaft bolts on VW Beetle, Jetta TDI and older VW/ Audi models.

- 8mm
- 3/8" Drive
- 90mm Length



#6300XL-10 12-Point Long Socket

Used for R & R of axle shaft bolts on VW Passat and Golf.

- 10mm
- 3/8" Drive
- 90mm Length



#6300XL-14 12-Point Long Socket

Used for R & R of late model VW Eurovan axle shafts and ball joints. Also used on VW Touareg inner CV bolts.

- 14mm
- 1/2" Drive
- 140mm Length



Axle Nut Set

Axle nut socket set covers all VW/Audi vehicles from [1996-2015] with a 14mm and 17mm allen as well as an 18mm, 24mm, 30mm, and 32mm 12-pt. socket. Applicable: Audi A4 [2002-2009], A4 [1996-2001], A6 [1999–2009]; VW Beetle, Cabrio, Golf, Jetta [1999–2015], Tiguan (4Motion) and Touareg [2009–2015].

• For [2009-newer] Audi A4 rear axle bolts, purchase #H985-19









#6500X-30 12-Point Socket



Used For R & R of front axle nuts. Applicable: [1999-2005] VW Cabrio, Beetle, Golf and Jetta.

- 30mm
- 1/2" Drive
- 45mm Length

#6500X-32 12-Point Socket



Used for R & R of front and rear axle nuts on [2004-2016] VW Touareg.

- 32mm
- 3/4" Drive
- 60mm Length

#6500X-18 12-Point Socket

Used for the R & R of the rear axle bolts on VW Jetta and Golf [2006-2015].

- 18mm
- 1/2" Drive
- 95mm Length

COMPARABLE: #T10162



#6500-14 Allen Socket



Applicable to Audi A4 Quattro front and rear axle bolts [1996-2001] and VW Passat rear axle bolts [1996-2002].

- 14mm
- 1/2" Drive
- 37mm Length

#6500-17 **Allen Socket**



Applicable to Audi A4 (AWD) front & rear axle bolts [2002-2009], Audi A6 front axle bolts [1999-2009] and VW Passat front axle bolts [1998-2005].

- 17mm
- 1/2" Drive
- 38mm Length

#3200X-4



1/4" hex drive bit used for R & R of 4mm door handle screws. Applicable: VW Golf, Jetta, Passat and Beetle.



#6500X-24 12-Point Socket



Used for R & R of front axle bolt. Applicable: VW Golf [2010-2013] and Tiguan [2009-2015].

- 24mm
- 1/2" Drive
- 38mm Length

COMPARABLE: #T10361

#3200T-6 T-6 Torx Bit

Used for the R & R of door hinge fasteners on VW Touareg as well as Porsche Cayenne.



#3200X-8 8mm, 12-Point Bit

Used for R & R of door hinge fasteners on late model VW using 8mm, 12-point bolts.











TOOLS FOR **HEAVY TRUCK**

73-77

CUMMINS /
DETROIT DIESEL /
FREIGHTLINER /
INTERNATIONAL /
MACK / VOLVO

73-77



#CM3021

Cummins ISX 4 Wedge Timing Set




NEW!



Used for setting the geartrain timing on all Cummins ISX engines [2007-2016].

COMPARABLE: #3163021

- Set includes 4°, 6° (x2) and 7° Wedges and crank pin.
- Extra 6° wedge is included for [2007-2012] engines with two camshafts.
- · Comes in custom plastic storage case.





11 all sates

#VTC100

Coolant Drain Hose



Used to drain the radiator on Volvo Heavy Duty Trucks. Applicable to Volvo Heavy Duty Trucks [2004-2018] and Mack Trucks [2007-2018].

COMPARABLE: #9996049





#HTLP100 Universal Heavy Truck Diesel Engine Cylinder Wet Liner Puller



Used to remove the diesel cylinder wet liner from heavy trucks and heavy equipment for Caterpillar, Cummins, Detroit Diesel, Mercedes OM460 and Volvo D13 engines.

• Includes thinner blades for Detroit Diesel

NOTE: SHORTER CYLINDER LINERS MAY REQUIRE ADDITIONAL SPACING BLOCKS UNDER THE VERTICAL SUPPORTS TO INCREASE THE LENGTH OF PULL.

#M0284

Oil Filter Wrench

Applicable to Dodge & Mercedes Sprinter with 3.0L V6 CRD engine [2007-2015].

- 84mm 14 Flats
- · Use with 22mm socket





Oil Filter Socket

Applicable to Mercedes Sprinter with 2.1L Turbo Diesel [2014-2017].

- 74.5mm 14 Flats
- Use with 22mm socket



California Residents: Proposition 65 WARNING. See page 125 for info.

#M1020

Glow Plug Socket

Glow Plug Socket

Applicable to Dodge /

Mercedes and Sprinter.

Applicable to Dodge / Mercedes Sprinter.

- 10mm
- 3/8" Drive

#M820

• 8mm

• 3/8" Drive



#OFAUD1000

Euro 1/4 Turn Oil Filler



Specifically designed to attach to the valve covers. When adding oil to the engine you don't have to worry about making a mess due to the internal baffle of the valve cover. Applicable: Dodge, Freightliner & Mercedes Sprinter Vans [2006-2013] 2.7L and 3.0L V6 CRD.





#ATFBASIC

Basic Driveline Filler

Used for filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Individual manufacturer sets are available as well as the individual adapters. U.S. made container, made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pump-saving both time and clean up afterwards.


- Used only to Fill, Not to Drain-So Clean Fluid Stays Clean
- 8 Liter Capacity
- Quick Attachment Adapters
- Pump Dispenses **Efficiently**
- On/Off Ball Valve
- Hose Length: 4ft 10in





#2017SACP

Swivel Spring Clamp Pliers







Used for various different spring clamp sizes found on fuel lines, radiator hoses, transmission cooler lines, etc. The rotating heads with unique grooves allow for 360° of adjustability for those hard to reach angles and locations.





#FZ55

Tank Adapter



Cooling system pressure tester adapter. Applicable to Dodge / Freightliner / Mercedes Sprinter vans [2007-2019].



#SPR886

Transmission Dipstick

Dodge / Freightliner Sprinter transmission dipstick [2002-2009].

COMPARABLE: #8863B



#6300X-16

12-Point Tamper-Proof Socket

Used for Mercedes diesel truck flywheel bolts. Also available in our #6300 set.

- 16mm Tamper-proof
- 1/2" Drive
- 60mm Length

COMPARABLE: #904589001000



#FZ32A **Tank Adapter**




For pressurizing cooling system. Applicable to Freightliner Cascadia [2008], Columbia [2008]; International 6.4L Diesel [2012], Navistar VT 365 and International with 466 engine [1994-2002].

M52 x 2.5 Threads

#H2850-E24





- E24
- 3/4" Drive
- 110mm Length




#SPR0558 **Glow Plug Pliers**











M52 x 2.5 Threads







For pressurizing cooling system. Applicable to Volvo trucks V670 and VN430; Kenworth trucks [2007-2008].

M48 x 3 Threads



#FZ36 **Cap Adapter**





For testing pressure relief valve in cap. Applicable to Freightliner diesel trucks [2004] and Sterling trucks [2005].

M52 x 2.5 Threads

#FZ25 **Tank Adapter**





For pressurizing cooling system. Applicable to Volvo trucks [1978-2006] and Dodge Promaster 1500 [2014-2018].

• M47 x 3 Threads

#6500T-100

Torx Socket

Used to remove parts to allow access for brake jobs on MAN Commercial Buses.

- T-100
- 3/4" Drive
- 60mm Length





Are you tired of hearing this when you call other companies?

"Our offices are located at..."

(Like you called to find out where they are!)

"Thank you for calling, if you know your party's extension..."

(Yea, right, I have my party's extension saved on a napkin from yesterday!)

"All of our agents are currently assisting other customers..."

(Does this mean I will wait 10 minutes, for a call center off shore to answer?)

"If you know the first or last name of the person you wish to speak to..."

(I see 150 customers on my tool route every week, and don't have time for this!)

At AST there are real people answering our phones!














TOOLS LISTED BY SPECIALTY AND APPLICATION

PLIERS	80
GENERAL TOOLS	81-83
FLUID EXCHANGE	84-87
FUNNELS	88-91
OIL FILTER SOCKETS	
& WRENCHES	92-94
DIPSTICKS / OIL	
& TRANSMISSION	95
SPECIALTY SOCKETS	96-101
STUD PULLERS	102-103
BODY / RADIO / ELECTRICAL	104-105
MOTORCYLCE / ATV / MARINE	106
ELECTRIC / HYBRID VEHICLES	107-108
APPLICATION CHARTS	108-124
CALIFORNIA PROP 65 WARNINGS	125



#2017SACP

Swivel Spring Clamp Pliers








Used for various different spring clamp sizes found on fuel lines, radiator hoses, transmission cooler lines, etc. The rotating heads with unique grooves allow for 360° of adjustability for those hard to reach angles and locations.

#CP2015 Fuel Hose Clamp Pliers

Used to crimp fuel hose clamps.





#SCP2014

Spring Clamp Pliers

Pliers used for spring clamps found on fuel lines, radiator hoses, Honda transmission cooler lines, etc. Unique Grooves in Pliers Allow Grabbing Clamps from 2 Angles. The Overall Length is 8".



#MVW2050F

Fuel Line Pliers

Fuel line pliers used for fuel lines with plastic snap-together connectors found on Volkswagen and Audi models and Mercedes (163) M-Class fuel filters and applicable to some Fiat, GM and Opel gas engine vehicles. Also works on late model Lexus and Toyota fuel/evap lines.



#SPR0558


Glow Plug Pliers

For disconnecting the electrical connector that is attached to the glow plug used on Dodge Sprinter.



#M2000CP

Fuel / EVAP Clamp Pliers



Wire Soldering Clamp



An ideal solution for holding wires in place during soldering. It is a second set of hands, clamping down onto wires from either side of the tool. Holds firmly and may be used for various gauges of wiring.



California Residents: Proposition 65 WARNING. See page 125 for info.





- · Six inch flex cable for difficult to reach areas
- . Spring-loaded, sliding claws clamp onto wires firmly
- Extra strong magnetic base provides ample support
- Frame and Claws Made in USA from Diecast Aluminum



#WSFLCPLUS

Flashlight Clamp with Magnetic **Base and Flexible Cable**









#WSFLC Clamp



Clamp used in conjunction with our #WSC15 Soldering Clamp Tool. This can be used to help mount your #WSC15 to "Non-Magnetic" surfaces while you are soldering or it can be used as a flashlight holder, giving you that extra set of hands.

NOTE: BEST FOR ROUND MEDIUM TO SMALL



#3206

Door, Trim and Molding Tool Set

Set includes a T-25 long Torx screwdriver Shank Length 10 inches for accessing door handles on various Mercedes models. One trim spoon and one light duty hook is included for various interior jobs. Includes one pair of trim and cluster hooks. Three soft wedges are also included for various trim and molding jobs both for interior and exterior applications. Includes carrying pouch.







#3810 6-Piece File Set

Includes the following six files and a protective case: flat file, flat file/tapered front, round file, triangle file, square file and a half round / half flat file. Steel construction with rubber / plastic handles. Total length is 7.25" (including handle).



#ALSJ05

Aluminum Soft Jaw Vise Blocks

Pair of 5" soft jaws machined from aluminum. V-slots put a better grip on round objects. Each jaw has a small and large vertical slot. A large horizontal slot runs the length of each jaw. Strong magnets attach soft jaws firmly to 4", 5" and 6" vises. Applicable to many makes and models.





#MW34

Soft Orange Wedge Set



Constructed of soft orange polyethylene, this set of three wedge-style dash panel removal tools allows installers to remove dash trim bezels and other vehicle interior moldings including door panels, without causing damage. Great for installing electronics.

Three diverse sizes for various uses



5-Lobe Tamperproof Bit Set

5 Lobe bits and a 1/4" drive. Includes: T-10, T-15, T-20, T-25, T-27, T-30, T-40, T-45 and T-50. Applicable to various BMW, Mercedes, VW and Volvo models.



#ATFBASIC

Basic Driveline Filler

Used for filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Individual manufacturer sets are available as well as the individual adapters. U.S. made container, made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pump-saving both time and clean up afterwards.



#EU2009

Brake Bleeder Wrench

9mm brake bleeder wrench.



#EU2011

Brake Bleeder Wrench

11mm brake bleeder wrench.



#7200



Applicable to Toyota, VW/Audi and Volvo. Comes with 3 sets of interchangeable pins. Pins may be threaded in two different locations, based on application access. Overall length 18". 12" spread between pins at tip of arms, when pivot arm is at 90 degrees. Holding pins are made in USA.

S FLUID EXCHANGE

#ATFSET15

15-Piece Driveline Filler System

Contains all AST adapters produced through 2018. Used for filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Individual manufacturer sets are available as well as the individual adapters. U.S. made 8L container, made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pump-saving both time and clean up afterwards. Applicable: Audi, BMW, Ford, GM, Honda, Infiniti, Lexus, Mercedes, Mini, Nissan, Porsche, Subaru, Toyota, Volkswagen and Volvo.





#ATFSET9

9-Piece Driveline Filler System

Used for filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Individual manufacturer sets are available as well as the individual adapters. U.S. made 8L container, made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pump—saving both time and clean up afterwards. Applicable: Audi, BMW, Ford, Honda, Lexus, Mercedes, Porsche, Toyota, Volkswagen and Volvo.

- For 724 transmission, see #M21250.
- For 725 transmission, see #ATFMB725.





#ATFEURO8

8-Piece Euro Driveline Filler

For filling fluids in transmission, differentials and transfer cases (not suitable for use with fuels or solvents). Individual manufacturer sets are available as well as the individual adapters. U.S. made 8L container, made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pump–saving both time and clean up afterwards. Audi, BMW, Mercedes, Mini, Porsche, Volkswagen and Volvo.





5-Piece Driveline Filler for VW/Audi

Used for filling fluids in transmission and transfer cases (not suitable for use with fuels or solvents). U.S. made 8L container, made of UHDP (ultra high density polyethylene). Individual manufacturer sets are available as well as the individual adapters. Newly designed drum features a second port for filling or dumping fluids without having to remove the pump-saving both time and clean up afterwards. Applicable TDI or 2.0L (turbo) gas models: [2002-2008] Audi A4 (AWD), [2005-2011] A6 (FWD) [V6]; [2007-2016] VW Eos, [2008-2016] Golf, R32, GTI, [2005.5-2016] Jetta, [2004-2016] Beetle, [2012-2015] Passat, [2009-2016] CC.

- Used only to Fill, Not to Drain-So Clean Fluid Stays Clean
- 8 Liter Capacity
- includes 5 Attachment Adapters
- · Pump Dispenses Efficiently
- On/Off Ball Valve
- · Hose Length: 4ft 10in



INCLUDES #ATF 129 ADAPTER,



#ATFMB

Driveline Filler for Mercedes

For filling transmission fluid in Mercedes 722.9 automatic transmissions [2004-2018] using a M12 x 1.5 adapter (not suitable for use with fuels or solvents). Set includes pump, U.S. made 8L container, made of UHDP (ultra high density polyethylene), hose, shut-off valve and the #ATF 129 adapter. Additional adapters are available separately.

- For 724 transmission, see #M21250.
- For 725 transmission, see #ATFMB725.
- Used only to Fill, Not to Drain-So Clean Fluid Stays Clean
- 8 Liter Capacity
- Quick Attachment Adapters
- Pump Dispenses Efficiently
- On/Off Ball Valve
- Hose Length: 4ft 10in



#ATFFORD


Driveline Filler for Ford

Used for filling Ford automatic transmissions (not suitable for use with fuels or solvents). Set includes pump, U.S. made 8L container, made of UHDP (ultra high density polyethylene)., hose, shut-off valve and the #ATF 101 adapter. Applicable: [2004-2010] Ford Explorer, [2005-2010] Mustang, [2002-2005] Thunderbird.

- Used only to Fill, Not to Drain-So Clean Fluid Stays Clean
- 8 Liter Capacity
- Quick Attachment Adapters
- · Pump Dispenses Efficiently
- On/Off Ball Valve
- . Hose Length: 4ft 10in




S FLUID EXCHANGE



#ATFBASIC

Basic Driveline Filler



#ATFDRUMONLY

Additional ATF Drum



8 Liter Drum Only for Driveline Filler. Used to store additional fluids that are not in use.



#ATF101

ATF Adapter for Ford



Adapter used in conjunction with the ATF Filler System for Ford Explorer [2004-2010], Mustang [2005-2010] and Thunderbird [2002-2005].

• 1/8-27 NPT

#ATF102 **Universal ATF** Adapter

Long, angled adapter used in conjunction with the ATF Filler System. Used on many applications.

#ATF103 **ATF Adapter** for VW/Audi

Used for filling the VW Touareg transmission. COMPARABLE: #VAG1924/1

#ATF104

ATF Adapter for VW/Audi



Long, angled adapter used in conjunction with ATF Filler Systems.

COMPARABLE:
ADAPTER INCLUDED WITH VW FACTORY #VAG1924

#ATF105

ATF Adapter for VW/Audi and Mini



Transmission filling adapter used on VW/Audi and Mini with "AISIN" transmission.

M10 x 1.0 Threads

COMPARABLE: #VAS6262/2

#ATF17CVT

ATF Adapter for VW/Audi CVT



Driveline adapter for VW/Audi CVT transmission.

M22 x 1.5 Threads

COMPARABLE: #VAS5162

#ATFSU118

Subara Filling Adapter



Used for filling the front Differential on Subaru Crosstrek [2012-2017], Forester (non turbo) [2014-2017], Impreza (non turbo) [2012-2017], Legacy 4 cyl. [2013-2017] and Outback (4 cyl.) [2013-2017].

• M18 x 1.5 Threads

#ATF108V

ATF Adapter for Volvo



Driveline filler adapter. Applicable to some Volvo models [2007-2018] 6 speed and 8 speed Automatic transmissions with out a fluid dipstick. Used to fill with using the 5/16" x 24 threaded plug.

5/16-24 Threads

#ATFTOY118

ATF Adapter for Toyota



M18 x 1.5 Threads

COMPARABLE: #00002-11103-02



#ATF16DSG

ATF Adapter for DSG



Driveline adapter for VW/Audi DSG transmission.

M24 x 1.5 Threads

COMPARABLE: #VAS6262A

#ATF129

ATF Adapter for Mercedes



Mercedes adapter for 722.9 transmissions [2004-2018].

- M12 x 1.5 Threads
- For 725 Transmissions, see #ATFMB725

#ATF180

ATF Adapter for Infiniti





Adapter for Infiniti models with 7-speed automatic transmissions [2008-2017].

M8 x 1.0 threads

#ATFSU100

Universal ATF Attachment

This flexible adapter is used to fit into hard to reach applications where there is at least a 10mm internal diameter opening to fit into.



#ATF175 GM

ATF Adapter for GM



• M12 x 1.75 Threads

COMPARABLE: #DT-47784





#ATF125NIS

ATF Adapter for Nissan



Adapter used to fill the CVT transmission in Nissan Altima [2014-2016], Pathfinder [2013-2017], Rogue [2014-2017], Sentra [2017] and Versa [2013-2017].

M12 x 1.25 Threads

COMPARABLE: NISSAN #KV31103950



*OFFM2012 Oil Funnel for

Ford and Mazda



Used on newer Ford and Mazda models with 4 cylinder engines. Applicable to Ford EcoSport [2018], Edge [2012-2018], Escape [2008-2016], Expedition [2016-2018], Explorer [2012-2015], F-150 [2016-2018], Focus [2007-2018], Fusion [2013-2018], Mustang [2018]; Jaguar XF [2013-2015]; Land Rover LR2 [2015],

Range Rover Evoque [2012-2015]; Mazda 3 [2006-2015], 5 [2005–2015] CX-5 [2013-2015], Mazdaspeed 3 [2007-2015], Mazdaspeed 6 [2005] and MX-5 Miata [2006-2015].

• DO NOT USE **BRAKE CLEAN**

NOTE: MAY NOT FIT SOME APPLICATIONS WHERE THE FIRE WALL COWL DOESN'T PROVIDE CLEARANCE FOR ATTACHMENT OF FUNNEL. USE #FUN14KIT FOR THESE APPLICATIONS.



#OFSU1042

Subaru Oil Funnel



Fits all Subaru models with threaded oil cap (except Tribeca). Applicable to Subaru BRZ, Impreza, Imreza WRX, Impreza WRX STI, Legacy, Outback and Scion FR-S [2000-2018].

• DO NOT USE **BRAKE CLEAN**



#OFGMRD08

Ford and GM Oil Funnel



Applicable to various Aston Martin, Buick. Cadillac, Chevrolet, Ford, GMC, Hyundai, Jaguar, Land Rover, Mazda, Mercury, **Pontiac and Saab** models.

• DO NOT USE **BRAKE CLEAN**

#OFAAGM

Extension

Angled Funnel





All AST Funnels

are Made in USA

No Mess Fill **Every Time**

Made of **Strong ABS Plastic** or Polycarbonate

DO NOT

USE BRAKE CLEAN!

Using Brake Parts

Cleaner on Plastic Voids

Warranty







For use with our #FUN14KIT or #OFKIT. We left space in the #FUN14KIT to accommodate this adapter. Fits all Subaru models with threaded oil cap (except Tribeca). Applicable to Subaru BRZ, Impreza, Imreza WRX, Impreza WRX STI, Legacy, Outback and Scion FR-S.

• DO NOT USE BRAKE CLEAN





ONLY USED IN CONJUNCTION WITH #OFGMRD08 OR #OFGMFORD FUNNELS.

DO NOT USE BRAKE CLEAN

[2013-2014].



WARNING:

These products can expose you to chemicals including Acrylonitrile & Styrene, which are known to the State of California to cause cancer and Bisphenol A (BpA) & Butadiene, which is known to the State of California to cause birth defects or other reproductive harm.





Oil funnel for Chrysler and Dodge models equipped with the 3.6L engine. Made of strong polycarbonate. Creates a custom fit to valve covers and filler necks. Applicable: Chrysler Town and Country; Dodge Avenger, Challenger, Charger, Dart, Durango, Grand Caravan, Journey and Jeep Wrangler [2011–2017].

 DO NOT USE BRAKE CLEAN



#OFHON1033

Oil Funnel



Jeep Land Rover, Mazda, and Nissan models. Applicable to Dodge Caravan [2010], Charger V8 [2017]; Fiat 500 [2012-2016]; Ford F-250 & -350 Power Stroke engines (6.9L, 7.3L, 6.0L and 6.4L); Honda Accord Civic, CR V, Element, Fit, Odyssey, Pilot, S2000 [1998-2018]; Jaguar 4.2L [2003-2009]; Jeep Wrangler [2001-2011], Land Rover Defender, Discovery, Range Rover [2002]; Mazda 2 [2013]; Nissan Altima [2016], Maxima [2008-2016], Pathfinder [2010-2016], Rogue [2012-2016], and Sentra [2013-2016]; RAM Trucks 1500 [2012-2017].

- DO NOT USE BRAKE CLEAN
- For Honda/Acura SUV's and VAN's, the funnel needs to be used in conjunction with our #0FH33 Angled Extension.



#OFTOY1038

Threaded Toyota Oil Funnel



Applicable to all Lexus, Scion (except FR-S) and Toyota models with a threaded engine oil fill cap. For Toyota and Lexus 1/4 turn style oil caps, see #0FT0Y1001.

• DO NOT USE BRAKE CLEAN

NOTE: FOR TOYOTA PRIUS AND YARIS, THE FUNNEL NEEDS TO BE USED IN CONJUNCTION WITH OUR #OFT38 ANGLED EXTENSION





#FUNCRY36 Adapter for 3.6L Chrysler, Dodge and Jeep



For use with our #FUN14KIT or #0FKIT. Applicable: Chrysler Town and Country; Dodge Avenger, Challenger, Charger, Dart, Durango, Grand Caravan, Journey and Jeep Wrangler [2011–2017].

• DO NOT USE BRAKE CLEAN

#OFH33Funnel Extension for Honda and Acura



Oil funnel extension for our #0FH0N1033 oil funnel. Adds coverage and access where normal funnels do not fit. Applicable to Acura MDX; Honda Pilot, Odyssey and Ridgeline.

• DO NOT USE BRAKE CLEAN

NOTE: USED IN CONJUNCTION WITH #OFHON1033 OR OFHON33 FUNNELS.







Oil funnel extension for our #0FT0Y1038 oil funnel. Applicable to Toyota Prius and Yaris. Adds coverage and access where normal funnels do not fit.

• DO NOT USE BRAKE CLEAN

NOTE: NOTE: MUST BE USED IN CONJUNCTION WITH #OFTOY1038 OR OFTOY38 FUNNELS.



WARNING:

These products can expose you to chemicals including Acrylonitrile & Styrene, which are known to the State of California to cause cancer and Bisphenol A (BpA) & Butadiene, which is known to the State of California to cause birth defects or other reproductive harm.

FUNNELS







6-Piece Custom Oil Funnel Set



Includes funnel and five adapters to fit over a hundred models including Acura, Aston Martin, Cadillac, Chevrolet, Dodge, Ford, GMC, Honda, Hyundai, Jaguar, Land Rover, Lotus, Lexus, Mazda, Nissan, Pontiac, Saab, Scion and Toyota. When combined with our other adapters, the 45 degree elbow extension allows access where funnels otherwise do not fit.

- DO NOT USE BRAKE CLEAN
- Includes five adapters to fit over a hundred models
- 45 Degree elbow extension allows access to where the funnel would otherwise not fit
- Subaru, Chrysler/Dodge/Jeep 3.6L and Euro adapters may be purchased separately

#OFHD419 Oil Funnel for **Harley-Davidson** For the "push-in style" oil fill caps for Harley-Davidson Touring models [1999-2006]. • DO NOT USE **BRAKE CLEAN**

#OFHD35

Oil Funnel for KIA & Harley-Davidson

Applicable to Harley- Davidson Dyna [2007-2016] and Touring [2007–2017]; Kia Forte [2013– 2015], Optima [2016], Rio [2013-2016], Sedona [2015-2016], Sorento [2011-2016], Soul [2013-2015] and Sportage [2014–2016].

• DO NOT USE BRAKE CLEAN







WARNING:

These products can expose you to chemicals including Acrylonitrile & Styrene, which are known to the State of California to cause cancer and Bisphenol A (BpA) & Butadiene, which is known to the State of California to cause birth defects or other reproductive harm.




#OFAUD1000Euro 1/4-Turn Oil Filler





Specifically designed to attach to the valve covers. When you're adding oil to the engine you don't have to worry about making a big mess due to the internal bafe of the valve cover. Applicable to Audi, BMW; Dodge Sprinter; Mercedes; Porsche Cayenne and Panamera; VW/Audi 1.4L, 1.8L, 1.9L TDI, 2.0T, 2.8L, 3.0L, 3.2L, 3.6L and 4.2L engines; and Volvo 2.5L engines. Also fits Teledyne 550 and 520 engines found in Beechcraft and Cessna aircraft.

May not fit applications where cowl causes interference.





#OFVW2013 1/4 Turn Oil Funnel for VW/Audi



1/4 Turn funnel with four slots. Custom fit into valve cover for no mess filling of oil. Applicable to VW/Audi models with 1.8L and 2.0L turbo engines [2014-2018].





OIL FILTER SOCKETS & WRENCHES

#2101

7-Piece Oil Filter **Wrench Socket Set**



Set contains oil filter wrench sockets for many domestic and foreign applications. Covers all Mercedes-Benz applications. The 27mm, 32mm and 36mm hex sizes cover VW/Audi, BMW, newer Mercedes engines, and GM 2.2 L Ecotec engines. Covers Ford Escape Hybrid and Ford OEM #FL 910 and #FL 793. Covers Chevrolet 2.2L and 2.4L engines [2007–2014], Dodge Sprinter and Volvo models. The four, cup-style wrenches cover many VW, BMW, Toyota and Mazda 3.

California Residents: Proposition 65 WARNING. See page 125 for info.

















#M0219 #M0284

32 x 36mm Oil **Filter Socket**

Double sided 3/8" drive. Applicable to Audi Q3 and S3 2.0L Turbo [2015-2016], A6 3.0L [2014– 2016], Q7 3.0L [2011– 2016], Q7 3.6L [2007-2010]; BMW 335d and X5 35d [2009-2011], BMW 6 and 8 cyl. engines [1994-2005]; Chevy Cobalt, Impala and Malibu with 2.2L / 2.4L engines [2007–2014]; Porsche models [2009-2016]. VW TDI [2011- 2016], Touareg [2009-2016] and VR6 motors and Volvo models [2007-2014].



#2124

Oil Filter Socket



Used for the R & R of the oil filter housing cap on BMW, Chrysler, Dodge, Jeep with 3.6L, Saturn and Chevy 4cyl. EcoTec engines.

- 24mm 6 Flats
- 3/8" Drive

#2127

Oil Filter Socket



Applicable to various models from Dodge Dart, Fiat, Hyundai, Kia and Mini models.

- 27mm 6 Flats
- 3/8" Drive

#BM1276

Oil Filter Wrench



Used ON BMW i3 "Range Extender" engine [2014-2018] and for R & R of oil filter on BMW motorcycles [2007–2016] with oil filter #11 42 7 673 541. Also for R & R of 12 flute Mercedes OEM oil filters.

- 76mm 12 flutes
- 3/8" Drive

NOTE: SOME NEW BMW MOTORCYCLES COME FROM FACTORY WITH FILTER ENDING IN '779'



#2132 Oil Filter Socket

Applicable to various models from Audi, BMW N57 diesel engine, Chevrolet 2.2L and 2.4L engines [2007-2014], Maserati, Saab, Saturn, and Volkswagen.

- 32mm 6 Flats
- 3/8" Drive



#2136

Oil Filter Socket

BMW M52, M60, M62, M70 and M73 engines: Ford F-250 and F-350 6.0L turbo diesel [2004]; Mercedes OM604, 605 and 606; Mini Cooper/S [2002-2006]; Volkswagen Corrado, Eurovan VR6, Golf R32 3.2L VR6, Jetta 2.0L Turbo [2006], Jetta 2.8L VR6, Passat 2.8L VR6, Touareg and Volvo models with 36mm hex molded into the oil filter cap [2007-newer].

- 36mm 6 Flats
- 3/8" Drive



OIL FILTER SOCKETS & WRENCHES



#M0219

Oil Filter Wrench



Applicable to Audi, BMW motorcycle, Dodge, Ford, Mazda, Mercedes, Porsche, Toyota and VW.

- 74mm 14 Flats
- · Use with 22mm socket

COMPARABLE: MERCEDES #103 589 02 09 00

California Residents: Proposition 65 WARNING. See page 125 for info.




#2175 Oil Filter Wrench



Applicable to various Mercedes and Volkswagen models. Also Fits newer Sprinter and Mercedes models with 2.1L turbo diesel engine [2015-2018].

- 74.5mm -14 Flats
- Use with 22mm socket







#SU8015

Oil Filter Wrench

Applicable to Hyundai 4cyl. [1992-2012]; KIA [2001-2012]; Scion FR-S [2013-2016]; Subaru BRZ [2013-2018], Forester [2016-2018], Impreza WRX [2016-2018], Legacy (6-cyl.), Outback and Tribeca.

- 80mm 15 Flats
- 3/8" Dive

FITS NAPA GOLD OIL FILTER #1334





#JAS6514

Oil Filter Wrench

Applicable to Honda vehicles [1987-2018]; Infiniti vehicles [2004-2018]; Jaguar F-Pace [2017], XE [2017], XF [2017]; Land Rover Evoque [2018]; Kawasaki Motorcycles [1990-2009]; Nissan 350Z [2002-2009], 370Z [2010-2018], Altima [1997-2018], Armada [2004-2018], Cube [2009-2014], Frontier [1997-2018], GT R [2008-2018], Juke [2011-2016], Maxima [1994-2018], Murano [2002-2018], Pathfinder [1995-2018], Quest[2006-2016], Rogue [2008-2018], Sentra [2001-2018], Titan [2003-2018], Versa [2006-2018] and Xterra [2002-2015]. Also works on Kawasaki factory filter #16097-0003 and Yamaha factory filter #5GH-13440-00. Also works on Powersports vehicles that utilize "HF303" oil filters including Honda, Polaris, Kawasaki and Yamaha.

- 65mm 14 Flats
- 3/8" Drive




#M0284

Oil Filter Wrench



Used on Mercedes 3.0L V6 CRD (Diesel) engines found in Jeep Grand Cherokee [2007–2008]; Mercedes Bluetec engines in E 320 [2007–2009], E 350 [2011–2013], GL 320 [2009], GL 350 [2010–2013], ML 320 [2009], ML 350 [2010-2014], R 320 [2009], R 350 [2010-2013], S 350 [2012–2013] and Sprinter [2007–2015].

- 84mm 14 Flats
- Use with 22mm socket





#V410

Oil Filter Wrench



Applicable to BMW models with N52, N54, N55 and N63 engines [2006–2017]. Fits all Volvo Models [1999–2007] (except 2005 40 and 50 Series). For [2015–newer] Volvo, see #VB414.

- 86.5mm 16 Flats
- Use with 22mm socket

COMPARABLE: BMW #119240 AND VOLVO #9995679

California Residents: Proposition 65 WARNING. See page 125 for info.



#TOY647LG

Oil Filter Wrench

NEW!



Applicable to Toyota V6 and V8 engines with canister style filter cartridge [2005-2019]. Does not fit on Sequoia.

- 64mm 14 Flats
- 3/8" Drive

OIL FILTER SOCKETS & WRENCHES

#JA19015

Oil Filter Wrench

Oil filter wrench for Jaguar and Land Rover models with the 3.0L v6 and 5.0L v8 engines [2010-2017].


- 90mm 15 Flats
- 3/8" Drive



Oil Filter Wrench for Volvo

Fits Volvo 2.0L turbo. Applicable to Volvo S60, S80, V60, XC60 and XC70 [2015-2019].

- 16 Flats
- · Use with 22mm socket










#TOY300

Oil Filter Wrench Set for Toyota

Toyota 3-piece oil filter wrench set. With the #TOY300 you have every gas engine Toyota and Lexus model covered [1980-2019].

Includes #T0Y640, #T0Y730 and #M0219.






#TOY730

Oil Filter Wrench

Applicable to Lexus ES 250 [1990-1991], ES 300[1992-2003], ES 300h [2013], ES 330 [2004-2006], GS 300 [1993-2005], GS 400 [1998-2000], GS 430 [2001–2004], GX 470 [2004–2009], IS 300 [2001–2005], LS 400 [1990-2000], LS 430 [2001-2006], LX 450 [1996-1997], LX 470 [1998-2007], RX 300 [1999–2003], RX 330 [2004–2006], RX 400h [2006–2008], SC 300 [1992–2000], SC 400 [1992–2000], SC 430 [2002–2010]; Toyota 4Runner [2003-2009], FJ Cruiser [2007-2009], Land Cruiser [1993-2007], Sequoia [2001-2009], Tacoma [2005-2013] and Tundra [2000-2010].

- 73mm 14 Flats
- 3/8" Drive or Use 24mm or 15/16" socket





#HD1674

Oil Filter Wrench for **Harley-Davidson**



Oil filter wrench for [1980-2016] Harley-Davidson motorcycles with a spin on oil filter.

- 74mm 14 Flats
- Use with 22mm socket

California Residents: Proposition 65 WARNING. See page 125 for info.





#TOY640 Oil Filter Wrench




Applicable to all Lexus / Scion /Toyota models with paper cartridge-style filter in Lexus 200h [2011-2016], ES 350 [2007-2018], GS 300 [2006-2018], GS 350 [2007-2018], GS 450h [2007-2018], GS 460 [2008-2011], GX 460 [2010-2018], HS 250h [2010-2013], IS 250 [2006-2010], IS 250 C [2010-2016], IS 350 [2006-2018], IS 350 C [2010-2016], IS F [2008-2014], LS 460 [2007-2016], LS 600h [2008-2016], LX 570 [2008-2018], RX 350 [2007-2018], RX 450h [2010-2018]; Scion tC [2005–2016], xA [2004–2006], xB [2004–2016], xD [2008–2013]; Toyota 4Runner [1985–2019], Avalon [1995–2019], Camry [1983–2019], Corolla [1983–2019], Echo [2000–2005], FJ Cruiser [2010–2014], Highlander [2001–2019], Prius [2001–2019], Matrix [2003–2014], MR2 [1985–2005], Paseo [1992–1997], RAV4 [1996–2019], Sequoia [2009–2016], Sienna [2007–2019], Solara [1999-2009], Tundra [2007-2019], Venza [2009-2016] and Yaris [2006-2019].

- 64mm 14 Flats
- Use with 24mm or 15/16" socket

COMPARABLE: #09228-06501 AND #09228-06500-02





COMPARABLE: MERCEDES #120 589 07 21 00

DETAILED VIEW

#AU40178 **Engine Oil Dipstick**

Applicable to Audi A4 [2009-2017], A5 [2009-2015], A6 [2009-2015], A8 [2011-2014], Q5 [2013-2015], RS5 [2013-2015], S4 [2010-2015], S5 [2009-2012], S6 [2013-2015], S7 [2013-2015]; Porsche Cayenne S Hybrid [2011-2014], Panamera S Hybrid [2012-2014]; Volkswagen Touareg [2011-2014].

COMPARABLE: #T 40178



#SPR886

Transmission Dipstick for Sprinter and Crossfire



Used on Dodge / Freightliner Sprinter [2002-2009] and Chrysler Crossfire [2004-2008].

COMPARABLE: CHRYSLER #8863B

#CRY323 **Transmission Dipstick** Stainless steel design and clear level marks with a knurled handle. Applicable to all 6F24 6-speed and 948TE 9-speed automatic transmissions found in Dodge Dart [2012-2016], Fiat 500 [2012-2017]; Jeep Cherokee [2014-2017], Compass **DETAILED** [2014], Patriot [2014] and Renegade [2015-2017]. COMPARABLE: MOPAR #10323A

#M7226

Transmission Dipstick for Mercedes 722.6




models with 722.6 transmission [1997-2006]; Freightliner Sprinter [2010-2016] and Jaquar models with W5A580, Jaquar XKR [2000-2002].

COMPARABLE: JAGUAR #307-379 AND MERCEDES #140 589 15 21 00.

#M21250

Transmission Dipstick



#CRY933

Transmission Dipstick for Chrysler

Used on all vehicles equipped with a NAG1, 42RLE, 62TE and CVT transmission. Applicable to Chrysler 200 [2011-2014], 300 [2006-2014], Aspen [2008-2009], Pacifica [2007-2008] Sebring [2007-2013], Town & Country [2008–2017]; Dodge Avenger [2007–2014], Caliber [2007–2012], Challenger [2008-2014], Charger [2006-2014], Dakota [2008- 2011], Durango [2008-2013], Grand Caravan [2008-2017], Journey [2009-2014], Magnum [2006-2013], Nitro [2007-2011], Promaster [2014-2017], Ram [2007-2013], Jeep Commander [2006-2010], Grand Cherokee [2006-2013], Liberty [2006-2012], Patriot [2007-2013] and Volkswagen Routan [2009 -2014].

COMPARABLE: #9336 AND #9336A.

TO THE REAL PROPERTY OF



SPECIALTY SOCKETS

#6300

12-point Socket Bit Set for VW/Audi

7-Piece set includes sockets:

- #6300XL-14 (long 14mm)
- #6300XL-8 (long 8mm)
- #6300XL-10 (long 10mm)
- #6300X-16 (16mm tamper-proof)
- #6300X-12 (12mm bit)
- #6300X-14 (14mm bit)
- #3424 (Spreader)







#6300X-12

Socket Bit

12mm, 12-Point

For the R & R of axle shaft

bolts on newer VW Jetta

and rear toe adjustment

with tight clearance on various VW models.

on Audi A6 [1999- newer].

Used for bell housing bolts







#6300X-14

14mm, 12-Point Socket Bit

For R & R of Audi TT differential bracket and for bell housing bolts with tight clearance on various VW models.





#3424 Spreader

For the R & R of the front shock absorber tube from the wheel bearing housing. Applicable to Audi A3 [2006-2008], TT [2000–2008] and A5 [2008– 2009]; Volkswagen Golf, Beetle [1999– 2008], Rabbit, GTI, Passat [2006–2008], Jetta [1999- 2006], Tiguan [2008].

• 3/8" Drive



#6300X-16

12-Point **Tamperproof Socket**

Used for R & R of manual transmission drain plug. Applicable: Audi Q7, Porsche Cayenne and VW Touareg brake caliper bolts.

- 16mm Tamper-proof
- 1/2" Drive
- 60mm Length

COMPARABLE: #904 589 00 10 00



#6300XL-8 12-Point **Long Socket**

Used for R & R of axle shaft bolts on VW Beetle, Jetta TDI and older VW/Audi models.

- 8mm
- 3/8" Drive
- 90mm Length



#6300XL-10 12-Point

Long Socket

Used for R & R of axle shaft bolts on Volkswagen Golf and Passat.

- 10mm
- 3/8" Drive
- 90mm Length



#6300XL-14 12-Point **Long Socket**

Used for R & R of late model VW Eurovan axle shafts and ball joints. Also used on VW Touareg inner CV bolts.

- 14mm
- 1/2" Drive
- 140mm Length





#6355X-14

12-Point Scoket

Ideal for use on rear brake caliper bolts on VW Jetta and Passat [2006- newer].

- 14mm
- 1/2" Drive
- 64mm Length



#6500TPT-100

Torx Socket

Used to remove and replace the camshaft adjuster central valve on Mercedes 274, 276, 270, 278 and 271 engines [2012-2016].

- T-100 Tamper-proof
- 1/2" Drive
- · 95mm Length

COMPARABLE: MERCEDES #271589001000



#6500T-100

Torx Socket

Used to remove parts to allow access for brake jobs on MAN Commercial Buses.

- T-100
- 3/4" Drive



#6500X-18

12-Point Socket

Used for R & R of the rear axle bolts on VW Jetta and Golf [2006-2015].

- 18mm
- 1/2" Drive
- 95mm Length

COMPARABLE: #T10162



#6500TL-80

Torx Socket

NEW!

Used on BMW for R & R of driver's side wiper arm on E31, E38 and E39 chassis. Also fits Lamborghini wheel lug bolts on Gallardo models.

- T-80 Tamper-proof
- 1/2" Drive
- · 100mm Length



• 60mm Length



#6500X-24

12-Point Socket

For R & R of front axle bolt. Applicable: VW Golf [2010-2013] and Tiguan [2009–2015].

- 24mm
- 1/2" Drive
- 38mm Length

COMPARABLE: #T 10361



#6500-14

Allen Socket

Applicable to Audi A4 Quattro front & rear axle bolts [1996-2001] and VW Passat rear axle bolts [1996-2002].

- 14mm
- 1/2" Drive
- 37mm Length



Applicable to Audi A4 (AWD) front

#6500-17

Allen Socket

& rear axle bolts [2002-2009], Audi A6 front axle bolts [1999-2009] and VW Passat front axle bolts [1998-2005].

- 17mm
- 1/2" Drive
- 38mm Length



#6500X-30

12-Point Socket

Used For R & R of front axle nuts. Applicable: [1999-2005] VW Cabrio, Beetle, Golf and

- 30mm
- 1/2" Drive
- 45mm Length



#6506

Axle Nut Socket Set for VW/Audi

6-Piece set includes sockets:

- #6500-14
- #6500-17
- #6500X-18
- #6500X-24 • #6500X-30
- #6500X-32

NOTE: FOR [2009-NEWER] AUDI A4 REAR AXLE BOLTS, ORDER #H985-19.





#6500X-32 12-Point Socket

Used for R & R of front and rear axle nuts on [2004-2016] VW Touareg.

- 32mm
- 3/4" Drive
- 60mm Length







SPECIALTY SOCKETS

#100-30A

12-Point Deep Socket

Used for R & R of transmission drive shaft flange nut and pinion shaft flange nut of differential. Applicable: many BMW, Mercedes and Toyota models with 30 mm, 12 pt axle nuts.

- 30mm
- 1/2" Drive
- 85mm Length
- Thin-walled



#3900

5-Lobe Tamperproof Bit Set

5 Lobe bits and a 1/4" drive. Includes: T-10, T-15, T-20, T-25, T-27, T-30, T-40, T-45 and T-50. Applicable to various BMW, Mercedes, VW and Volvo models.



#M8160

Extra Long 8mm Socket



Used for R&R of rear tail light assembly on Mercedes models [2017-2018].

- 1/4" Drive
- 160mm Length



#BMW10160

Extra Long 10mm Socket



Applicable to Mercedes-Benz rear bumpers and used for R & R of the ground connector screw for the injector on BMW N54 engines.

- 1/4" Drive
- 160mm Length

FOR TAIL LIGHT ASSEMBLY ON NEWER MERCEDES, ALSO ORDER M8160



#BMW11850

Head Bolt Socket for BMW



#BMW11860

Head Bolt Socket for BMW

Used on BMW N51, N52, N54 & N55 engines. Used in conjunction with #BMW11850.

- T-60
- 1/2" Drive
- 195mm Length

COMPARABLE: BMW #118580





#BFLT60 Machined T-60 Socket



Special machined, long T60 Torx socket is machined for clearance to access the rear wheel bearing bolts without hitting the ABS rotor sensor on Ford Edge/Lincoln MKX. Also used for R and R of flywheel bolts on BMW E34 and E39 [V8] 4.0L 4.4L & 5.0L with standard transmission.

- 1/2" Drive
- 140mm Length

COMPARABLE: #114180



#BMW377

Allen Socket

Used for easy removal of

bolts on BMW E36, E46,

E39 and E31 models, and

Mercedes S Class (221).


• 7mm

• 3/8" Drive

• 32mm Length

the rear brake caliper slide





- T-30
- 70mm Length



#H985-19 Allen Socket



Used on Audi A4 rear axle bolts [2009–newer] and anywhere a 19mm Allen socket is needed on Audi, Mercedes, Porsche, and VW.

- 19mm
- 1/2" Drive
- 42mm Length



#EU2090

Allen Socket

Applicable to Volvo front caliper slide bolts [2010–2015].

- 9mm
- 3/8" Drive
- 50mm Length



#H2850-E24

Female Torx Socket

Used for R & R of head bolts on International and Man commercial vehicles which use MAN D20, D25 and D28 engines.

- E24
- 3/4" Drive
- 110mm Length

#ALT34018

ncial

NEW!

#TSE10TP5Tesla E10 5

Tesla E10 5 Lobe Socket







Used to remove the license plate bracket fasteners on model S and used on Model 3 to remove the electrical connectors.

- E10 5 Point
- 1/4" Drive
- 25mm Length



DANGER:

Caution when using on electric vehicles, High Voltage Shock possible

#6300T-50 Torx Socket

NEW!

Used in conjunction with #ALT34018 on KIA and Mercedes Alternator Pulley Bolts.

- T-50
- 3/8" Drive
- 70mm Length



Multi-Toothed Alternator Pulley Socket

Used for R & R of free-wheel pulley on the alternator. Used in conjunction with #S3054X-10 or #6300T-50 sockets.

COMPARABLE:

MERCEDES #602589001000, VW/AUDI #3400, VOLVO #9995760



Socket for Nissan

Applicable to the Flywheel bolts used on Nissan models.

- E12
- 1/2" Drive
- 37mm Length





#HO10PT

10-Point Socket



Applicable: [2001–newer] Honda Civic and Acura RSX rear lower control arms.

- 16mm
- 1/2" Drive
- 40mm Length

SPECIALTY SOCKETS

#BMW11845

Torx Socket

Used for BMW VANOS housing bolts.

- T-45 Tamper-proof
- 3/8" Drive
- · 100mm Length



Female Torx Socket

Used on front axle nut on All Wheel Drive Mercedes C 230, C 300, C 350 [2008-2009], C 250, C 300, C 350 [2010-2011], C 300, C 350 [2012–2014], C 350 [2015], E 350, E 550 [2010– 2014], E 350 [2015–2016] and S 550 [2007–2013].

- E24
- 1/2" Drive
- 78mm Length



Glow Plug Socket Glow plug socket for Dodge Sprinter. • 10mm • 3/8" Drive

#M1020

#MSP1412

Magnetic Spark Plug Socket

Fits BMW, BMW Motorcycles, Ford, Mini, Nissan, Porsche, Scion, Subaru and Toyota.

- 14mm 12 Point
- 3/8" Drive

NOTE: SPARK PLUG SOCKET IS SLENDER IN DESIGN TO FIT APPLICATION.



#M820 **Glow Plug Socket** Glow plug socket for Mercedes and Sprinter. • 8mm • 3/8" Drive

#M17XLWS

Long Mercedes Lug Bolt Socket

Used to R &R the "Flower Shaped" lug bolt on Maybach and Mercedes 221 S class and late model CL class. Fits Mercedes wheel lug bolt part #0009905407.

- 1/2" Drive
- 86mm Length



#M17WLS

Mercedes Lug Bolt Socket

Used to R &R the "Flower Shaped" lug bolt on Maybach and Mercedes 221 S-class and late model CL class. Fits Mercedes wheel lug bolt part #0009905407.

- 1/2" Drive
- 50mm Length





#SP1412

Spark Plug Socket

Fits BMW, BMW Motorcycles, Ford, Mini, Nissan, Porsche, Scion, Subaru and Toyota.

- 14mm 12 Point
- 3/8" Drive
- Rubber boot to hold spark plug

COMPARABLE: BMW #121220

NOTE: SPARK PLUG SOCKET IS SLENDER IN DESIGN TO FIT APPLICATION.



#S3054X-10

12-Point Socket



Used for R and R of cylinder head bolts. Applicable to Mercedes OM 601, OM 602 and OM 603 engines; Pontiac Vibe [2003-2007]; Toyota Matrix [2003-2007]; Volkswagen and Audi 10mm, 12-point head bolts.

- 10mm
- 1/2" Drive
- 140mm Length

NOTE: MOST [1998-NEWER] VW/AUDI APPLICATIONS REQUIRE THE #3462 HEAD BOLT SOCKET.

COMPARABLE: MERCEDES #601589001000, VW #3410 AND VOLVO #9512849.

#S3054X-12

12-Point Socket



Applicable to Mercedes head bolts on OM 615, 616, 617, M 102, and M 103 engines; for R and R of cylinder head bolts on Toyota 4Runner V6 [2003], all 2ZZ engines with WT including Toyota Celica [2000-2001] and Highlander 2AZ-FE engines [2001-2006]; older Volkswagen and Audi models with 12mm, 12-point head bolts.

- 12mm
- 1/2" Drive
- 140mm Length

NOTE: MOST [1998-NEWER] VW/AUDI APPLICATIONS REQUIRE THE #3462 HEAD BOLT SOCKET.

COMPARABLE: MERCEDES #617589001000



#SU070

Drain Plug Socket for Subaru

Used for R & R of the drain plug on Manual Transmission. Applicable to Subaru with manual transmission [2003-2016]

- 1/2" Drive
- 105mm Length

#S40-300 3mm Socket

Used on Audi A6 [2012+] **Fuel Door Actuators and** any place a 3mm socket is needed.

- 1/4" Drive
- 25mm Length



#3035

3.5mm Socket

Used for R & R of the Proximity (Radar) Sensors and any place a 3.5mm socket is needed.

- 1/4" Drive
- 25mm Length



#TOV105

Head Bolt Socket

Used for head bolt sockets on newer Toyota models that use a special #8 bi-hexagon socket. Applicable: Toyota Paseo, Prius [20012009], Tercel and Yaris [2006-2013].

- #8 Bi-Hexagon
- 1/2" Drive
- 100mm Length



#T10107B

Long Allen Socket

Fits right hand stub shaft: 6-speed manual, OA5 and O2N and VW 2.5L I5 (4v) intake manifold bolts, Jetta (BGP & BGQ) [2005-2007], Jetta (CBTA & CBUA) [2008-2014], Rabbit (BGP & BGQ) [2006-2007], Rabbit (CBTA & CBUA) [2008-2009], Beetle (BPR & BPS) [2006-2010] and Beetle (CBTA & CBUA) [2012-2014].

- 6mm
- 3/8" Drive
- · 325mm Length



#VW5220

Camshaft Adjuster Socket

Used for camshaft adjuster bolt on VW/Audi 2.0L turbo (BPG) (BPY) engines.

- #10 Polydrive
- 1/2" Drive
- 53mm Length





Individual Stud Removers / Installers

3/8" & 1/2" Drive except #200-9/16 & #200-5/8 which are 27mm Hex.



#200-6 6mm



#200-7 7mm



#200-8 8mm



#200-10 **10mm**



#200-12 **12mm**



#200-1/4 1/4"



#200-5/16 5/16"



#200-3/8 3/8"



#200-7/16 7/16"



#200-1/2 1/2"



#200-9/16 9/16"




#200-5/8 5/8"

The AST Production Year is stamped on the stud remover. Stud removers are warrantied for 10 years from this date.

Stud Removers: Stud removers are warrantied for 10 years.

External body: The production year is stamped on the stud remover. Only if the external body is damaged, should the stud puller be sent in, if it is within the 10 year warranty.



Parts Kit for Stud Removers / Installers



Internal Parts Kit contains: cage, three rollers,clip, and washer

Internal parts: DO NOT send in your stud remover that only needs the internal parts replaced. Simply call for assistance and we will send out a replacement parts kit [at no charge while under warranty]. The table to the right indicates replacement numbers for the internal parts.

California Residents: Proposition 65 WARNING. See page 125 for info.

STUD REMOVER SI	ZE IN	ITERNAL D	ARTS KIT


6mm	#60
7mm	#70
8mm	#80
10mm	#100
12mm	#120
1/4"	#250
5/16"	#312
3/8"	#375
7/16"	#437
1/2"	#500
9/16"	#562
5/8"	#625

#201

4-Piece Metric Stud Puller Set



4-Piece stud remover set. Includes 6mm, 8mm, 10mm and 12mm stud remover tools. Works on most makes and models. Multiple applications. Carrying case included.




#201-7

5-Piece Metric Stud Puller Set



5-Piece metric stud remover set. Includes 6mm, 7mm, 8mm, 10mm and 12mm stud remover tools.




#202

5-Piece Standard Stud Puller Set



5-Piece standard stud remover set. Includes 1/4, 5/16, 3/8, 7/16, and 1/2 inch stud remover tools. Works on most makes and models.




#203

7-Piece Standard Stud Puller Set



7-Piece standard stud remover set. Includes 1/4, 5/16, 3/8, 7/16, 1/2, 9/16, and 5/8 inch stud remover tools. Works on most makes and models.



#SR101

Stud Remover and Installer Set

Pieces thread onto broken studs, lock together and are turned out with a socket or wrench.

 Contains sizes: M6 x 1.0, M8 x 1.25, M10 x 1.25 and M10 x 1.5









#3810

6-Piece File Set

Includes the following six files and a protective case: flat file, flat file / tapered front, round file, triangle file, square file and a half round / half flat file.






DETAILED VIEW OF FILE TIPS SHOWN HERE

#VW93005

Connector Release Tool

Used to remove flat terminals with two release tangs from the connector plug (1mm wide, 2.5mm apart and 16mm long). Replaces #S 1556 N.





#WSC15 Wire Soldering Clamp



This clamp tool is an ideal solution for holding wires in place during soldering. It is a second set of hands, clamping down onto wires from either side of the tool. Holds firmly and may be used for various gauges of wiring.



- Spring-loaded, sliding claws clamp onto wires firmly
- Extra strong magnetic base provides ample support
- Frame and Claws Made in **USA from Diecast Aluminum**



#M8160

Extra Long 8mm Socket





Used for R & R of rear tail light assembly on Mercedes models [2017-2018].

- 1/4" Drive
- 160mm Length

#BMW10160

Extra Long 10mm Socket





Used for R & R of the ground connector screw for the injector on BMW N54 engines and Mercedes-Benz rear bumpers.

- 1/4" Drive
- 160mm Length

COMPARABLE: #118620





Constructed of strong black polycarbonate, this set of three wedge-style dash panel removal tools allows installers to remove oil pans, rocker covers and more, without causing damage.



• More Ridgid than the Orange #MW 34 Set and used on **Much Heavier Jobs**

California Residents: Proposition 65 WARNING. See page 125 for info.

Door, Trim and Molding Tool Set Set includes a T-25 long Torx screwdriver for accessing door handles on various BMW and Mercedes models. One trim spoon and one light duty hook is included for various interior jobs. Includes a specialty door handle tool for VW Tiguan models, as well as one pair of trim and cluster hooks. Three soft wedges are also included for various trim and molding jobs both for interior and exterior applications. Includes carrying pouch.

#MW34

Soft Orange Wedge Set



Constructed of soft orange polyethylene, this set of three wedge-style dash panel removal tools allows installers to remove dash trim bezels and other vehicle interior moldings including door panels, without causing damage. Great for installing electronics.



• Three Diverse Sizes for Various Uses



#M0333

Puller Set (pair of hooks)



Used for R & R of the instrument cluster on Mercedes models. Applicable: Mercedes W 107, 116, 123, 124, 126, 129, 140, 168, 170, 201, 202, 208, 210 and 463 chassis.

Assembly Tool

#T10389




housing on doors with no lock cylinder. Applicable to VW Tiguan [2009-2016].

INCLUDED IN

#T10518A **Grab Handle**



the roof grab handle of the Golf [2013-2017] and Tiguan [2016-2017] without causing damage.



#3316

Radio Removal Keys

For removing the factory installed radio. Applicable: new body style VW Passat [1999-2005] and Jetta and Golf [1999-2005] with vertically aligned key slots.



#3344A

Radio Removal Tool

For radio removal on Audi A4, A6, A8 and VW new Beetle models with horizontally aligned key slots. Two pair required in most cases.

COMPARABLE: VW #T 10057






#HD1674

Oil Filter Wrench for Harley-Davidson

For Harley Davidson motorcycles [1980–2016] with a spin on oil filter. Machined, window design clears the crank sensor.

- 74mm 14 Flats
- · Use with 22mm socket






#M0219

Oil Filter Wrench



Used on BMW motorcycles F650, F800, K100, K1100, K1200GT [2003–2004], K1200LT, K1200R, K1200RS [1996–2004], K1200S, K1300, K75, R1100, R1150, R1200C, R1200CL, R1200GSW [2013–2014], R850 and S1000RR.

- 74mm 14 Flats
- · Use with 22mm socket





#JAS6514

Oil Filter Wrench

Applicable to Honda and Nissan vehicles. Kawasaki factory filter #16097-0003 and Yamaha factory filter #5GH-13440-00. Also works on Powersports vehicles that utilize "HF303" oil filters including Honda, Polaris, Kawasaki and Yamaha.

- 65mm 14 Flats
- 3/8" Drive



#BM1276

Oil Filter Wrench

For R & R of oil filter on BMW motorcycles [2007–2016] with oil filter #11 42 7 673 541 found on BMW F650F, F800GS, HP2, K 1600 GTL /GT, K1200GT [2006–2008], K1200R/SP0RT, K1200S, R 1200 ST, R1200GS, R1200R, R1200RT, R1200S and S 1000 RR.

- 76mm 12 Flutes
- 3/8" Drive



#FZ13818

Adapter

For pressurizing cooling system. Works with many Asian and domestic models. Applicable: vehicles with small, shallow necks.



#OFHD35

Oil Funnel for Harley-Davidson



 DO NOT USE BRAKE CLEAN

California Residents: Proposition 65 WARNING. See page 125 for info.



#OFHD419

Oil Funnel for Harley-Davidson





 DO NOT USE BRAKE CLEAN

California Residents: Proposition 65 WARNING. See page 125 for info.



#3035

3.5mm Socket

Used for R & R of the Proximity (Radar) Sensors on Tesla vehicles.

- 1/4" Drive
- 25mm Length



#ATFBASIC

Basic Driveline Filler

Applicable to Nissan Leaf to fill the gear reduction assembly and on Tesla Drive lines. U.S. made container, made of UHDP (ultra high density polyethylene). Newly designed drum features a second port for filling or dumping fluids without having to remove the pumpsaving both time and clean up afterwards.

- Used only to Fill, Not to Drain-So Clean Fluid Stays Clean
- 8 Liter Capacity
- Quick Attachment Adapters
- Pump Dispenses Efficiently
- On/Off Ball Valve
- · Hose Length: 4ft 10in



#TSE10TP5 Tesla E10 5 Lobe Socket

NEW!





1/4" Drive. Used to remove the license plate bracket fasteners on model S and used on Model 3 to remove the electrical connectors.

- E10 5 Point
- 1/4" Drive
- 25mm Length



DANGER:

Caution when using on electric vehicles, High Voltage Shock possible





#TM1215

Ball Joint Hammer Nut




Used for breaking free steering knuckle/ suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts.


- M12 x 1.5 Threads
- 22mm 7/8" Hex





NOTE: FOR THE COMPLETE 4PC. SET, PURCHASE THE #TM20194 CONTAINING M12X1.25, M12X1.5, M14X1.5 AND M16X1.5.





#TM1415

Ball Joint Hammer Nut



Used for breaking free steering knuckle/ suspension joints using an impact hammer. Nut must be threaded all the way onto knuckle/ suspension joints threaded shafts.

- M14 x 1.5 Threads
- 22mm 7/8" Hex





#TOY640

Oil Filter Wrench








Applicable to all models with paper cartridge-style filter in Lexus CT 200h [2011-2016], GS 450h [2007-2018], HS 250h [2010-2013], LS 600h [2008-2016], RX 450h [2010-2018]; Toyota Avalon Hybrid [2013-2019], Camry Hybrid [2007-2019], Highlander Hybrid [2006-2019], Prius [2001-2019] and RAV4 Hybrid [2016-2019].

- 64mm -14 Flats
- Use 24mm or 15/16" socket

COMPARABLE: #09228-06501 AND #09228-06500-02







For pressurizing cooling system. Applicable to Lexus CT 200h [2011–2016], GS 450h [2007-2018], HS 250h [2010–2013], LS 600h [2008-2016], RX 450h [2010-2018]; Toyota Avalon Hybrid [2013–2019], Camry Hybrid [2007–2019], Highlander Hybrid [2006–2019], Prius [2001-2019] and RAV4 Hybrid [2016-2019].

M34 x 3 Threads

Tank Adapter





For pressurizing cooling system . Applicable to BMW Hybrid Models 330e, 530e, 740e and X5 40e [2016-2019]; BMW Electric Models i3 and i8 [2014-2019].

• M47 x 3 Threads



APPLICATION CHARTS 110-124
CALIFORNIA PROP 65

WARNINGS 125









• M51 x 4 Threads

MAKE / MODEL	YEAR RANGE
BMW – 318i	[1996–2005]
BMW – 323i	[1999]
BMW - 323is	[1996–2005]
BMW – 325i	[2004]
BMW – 328i	[1996–2005]
BMW - 330ci	[1996–2005]
BMW – 330xi	[1996–2005]
BMW – 530i	[1997–2003]

MAKE / MODEL	YEAR RANGE
BMW – 540i	[1997–2003]
BMW - 740i	[1995–2000]
BMW – 745i	[2002–2004]
BMW – X3	[1990–2003]
BMW – X5	[2005–2006]
BMW – Z3	[1996–2005]
BMW – Z4	[1996–2005]
BMW – Z8	[2001]



MAKE / MODEL	YEAR RANGE
Land Rover – Discovery	[1999–2004]
Land Rover – Range Rover	[1995–2004]





• M52 x 3 Threads

THE BMW 350 MAY NOT FIT ON [2014-JANUARY 2016] BMW 750I. THE TANK HAS DIFFERENT THREADS AND BMW SUPERSEDED THE TANK TO A NEW CORRECTED PART NUMBER. CARS MADE AFTER JANUARY OF 2016 HAVE THE SUPERSEDED TANK AND THE BMW 350 WORKS PERFECTLY.

MAKE / MODEL	YEAR RANGE
BMW – 128i	[2008–2013]
BMW – 135i	[2008–2013]
BMW - 135is	[2013]
BMW – 230i	[2017–2018]
BMW – 320i	[2012–2013]
BMW – 323i	[2006–2011]
BMW - 325Ci	[2006]
BMW – 325i	[2006]
BMW – 325xi	[2006]
BMW - 328Cic	[2007–2012]
BMW – 328i	[2007–2018]
BMW – 328xi	[2007–2012]
BMW - 330Ci	[2006]
BMW - 330e	[2017–2018]
BMW – 330i	[2006–2018]
BMW – 330xi	[2006]
BMW - 335Cic	[2007–2012]
BMW – 335d	[2009–2011]
BMW – 335i	[2007–2013]

MAKE / MODEL	YEAR RANGE
BMW - 335is	[2011–2013]
BMW – 335xi	[2007–2012]
BMW – 430i	[2017–2019]
BMW - 525	[2004–2005]
BMW – 525i	[2007]
BMW – 525xi	[2007]
BMW – 528i	[2009–2013]
BMW – 528xi	[2008–2010]
BMW - 530	[2004–2005]
BMW - 530e	[2012–2013]
BMW – 530i	[2006–2018]
BMW – 530xi	[2006–2007]
BMW – 535d	[2014–2015]
BMW – 535i	[2008–2016]
BMW – 535xi	[2008–2010]
BMW – 540i	[2017–2018]
BMW - 545	[2004–2005]
BMW - 550	[2006–2007]
BMW – 550i	[2008–2013]

MAKE / MODEL	YEAR RANGE
BMW – 640i	[2012–2018]
BMW - 645Ci	[2004–2005]
BMW – 650i	[2006–2018]
BMW - 740e	[2016–2018]
BMW – 740i	[2008–2015]
BMW - 750i	[2009–2018] *SEE NOTE
BMW – 750Li	[2009–2013]
BMW – X3	[2007–2018]
BMW – X4	[2016–2018]
BMW – X5	[2007–2018]
BMW – Z4	[2009–2016]














MAKE / MODEL	YEAR RANGE
Acura – MDX	[2018]
Acura – Clarity	[2018]
Chevrolet – Metro	[1998–1998]
Chevrolet – Prizm	[1998–1998]
Chevrolet – Tracker	[1998–1998]
Chrysler – Colt	[1993]
Chrysler – Summit	[1993–1995]
Honda – Accord	[1994–2016]
Honda – Civic	[1994–2015]
Honda – CR-V	[2014]
Honda – Element	[2008]
Honda – Odyssey	[1999–2018]
Honda – Pilot	[2003–2016]
Honda – S2000	[2008]
Isuzu – All Models	[1998–1999]
Lexus – ES 300	[1992–1993]
Lexus – GS 300	[1993–1999]
Lexus – GS 400	[1989–1999]

MAKE / MODEL	YEAR RANGE
Lexus – RX 300	[2000]
Mazda – 5	[2007]
Mazda – Protege	[2000–2003]
Mitsubishi – Diamante	[1996–1998]
Mitsubishi – Eclipse Spyder	[2002]
Mitsubishi – Galant	[1994–2003]
Mitsubishi – Mirage	[1993–1999]
Scion – FR-S	[2013–2016]
Scion – tC	[2008]
Subaru – (6-cyl.) models	[2001–2016]
Subaru – Ascent	[2019]
Subaru – BRZ	[2013–2017]
Subaru – Forester	[2016]
Subaru – Impreza	[2006–2018]
Subaru – Legacy	[2016]
Subaru – Outback	[2006-2018]
Subaru – Tribeca B9	[2006]
Subaru – XV Crosstrek	[2013–2018]

MAKE / MODEL	YEAR RANGE
Toyota – 4Runner	[2001–2019]
Toyota – Avalon	[2011–2016]
Toyota – Camry	[1992–2019]
Toyota – Celica	[1990–1998]
Toyota – Corolla	[1993–2016]
Toyota – Echo	[2000–2003]
Toyota – FJ Cruiser	[2007–2014]
Toyota – Highlander	[2001–2019]
Toyota – Matrix	[2003-2013]
Toyota – Paseo	[1992–1999]
Toyota – RAV4	[1996–2016]
Toyota – Sequoia	[2001–2003]
Toyota – Sienna	[2010–2019]
Toyota – Supra	[1992–1997]
Toyota – Tacoma	[2006–2016]
Toyota – Tercel	[1991–1999]
Toyota – Tundra	[2000–2019]
Toyota – Venza	[2011–2016]
Toyota – Yaris	[2011–2016]





• M34 x 3 Threads

MAKE / MODEL	YEAR RANGE
Lexus – LS 460	[2007–2013]
Lotus – Elise	[2005]
Scion – tC	[2011–2016]
Scion – xB	[2011–2013]

MAKE / MODEL	YEAR RANGE
Toyota – Celica GTS-S	All Applicable
Toyota – Highlander	[2006–2010]
Toyota – MR2 Spyder	All Applicable
Toyota – Prius	[2001–2016]
Toyota – RAV4	[2006–2018]







#FZ163 Cooling System Adapter


MAKE / MODEL	YEAR RANGE
Porsche – Boxster	[2007–2012]
Porsche – Cayman	[2005–2013]







• M48 x 3 Threads



MAKE / MODEL	YEAR RANGE
Audi – Models with male threads on exp. tank	[1975–1993]
Audi – A8	[1999]

MAKE / MODEL	YEAR RANGE
Audi – S8	[2001]
Kenworth – Heavy Truck	[2007–2008]
Porsche – 911	[1999–2008]
Porsche – Boxster	[2003]

MAKE / MODEL	YEAR RANGE
Volkswagen – Models with male threads on exp. tank	[1975–1993]
Volvo trucks – V670	[2005]
Volvo trucks – VN430	[2005]



MAKE / MODEL	YEAR RANGE
Autocars – Trucks	[2001–2016]
BMW - 330e	[2017–2018]
BMW – 430i	[2017–2019]
BMW - 530e	[2017–2018]
BMW - 740e	[2017–2018]
BMW – i3	[2014–2018]
BMW – i8	[2014–2018]
BMW – X5 xdrive 40e	[2017–2018]





MAKE / MODEL	YEAR RANGE
BMW – V8 Twin (turbo) Intercooler Coolant Reservoir	[2008–2017]
Ferrari – 350 series with threaded tank	All Applicable
Ferrari – 450 series with threaded tank	All Applicable
Ferrari – 550 series with threaded tank	All Applicable
Fiat - 500	[2012–2016]
Jeep – All Models	[1987–1990]

MAKE / MODEL	YEAR RANGE
Land Rover – Freelander	[2002–2004]
Mini – Mini Cooper	[2007–2016]
RAM Trucks – Promaster Van	[2014–2018]
Saab - 9000	[1986–1998]
Sterling – All Models	[1987–1991]
Volvo – Passenger Vehicles (with threaded neck)	[1978–2006]
Volvo – Volvo Trucks (M47 x 3 threads)	[1978–2006]

YEAR RANGE







#FZ32A **Tank Adapter**

• M52 x 2.5 Threads





Cap Adapter

MAKE / MODEL

• M52 x 2.5 Threads



MAKE / MODEL	YEAR RANGE
Aston Martin – DB9	[2016]
Aston Martin – Rapide	[2016]
Aston Martin – Rapide S	[2016]
Aston Martin – Vanquish	[2016]
Aston Martin – Vantage	[2016]
Dodge – Dart 2.4L	[2016]
Ford – Crown Victoria	[1994–2003]
Ford – E-Series van	[1995–2003]
Ford – Edge	[2013–2015]
Ford – Escape	[2007–2012]
Ford – Excursion	[2000–2004]
Ford – Expedition	[2003–2016]
Ford – Explorer	[2002–2018]
Ford – F-150	[2004–2014]
Ford – F-250	[2002–2016]
Ford – F-250 6.7L Power Stroke	[2016–2018]
Ford – Five Hundred	[2005]
Ford – Freestyle	[2005]

Ford – Flex	[2011]
Ford – Focus	[2006]
Ford – Fusion	[2010–2011]
Ford – Mustang	[1996–2014]
Ford – Taurus	[1996–2006]
Ford – Thunderbird	[1993–2005]
Ford – Windstar	[2002–2003]
Freightliner – Cascadia	[2008]
Freightliner – Columbia	[2008]
International – 6.4L Diesel	[2012]
International – Navistar VT 365	[2007]
International – with 466 engine	[1994–2002]
Jaguar – F-Type	[2016]
Jaguar – S Type	[2003–2008]
Jaguar – X Type	[2003–2008]
Jaguar – XF	[2009–2015]
Jaguar – XJ	[2003–2015]
Jaguar – XK	[2003–2013]

MAKE / MODEL	YEAR RANGE
Land Rover – Discovery Sport	[2016]
Land Rover – LR3	[2005–2014]
Land Rover – Range Rover	[2016]
Land Rover – Range Rover Sport	[2006–2016]
Lincoln – Mark VIII	[1993–1998]
Lincoln – Navigator	[1998]
Lincoln – Towncar	[1993–1999]
Mercedes – ML 320	[1998–2005]
Mercedes – ML 430	[1998–2005]
Mercury – Cougar	[1995]
Mercury – Crown Victoria	[1993–2003]
Mercury – Grand Marquis	[1993–2003]
Mercury – Sable	[1996–2003]
Nissan – Armada	[2005–2015]
Nissan – Titan	[2004–2015]







#FZ35ATank Adapter

• M52 x 2.5 Threads






#FZ36Cap Adapter

MAKE / MODEL

• M52 x 2.5 Threads



MAKE / MODEL	YEAR RANGE	
Aston Martin – DB9		[2016]
Aston Martin – Rapide	;	[2016]
Aston Martin – Rapide	S	[2016]
Aston Martin – Vanqui	sh	[2016]
Aston Martin – Vantag	е	[2016]
Buick – Encore		[2014]
Buick - Lacrosse		[2011–2014]
Buick – Roadmaster		[1994–1996]
Buick - Skylark		[1992–1998]
Cadillac – ATS		[2014–2015]
Cadillac – CTS		[2003–2015]
Cadillac – CTS4		[2016]
Cadillac – ELR Coupe		[2014]
Cadillac – Escalade		[1999–2015]
Cadillac – Escalade Es	SV	[2014–2015]
Cadillac – Fleetwood		[1994–1996]
Cadillac – Seville		[1998–2004]
Cadillac – SRX		[2014–2015]
Cadillac – XTS Sedan		[2014–2015]
Chevrolet – Aveo		[2008–2011]
Chevrolet – Beretta		[1992–1996]
Chevrolet – Camaro		[1999–2015]
Chevrolet – Caprice		[1995–1996]
Chevrolet – Cavalier		[1995–2005]
Chevrolet - Cobalt		[2005–2010]
Chevrolet – Corsica		[1992–1996]
Chevrolet – Corvette		[1999–2015]
Chevrolet – Cruze		[2011–2018]
Chevrolet – Express		[2010–2015]
Chevrolet – Impala SS		[1994–1996]

Chevrolet – Malibu	[1997–2018]
Chevrolet – Metro	[1999–2001]
Chevrolet – Prizm	[1999–2002]
Chevrolet – Silverado 1500	[1999–2018]
Chevrolet – Silverado 2500 (gas)	[1999–2016]
Chevrolet – Suburban	[2000–2015]
Chevrolet - Tahoe	[1999–2015]
Chevrolet - Tracker	[1999–2004]
Chevrolet – Trailblazer	[2001–2009]
Chevrolet – Trax	[2015]
Chevrolet – Van	[2007–2011]
Chrysler – 200	[2015]
Chrysler – Pacifica	[2017]
Freightliner – Diesel truck	[2004–2004]
GMC – Envoy	[2002–2002]
GMC - Sierra	[2014]
GMC - Sierra 1500	[1999–2015]
GMC - Sierra 2500	[1999–2003]
GMC – Sierra 2500 HD	[2015]
GMC - Sierra 3500	[2014]
GMC – Sierra 3500 HD Denali	[2014]
GMC – Sierra 3500 6.6L Duramax DSL	[2016]
GMC – Terrain	[2014]
GMC – Terrain Denali	[2014]
GMC – Yukon	[1999–2015]
Jaguar – F-Type	[2016]
Jaguar – S Type	[2003–2008]
Jaguar – X Type	[2003–2008]

YEAR RANGE

MAKE / MODEL YEAR RANGE	<u> </u>
Jaguar – XF	[2009–2015]
Jaguar – XJ	[2003–2015]
Jaguar – XK	[2003–2013]
Jeep – Grand Cherokee	[2016–2017]
Land Rover – Discovery Sport	[2016]
Land Rover – Freelander	[2005]
Land Rover – LR3	[2005–2014]
Land Rover – Range Rover	[2016]
Land Rover – Range Rover Sport	[2006–2016]
Oldsmobile – Achieva	[1992–1998]
Oldsmobile – Alero	[1999]
Oldsmobile – Aurora	[1995–1999]
Oldsmobile – Cutlass	[1997–1998]
Oldsmobile – Intrigue	[1999–2000]
Pontiac – G6	[2005–2008]
Pontiac – Grand Am	[1992–1999]
Pontiac – Grand Prix	[2006]
Pontiac – Sunfire	[1995–1999]
RAM Trucks – 1500 3.0L EcoDiesel	[2014–2017]
RAM Trucks – 2500 6.7L Cummins	[2013–2018]
RAM Trucks – 3500 6.7L Cummins	[2013–2018]
Saab - 93	[2003–2004]
Saturn - All Models	[1990–2005]









#FZ41 **Tank Adapter**

• M63 x 3 Threads

YEAR RANGE
[2006–2018]
[1996–2018]
[2008–2018]
[1998–2018]
[2012–2018]
[2006–2018]
[2001–2003]
[2016–2018]
[2009–2018]
[2007–2018]

YEAR RANGE
[2016–2018]
[2000–2018]
[2008–2018]
[2016–2018]
[2000–2015]
[2006–2013]
[2012–2015]
[2004–2013]
[2018]
[1999–2015]

MAKE / MODEL	YEAR RANGE
Volkswagen – CC	[2009–2015]
Volkswagen – EOS	[2007–2015]
Volkswagen – Golf	[1999–2018]
Volkswagen – GTI	[2008–2016]
Volkswagen – Jetta	[2015–2018]
Volkswagen – Passat	[1998–2018]
Volkswagen – Rabbit	[2006–2009]
Volkswagen – Tiguan	[2009–2018]
Volkswagen – Touareg	[2004–2015]







#FZ47 **Tank Adapter**

• M49 x 2.5 buttress Threads

MAKE / MODEL	YEAR RANGE
Ford – C-Max	[2014–2016]
Ford – EcoSport	[2018–2018]
Ford – Edge	[2013–2018]
Ford – Escape	[2013–2018]
Ford – Expedition	[2015–2018]
Ford – F-150	[2015–2018]
Ford – Fiesta	[2011–2018]
Ford – Focus	[2012–2018]
Ford – Fusion	[2013–2018]
Ford – Mustang	[2016–2018]

MAKE / MODEL	YEAR RANGE
Ford – Transit 150 3.5L (turbo)	[2015–2016]
Ford – Transit 150 3.2L (Diesel)	[2015]
Ford – Transit 250 3.7L	[2015]
Ford – Transit Connect	[2014–2015]
Land Rover – LR2	[2007–2015]
Land Rover – Range Rover Evoque	[2012–2017]
Mazda – 3	[2004–2013]
Mazda – 6	[2004–2009]
Volvo – S40	[2004–2010]
Volvo – S60	[2016–2019]

MAKE / MODEL	YEAR RANGE
Volvo – S80	[2008–2016]
Volvo – S90	[2016–2019]
Volvo – V50	[2005–2010]
Volvo – V60	[2010–2019]
Volvo – V90	[2016–2019]
Volvo – XC40	[2019]
Volvo – XC60	[2010–2019]
Volvo – XC70	[2008–2016]
Volvo – XC90	[2016–2019]







#FZ55Tank Adapter

• M46 x 2.5mm Threads

MAKE / MODEL	YEAR RANGE
Dodge – Sprinter	[2007–2009]
Mercedes – Sprinter	[2010–2019]

Mercedes - Metris [2018-2019]







#M034919

Tank Adapter

- M62 x 4mm Threads
- Applicable to 1996-2019 models
- For ML models [1998-2005], see #FZ35A

MAKE / MODEL	YEAR RANGE
Mercedes – AMG	All Applicable
Mercedes – C class	All Applicable
Mercedes – CL class	All Applicable
Mercedes – CLK class	All Applicable

MAKE / MODEL	YEAR RANGE
Mercedes – CLS class	All Applicable
Mercedes – E class	All Applicable
Mercedes – G class	All Applicable
Mercedes – ML 164	All Applicable

MAKE / MODEL	YEAR RANGE
Mercedes – R class	All Applicable
Mercedes – S class	All Applicable
Mercedes – SL class	All Applicable
Mercedes – SLK class	All Applicable



I DIDN'T KNOW WHAT
TO SAY, SO I HUNG UP.

AT AST THERE ARE
REAL PEOPLE
ANSWERING THE
PHONES!







#2124 24mm Oil Filter Socket

• 3/8" Drive

MAKE / MODEL	YEAR RANGE
BMW - 545	[2004–2005]
BMW - 550	[2006–2010]
BMW - 645Ci	[2004–2005]
BMW – 650i	[2006–2010]
BMW – 745i	[2002–2005]
BMW – 745Li	[2002–2005]
BMW – 750i	[2006–2008]
BMW – 750Li	[2006–2008]

MAKE / MODEL	YEAR RANGE
BMW – Alpina B7	[2007–2008]
BMW – X5	[2004–2010]
Chevrolet – Trax	[2015–2015]
Chrysler – 200	[2011–2016]
Chrysler – 300	[2011–2016]
Chrysler – Town & Country	[2011–2016]
Dodge – Avenger	[2011–2016]
Dodge –Challenger	[2011–2016]

MAKE / MODEL	YEAR RANGE
Dodge -Charger	[2011–2016]
Dodge Durango	[2011–2016]
Dodge –Grand Caravan	[2011–2016]
Dodge –Journey	[2011–2016]
Jeep – Grand Cherokee	[2011–2016]
Jeep – Wrangler	[2012–2017]
Maserati – Ghibli	[2013–2013]
Saturn – Astra	[2008–2009]



#2127 27mm Oil Filter Socket

• 3/8" Drive

MAKE / MODEL	YEAR RANGE
Kia – Sedona (6-cyl.)	[2014–2015]
BMW - 535d	[2014–2015]
BMW – 740Ld xDrive	[2015]
BMW - X5 35d xDrive	[2014–2015]
Fiat - 500	[2012–2013]
Hyundai – Azera	[2009–2012]

MAKE / MODEL	YEAR RANGE
Hyundai – Equus	[2011–2013]
Hyundai – Genesis	[2008–2013]
Hyundai – Santa Fe 3.3L	[2009]
Hyundai – Sonata 3.3L	[2009]
Hyundai – Veracruz	[2007–2013]
Kia – Amanti	[2007-2009]

MAKE / MODEL	YEAR RANGE
Kia – Borrego	[2009–2012]
Kia – Cadenza	[2014–2018]
Kia – Sedona (6-cyl.)	[2016–2018]
Kia – Sorento	[2007–2018]
Mercedes - C 300 (204)	[2015]
Mini – Cooper	[2007–2015]







#2132 32mm Oil Filter Socket

• 3/8" Drive

MAKE / MODEL	YEAR RANGE
Audi – A4	[2017]
Audi – Q3	[2015–2016]
Audi – S3	[2015–2016]
BMW – 230i	[2017–2018]
BMW – 330i	[2017–2018]
BMW – 335d	[2009–2011]
BMW – 340i	[2017–2018]
BMW – 430i	[2017–2018]

MAKE / MODEL	YEAR RANGE
BMW – 530i	[2017–2018]
BMW – 540i	[2017–2018]
BMW – 740i	[2017–2018]
BMW - M240i	[2017–2018]
BMW – X1	[2016–2018]
BMW – X5 35d	[2009–2013]
Chevrolet – Cobalt	[2007–2010]
Chevrolet – Impala	[2014]

MAKE / MODEL	YEAR RANGE
Chevrolet – Malibu	[2007-2014]
Land Rover – Range Rover 3.0L Diesel	[2016]
Maserati – Quattroporte	[2013–2014]
Saab – 9-3	[2003]
Saturn – Ion	[2005]
Volkswagen – Golf 2.0 TDI	[2011–2016]
Volkswagen – Jetta 2.0 TDI	[2011–2016]



#2136 36mm Oil Filter Socket

• 3/8" Drive

MAKE / MODEL	YEAR RANGE
Audi – A6 3.0 (turbo)	[2014–2016]
Audi – Q7	[2007–2016]
BMW – M52 Engine	[1994–2000]
BMW - M54 Engine	[2000–2005]
BMW – M60 Engine	[1992–1996]
BMW - M62 Engine	[1994–2005]
BMW – M70 Engine	[1988–1996]
BMW – M73 Engine	[1993–2002]

MAKE / MODEL	YEAR RANGE
Ford – F-250 6.0L (turbo diesel)	[2004]
Ford – F-350 6.0L (turbo diesel)	[2004]
Mercedes – E300 diesel	[1996–1999]
Mini – Cooper	[2002–2006]
Porsche – 911	[2009–2016]
Porsche – Boxster	[2009–2016]
Porsche – Cayenne	[2009–2016]
Porsche – Panamera	[2009–2016]

MAKE / MODEL	YEAR RANGE
Volkswagen – Corrado	
Volkswagen – Eurovan	
Volkswagen – R32	[2004]
Volkswagen – Touareg	[2002–]
Volvo – 3.0L	[2007–2014]
Volvo – 3.2L engine	[2007–2014]

APPLICATION CHARTS | FILTER WRENCHES (AS)







• 14 Flat, 22mm Hex Drive

California Residents: Proposition 65 WARNING. See page 125 for info.

MAKE / MODEL	YEAR RANGE
Audi – 4000	All Applicable
Audi – 5000	All Applicable
BMW – M44 engine	All Applicable
Dodge – Sprinter (gas engine)	[2003–2006]
Mercedes – C 350	[2015]
Mercedes – C 400	[2015]

MAKE / MODEL	YEAR RANGE
Mercedes – E 250 2.1L (turbo diesel)	[2014–2016]
Mercedes – GLK 250 2.1L (turbo diesel)	[2014]
Mercedes – ML 250 2.1L (turbo diesel)	[2015]
Mercedes – Sprinter 2.1L (turbo diesel)	[2014–2016]

MAKE / MODEL	YEAR RANGE
Porsche – 924	All Applicable
Porsche – 944	All Applicable
Volkswagen – Beetle	[2005–2014]
Volkswagen – Dasher	All Applicable
Volkswagen – Fox	All Applicable
Volkswagen – Golf	All Applicable
Volkswagen – Jetta	[2005–2014]
Volkswagen – Scirocco	All Applicable
Volkswagen – Rabbit	[1975–1984]





#BM1276

76mm Oil Filter Wrench

• 3/8" Drive

MAKE / MODEL	YEAR RANGE
BMW – i3 "Range Extender"	[2014-2018]
BMW - Motorcycles	[2007-2016]
Mercedes – Factory Oil Filter with 12 flutes	






#HD1674

Oil Filter Wrench for Harley-Davidson

MAKE / MODEL **YEAR RANGE** Harley-Davidson Motorcycles [1980-2016]







#JA19015 90mm Oil Filter Wrench

• 15 Flats, 3/8" Drive

MAKE / MODEL	YEAR RANGE
Jaguar – XF	[2010–2018]
Jaguar – XFR	[2010–2016]
Jaguar – XJ	[2010–2018]
Jaguar – XJL	[2010–2016]
Jaguar – XK	[2010–2016]
Jaguar – XKR	[2010–2016]

MAKE / MODEL	YEAR RANGE
Land Rover – LR4	[2010–2018]
Land Rover – Range Rover	[2010–2018]
Land Rover – Range Rover Sport	[2010–2018]





#JAS6514 65mm Oil Filter Wrench

• 14 Flat, 3/8" Drive

MAKE / MODEL	YEAR RANGE
Honda – All Models (except S2000)	[1990–2018]
Infiniti – M35	[2004–2007]
Infiniti – M45	[2004–2007]
Jaguar – F-Pace	[2017]
Jaguar – XE	[2017]
Jaguar – XF	[2017]
Kawasaki – Motorcycle	[1990–2009]
Land Rover – Range Rover Evoque	[2018]

MAKE / MODEL	YEAR RANGE
Mazda-3	[2012–2018]
Mazda-6	[2014–2018]
Mazda CX-3	[2016–2018]
Mazda CX-5	[2013–2018]
Mazda MX-5 Miata	[2016–2018]
Nissan – 350Z	[2002–2009]
Nissan – 370Z	[2010–2018]
Nissan – Altima	[1997–2018]
Nissan – Armada	[2004–2018]
Nissan – Cube	[2009–2014]
Nissan – Frontier	[1997–2018]
Nissan – GT-R	[2008–2018]

MAKE / MODEL	YEAR RANGE
Nissan – Juke	[2011–2018]
Nissan – Maxima	[1994–2018]
Nissan – Murano	[2002–2018]
Nissan – Pathfinder	[1995–2018]
Nissan – Quest	[2006–2018]
Nissan – Rouge	[2008–2018]
Nissan – Sentra	[2001–2018]
Nissan – Titan	[2003–2018]
Nissan – Versa	[2006–2018]
Nissan – Xterra	[2002–2016]
Yamaha – Motorcycle	[1990–2009]

APPLICATION CHARTS | FILTER WRENCHES (S)









• 14 Flat, 22mm Hex Drive

California Residents: Proposition 65 WARNING. See page 125 for info.

MAKE / MODEL	YEAR RANGE
Audi – A4 2.0 (turbo)	[2009–2016]
Audi – Q5 2.0 (turbo)	[2012–2016]
BMW Motorcycle – F650	All Applicable
BMW Motorcycle – F800	All Applicable
BMW Motorcycle – K75	All Applicable
BMW Motorcycle – K100	All Applicable
BMW Motorcycle – K1100	All Applicable
BMW Motorcycle – K1200GT	[2003–2004]
BMW Motorcycle – K1200LT	All Applicable
BMW Motorcycle – K1200R	All Applicable
BMW Motorcycle – K1200RS	[1996–2004]
BMW Motorcycle – K1200S	All Applicable
BMW Motorcycle – K1300	All Applicable
BMW Motorcycle – R850	All Applicable
BMW Motorcycle – R1100	All Applicable
BMW Motorcycle – R1150	All Applicable
BMW Motorcycle – R1200C	All Applicable
BMW Motorcycle – R1200CL	All Applicable
BMW Motorcycle – R1200GSW	[2013–2014]
BMW Motorcycle – S1000RR	All Applicable
Dodge – Avenger	[2012–2013]
Dodge – Caliber	[2012]
Dodge – Dart	[2013]
Dodge – Sprinter (gas engines)	[2003–2012]
Ford – Escape	[2006–2008]
Ford – Fusion	[2006–2008]

MAKE / MODEL	YEAR RANGE
Ford – Focus	[2004–2007]
Jaguar – XE (2.0L Turbo)	[2017]
Jaguar – XF (2.0L Turbo)	[2017]
Land Rover – Range Rover Evoque	[2013–2017]
Mazda – 3	[2004–2009]
Mazda – 5	[2006–2011]
Mazda – 6	[2003–2009]
Mazda – CX-7	[2007–2009]
Mazda – Mazdaspeed 3	[2007–2009]
Mazda – Mazdaspeed 6	[2006–2007]
Mercedes – M104	[1989–1999]
Mercedes – M119 engine	[1989–1999]
Mercedes – M111 engine	[1992–2003]
Mercedes – M112 engine	[1998–2006]
Mercedes – M113 engine	[1997–2010]
Mercedes – M120 engine	[1991–2002]
Mercedes – M137 engine	[1998–2002]
Mercedes – M155 engine	[2004–2006]
Mercedes – M272 engine	[2005–2015]
Mercedes – M273 engine	[2006–2015]
Mercedes – M275 engine	[2003–2014]
Mercedes – M276 engine	[2010–2015]
Mercedes – M285 engine	[2003–2012]
Mercedes – Sprinter (gas)	[1998–2015]
Porsche – 911	[1999–2008]
Porsche – Boxster	[1997–2008]

MAKE / MODEL	YEAR RANGE
Porsche – Caymen	[2005–2008]
Toyota – 4Runner	[1985–2002]
Toyota – Avalon	[1995–2002]
Toyota – Camry [V6]	[1988–2004]
Toyota – Highlander [V6]	[2001–2010]
Toyota – Previa	[1991–1997]
Toyota – Sienna	[1998–2007]
Toyota – Solara [V6]	[1999–2009]
Toyota – Supra	[1979–1998]
Toyota – T100	[1993–1998]
Toyota – Tacoma	[1995–2012]
Toyota – Tundra	[2000–2004]
Volkswagen – Beetle 2.5L	[2005–2014]
Volkswagen – CC	[2009–2013]
Volkswagen – EOS	[2009–2013]
Volkswagen – Golf	[1999–2005]
Volkswagen – GTI	[2008]
Volkswagen – Jetta 1.4 (turbo)	[2016]
Volkswagen – Tiguan	[2009–2016]







• 14 Flat, 22mm Hex Drive

California Residents: Proposition 65 WARNING. See page 125 for info.

MAKE / MODEL	YEAR RANGE
Dodge – Sprinter	[2007–2009]
Freightliner – Sprinter	[2007–2018]
Jeep – Grand Cherokee	[2007–2008]
Mercedes – E 320 (BLUETEC)	[2007–2009]

MAKE / MODEL	YEAR RANGE
Mercedes – E 350 (BLUETEC)	[2011–2015]
Mercedes – GL 320 (BLUETEC)	[2009]
Mercedes – GL 350 (BLUETEC)	[2010–2015]
Mercedes – ML 320 (BLUETEC)	[2009]

MAKE / MODEL	YEAR RANGE
Mercedes – ML 350 (BLUETEC)	[2010–2015]
Mercedes – R 320 (BLUETEC)	[2009]
Mercedes – R 350 (BLUETEC)	[2010–2015]
Mercedes – S 350 (BLUETEC)	[2012–2015]
Mercedes – Sprinter	[2007–2017]





#SU8015 **80mm Oil Filter Wrench**

• 15 Flats, 3/8" Drive

MAKE / MODEL	YEAR RANGE
Hyundai – Accent	[1995–2013]
Hyundai – Elantra	[1992–2013]
Hyundai – Excel	[1986–1994]
Hyundai – Genesis Coupe 2.0L	[2008–2012]
Hyundai – S Coupe	[1992–1994]
Hyundai – Santa Fe 2.4L	[2000]
Hyundai – Santa Fe 2.7L	[2000–2009]
Hyundai – Sonata	[1992–2012]
Hyundai – Tiburon	[2001–2008]
Hyundai – Tucson	[2004–2012]
Hyundai – Veloster	[2011–2013]
Hyundai – XG300	[2000–2005]

MAKE / MODEL	YEAR RANGE
Hyundai – XG350	[2000–2005]
Kia – Amanti	[2004–2006]
Kia – Forte	[2010–2018]
Kia – Niro	[2017–2018]
Kia – Optima	[2001–2018]
Kia – Rio	[2006–2012]
Kia – Rondo	[2007–2009]
Kia – Sorento	[2003–2018]
Kia – Soul	[2010–2018]
Kia – Spectra	[2004–2009]
Kia – Sportage	[2005–2018]
Nissan – Sentra	[1999]

MAKE / MODEL	YEAR RANGE
Scion – FR-S	[2013–2016]
Subaru – BRZ	[2013–2018]
Subaru – Forester	[2011–2016]
Subaru – Impreza WRX	[2016]
Subaru – Legacy (6-cyl.)	All Applicable
Subaru – Outback (6-cyl.)	All Applicable
Subaru – Tribeca	All Applicable
Subaru – WRX	[2015–2018]
Subaru – All 6-cyl. Engines	All Applicable









#TOY640 **64mm Oil Filter Wrench**

• 14 Flats, 24mm Hex Drive

California Residents: Proposition 65 WARNING. See page 125 for info.

MAKE / MODEL	YEAR RANGE
Lexus – CT 200h	[2011–2016]
Lexus – ES 350	[2007–2018]
Lexus – GS 300	[2006–2018]
Lexus – GS 350	[2007–2018]
Lexus – GS 450h	[2007–2018]
Lexus – GS 460	[2008–2011]
Lexus – GX 460	[2010–2018]
Lexus – HS 250h	[2010–2013]
Lexus – IS 250	[2006–2016]
Lexus – IS 250 C	[2010–2016]
Lexus – IS 350	[2006–2016]
Lexus – IS 350 C	[2010–2016]
Lexus – IS F	[2008–2014]
Lexus – LS 460	[2007–2016]

MAKE / MODEL	YEAR RANGE
Lexus – LS 600h	[2008–2016]
Lexus – LX 570	[2008–2018]
Lexus – RX 350	[2007–2018]
Lexus – RX 450h	[2010–2018]
Scion – tC	[2005–2016]
Scion – xA	[2004–2006]
Scion – xB	[2004–2016]
Scion – xD	[2008–2013]
Toyota – 4Runner	[2010–2019]
Toyota – Avalon	[2005–2019]
Toyota – Camry	[1983–2019]
Toyota – Corolla	[1983–2019]
Toyota – Echo	[2000–2005]
Toyota – FJ Cruiser	[2007–2014]

MAKE / MODEL	YEAR RANGE
Toyota – Highlander	[2001–2019]
Toyota – Matrix	[2003–2014]
Toyota – MR2	[1985–2005]
Toyota – Paseo	[1992–1997]
Toyota – Prius	[2001–2019]
Toyota – RAV4	[1996–2019]
Toyota – Sequoia	[2009–2019]
Toyota – Sienna	[2007–2019]
Toyota – Solara	[1999–2008]
Toyota – Tundra	[2007–2019]
Toyota – Venza	[2009–2016]
Toyota – Yaris	[2006–2019]



#TOY647LG 64mm Oil Filter Wrench

• 14 Flats, 3/8" Drive

MAKE / MODEL

YEAR RANGE

Toyota - V6 and V8 models

[2005-2019]







#TOY730 73mm Oil Filter Wrench

• 14 Flat, 3/8" Drive

California Residents: Proposition 65 WARNING. See page 125 for info.

MAKE / MODEL	YEAR RANGE
Lexus – ES 250	[1990–1991]
Lexus – ES 300	[1992–2003]
Lexus – ES 300h	[2013]
Lexus – ES 330	[2004–2006]
Lexus – GS 300	[1993–2005]
Lexus – GS 400	[1998–2000]
Lexus – GS 430	[2001–2004]
Lexus – GX 470	[2004–2009]
Lexus – IS 300	[2001–2005]
Lexus – LS 400	[1990–2000]

MAKE / MODEL	YEAR RANGE
Toyota – FJ Cruiser 4.0L	[2007–2010]
Toyota – Land Cruiser	[1993–2007]
Toyota – Sequoia	[2001–2009]
Toyota – Tacoma	[2005–2013]
Toyota – Tundra	[2000–2010]





#V410

86.5mm Oil Filter Wrench

• 16 Flat, 22mm Hex Drive

California Residents: Proposition 65 WARNING. See page 125 for info.

MAKE / MODEL	YEAR RANGE
BMW - [N20 engine]	[2011–2017]
BMW - [N52 engine]	[2006–2012]

MAKE / MODEL	YEAR RANGE
BMW – [N54 engine]	[2006–2012]
BMW - [N55 engine]	[2011–2017]

MAKE / MODEL		YEAR RANGE	
	Volvo – All models (exc. 2005 40 & 50 Series)	[1999–2006]	





#VB414Oil Filter Wrench

• 16 Flat, 22mm Hex Drive

California Residents: Proposition 65 WARNING. See page 125 for info.

MAKE / MODEL	YEAR RANGE
Volvo – S60	[2015–2019]
Volvo 2.0L – S80	[2015–2019]

MAKE / MODEL	YEAR RANGE	
Volvo 2.0L – V60	[2015–2019]	
Volvo 2.0L – XC60	[2015–2019]	

MAKE / MODEL	YEAR RANGE
Volvo 2.0L – XC70	[2015–2019]





WARNING:

These products can expose you to chemicals including Hexavalent Chromate, which are known to the State of California to cause cancer and birth defects or other reproductive harm

Hexavalent Chromate

AST Tools with this warning:

#MC240 Window Wrench #JLR0197 Fuel Injector Puller
#MC114 Serpentine Belt Wrenches #MB164251 Fuel Pump Wrench
#SU200T Camshaft Pulley Holder #3307 Fuel Pump Wrench
#3217 Fuel Sender Spanner



WARNING:

These products can expose you to chemicals including Bisphenol A (BpA), which is known to the State of California to cause birth defects or other reproductive harm.

BPA

AST Tools with this warning:

#0FCRY36 Engine Oil Funnel #FUNCRY36 Funnel Adapter #0FGMRD08 Engine Oil Funnel #MW35 Hard Black Wedge Set



WARNING:

These products can expose you to chemicals including Lead and Nickel, which are known to the State of California to cause cancer.

Lead and Nickel

AST Tools with this warning:

#2175 Oil Filter Wrench #T0Y730 Oil Filter Wrench 74mm Oil Filter Wrench #M0219 #VB414 Oil Filter Wrench 84mm Oil Filter Wrench #HD1674 #M0284 Oil Filter Wrench #WSC15 #T0Y640 Oil Filter Wrench Wire Soldering Clamp



WARNING:

These products can expose you to chemicals including Acrylonitrile & Styrene, which are known to the State of California to cause cancer and Butadiene, which is known to the State of California to cause birth defects or other reproductive harm.

ABS

AST Tools with this warning:

#0FFM2012 Engine Oil Funnel #0FH0N1033 Oil Funnel #OFAAGM Angled Funnel Extension #0FSU1042 Subaru Oil Funnel #0FH33 **Funnel Extension** #0FSU42 Subaru Adapter #0FHD35 Oil Funnel #0FT38 **Funnel Extension** #0FHD419 Oil Funnel #0FT0Y1038 Threaded Toyota Oil Funnel



WARNING:

This product can expose you to chemicals including Acrylonitrile & Styrene, which are known to the State of California to cause cancer and Bisphenol A (BpA) & Butadiene, which is known to the State of California to cause birth defects or other reproductive harm.

ABS and BPA

AST Tools with this warning:

#FUN14KIT Oil Funnel Set



WARNING:

These products can expose you to chemicals including Nickel, which are known to the State of California to cause cancer.

Nickel

200-7

AST Tools with this warning:

#BMW2755 Intermediate Spring Tool #BMW5585 Camshaft Bridge



WARNING:

These products can expose you to chemicals including Chromium and Lead, which are known to the State of California to cause cancer.

Chromium and Lead

AST Tools with this warning:

Stud Remover

#201	Stud Puller Set	200-8	Stud Remover	200-7/16	Stud Remover
#201-7	Stud Puller Set	200-10	Stud Remover	200-1/2	Stud Remover
#202	Stud Puller Set	200-12	Stud Remover	200-9/16	Stud Remover
#203	Stud Puller Set	200-1/4	Stud Remover	200-5/8	Stud Remover
200-6	Stud Remover	200-5/16	Stud Remover		

Stud Remover

200-3/8

60 102 70 102 80 102 100 102 200-6 102 200-7 42, 102 200-8 102 200-10 102 200-12 102 200-1/4 102 200-3/8 102 200-3/8 102 200-1/2 102 200-9/16 102 200-9/16 102 201 103 202 103 203 103 205 102 312 102 375 102 437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69, 92, 118	TOOL #	PAGE #
80 102 100 102 120 102 200-6 102 200-7 42, 102 200-8 102 200-10 102 200-12 102 200-1/4 102 200-5/16 102 200-3/8 102 200-1/2 102 200-9/16 102 200-5/8 102 201 103 202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	60	102
100 102 120 102 200-6 102 200-7 42, 102 200-8 102 200-10 102 200-12 102 200-1/4 102 200-5/16 102 200-3/8 102 200-1/2 102 200-9/16 102 200-9/16 102 201 103 202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 625 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	70	102
120 102 200-6 102 200-7 42, 102 200-8 102 200-10 102 200-12 102 200-1/4 102 200-5/16 102 200-3/8 102 200-1/2 102 200-9/16 102 201 103 202 103 203 103 204 102 312 102 375 102 437 102 500 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	80	102
200-6 102 200-7 42, 102 200-8 102 200-10 102 200-12 102 200-14 102 200-5/16 102 200-3/8 102 200-1/2 102 200-9/16 102 200-5/8 102 201 103 202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	100	102
200-7 42, 102 200-8 102 200-10 102 200-12 102 200-1/4 102 200-5/16 102 200-3/8 102 200-1/2 102 200-9/16 102 201 103 202 103 203 103 203 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	120	102
200-8 200-10 102 200-12 102 200-1/4 102 200-5/16 102 200-3/8 102 200-1/2 102 200-1/2 102 200-9/16 102 201 103 202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 103 203 103 250 102 375 102 437 102 500 102 562 102 103 203 203 203 203 203 203 203 203 203 2	200-6	102
200-10 102 200-12 102 200-1/4 102 200-5/16 102 200-3/8 102 200-7/16 102 200-9/16 102 200-9/16 102 201 103 202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-7	42, 102
200-12 102 200-1/4 102 200-3/8 102 200-7/16 102 200-1/2 102 200-9/16 102 201 103 202 103 203 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-8	102
200-1/4 102 200-5/16 102 200-3/8 102 200-7/16 102 200-1/2 102 200-9/16 102 201 103 202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-10	102
200-5/16 102 200-3/8 102 200-7/16 102 200-9/16 102 200-5/8 102 201 103 202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-12	102
200-3/8 102 200-7/16 102 200-1/2 102 200-9/16 102 200-5/8 102 201 103 202 103 203 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-1/4	102
200-7/16 102 200-1/2 102 200-9/16 102 201 103 202 103 203 102 312 102 375 102 437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-5/16	102
200-1/2 102 200-9/16 102 200-5/8 102 201 103 202 103 203 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-3/8	102
200-9/16 102 200-5/8 102 201 103 202 103 203 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-7/16	102
200-5/8 102 201 103 202 103 203 102 312 102 375 102 437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-1/2	102
201 103 202 103 203 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-9/16	102
202 103 203 103 250 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	200-5/8	102
203 103 250 102 312 102 375 102 437 102 500 102 562 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	201	103
250 102 312 102 375 102 437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	202	103
312 102 375 102 437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	203	103
375 102 437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	250	102
437 102 500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	312	102
500 102 562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	375	102
562 102 625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	437	102
625 102 100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	500	102
100-30A 17, 43, 50, 98 201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	562	102
201-7 42, 103 1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	625	102
1018 28 2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	100-30A	17, 43, 50, 98
2017SACP 76, 80 2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	201-7	42, 103
2101 41, 51, 69, 92 2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	1018	28
2124 22, 31, 41, 92, 117 2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	2017SACP	76, 80
2127 10, 22, 30, 46, 51, 92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	2101	41, 51, 69, 92
92, 117 2132 41, 48, 69, 92, 118 2136 30, 41, 51, 56, 69,	2124	22, 31, 41, 92, 117
2136 30, 41, 51, 56, 69,	2127	
	2132	41, 48, 69, 92, 118
	2136	
2175 22, 41, 51, 69, 76, 93, 119	2175	
3035 9, 57, 101, 107	3035	9, 57, 101, 107

TOOL #	PAGE #
3200T-6	72
3200X-4	72
3200X-8	72
3206	54, 82, 105
3217	66
3242	61
3299A	61
3307	66
3316	57, 105
3344A	57, 105
3359	59
3366	60
3391	64
3424	71, 96
3428	59
3462	70, 96
3810	82, 104
3900	83, 98
6300	71, 96
6300T-50	10, 50, 99
6300X-12	71, 96
6300X-14	71, 96
6300X-16	71, 77, 96
6300XL-10	71, 96
6300XL-14	71, 96
6300XL-8	71, 96
6355X-14	70, 97
6500-14	72, 97
6500-17	72, 97
6500T-100	50, 77, 97
6500TL-80	42, 97
6500TPT-100	50, 97
6500X-18	72, 97
6500X-24	72, 97
6500X-30	72, 97
6500X-32	72, 97
6506	72, 97
6814TDI	59
7200	17, 24, 62, 83
7200-4	24, 32

TOOL #	PAGE #
8010	28
8012	28
8013	28
8014	28
8016	22
8021	28, 32
8022	32
8023	28
8024	28
8026	13, 15
8027	32
8028	20
8032	35
23236	41, 70, 92
ALSJ05	82
ALT34018	10, 50, 56, 70, 99
ATF16DSG	65, 87
ATF17CVT	65, 87
ATF101	25, 87
ATF102	41, 87
ATF103	65, 87
ATF104	65, 87
ATF105	44, 65, 87
ATF108V	56, 87
ATF125NIS	14, 87
ATF129	54, 87
ATF175GM	32, 87
ATF180	14, 87
ATFBASIC	14, 41, 76, 83, 86, 107
AFTDRUMONLY	86
ATFEURO8	84
ATFFORD	25, 85
ATFMB	54, 85
ATFMB725	54
ATFSET9	84
ATFSET15	84
ATFSU100	10, 20, 44, 87
ATFSU118	20, 87
ATFTOY118	16, 87
ATFVW5	65, 85

TOOL #	PAGE #
AU40178	68, 95
BFLT60	30, 43, 99
BM1276	40, 92, 106
BMW0062	34
BMW345	34, 49, 110
BMW350	34, 110
BMW377	42, 99
BMW400-1	38
BMW432	43
BMW2026	38
BMW2510	39
BMW2755	37
BMW3028	37
BMW400	38
BMW4053-1	43
BMW4053-2	43
BMW4622	35
BMW5254	38
BMW5346	34
BMW5532	35
BMW5585	37
BMW6119F	35
BMW6208	36
BMW6222	38
BMW7080SAC	35
BMW8390	35
BMW9054	36
BMW9235	38
BMW10160	43, 50, 98
BMW11845	43, 100
BMW11850	36, 98
BMW11860	36, 98
BMW124052	34
BMW124057	34

BMW575190

BMWMC280

CM3021

CM369

CP2015 CRY323

CRY933

CVB15

38

36

74

74 80

24, 95

24, 95

17, 39, 55

TOOL #	PAGE #
EU2009	83
EU2011	83
EU2090	56, 99
F20T	27, 47
F1248	11, 27
F1616-376B	26
F1616-1552	26
F1616T	26
F16393	26
FM2303	11, 27
FM2330	11, 27
FUN14EURO	40, 53, 69, 91
FUN14KIT	90
FUNCRY36	22, 89
FZ22	56, 67, 77, 112
FZ25	23, 34, 49, 56, 77, 108, 112
FZ32A	13, 25, 49, 52, 77, 113
FZ35A	23, 25, 32,77, 114
FZ36	13, 25, 32, 49, 52, 77, 113, 114
FZ41	67, 115
FZ47	11, 25,49, 56, 115
FZ55	23, 77, 116
FZ148	17, 108, 111
FZ163	67
FZ13818	8, 11, 17, 19, 32, 106, 111
GM140	31
GM245	19, 31
H985-19	99
H2223LGT-30	42, 50, 70, 99
H2587	60
H2760	40, 51
H2850-E24	77, 99
HD1674	94, 106, 119
HO10PT	9, 99
HON1419	8
HON37517	8
HONBC26	8
HTLP100	75

TOOL #	PAGE #
JA19015	48, 94, 120
JAS6514	9, 12, 14, 48, 93, 106, 120
JLR20T	47
JLR0197	49
JLR5008	47
JLR5037	48
JLR5038	48
JLR9899	49
M17WLS	50, 100
M17XLWS	50, 100
M0219	12, 15, 22, 30, 40, 48, 51, 69, 93, 106, 121
M0284	22, 51, 76, 93, 122
M0333	54, 105
M0721	53, 95
M820	23, 50, 76, 100
M1020	23, 76, 100
M1620	51
M2000CP	80
M2010ACP	80
M2039	50
M7226	49, 53, 95
M8160	50, 98, 104
M21250	53, 95
M27161	54
M034919	52, 116
M0E24	50, 100
MB4517	51
MB164251	52
MC100	46
MC240	43
MC560	43
MC1216SET	45
MC1400	45
MC1400-1	44
MC1800	45
MC9570	46
MC11419	46
MCB4648	44



TOOL #	PAGE #
MSP1412	13, 20, 30, 42, 55, 100
MVW2050F	51, 66, 80
MW34	82, 105
MW35	82, 105
N512	13, 99
OFAAGM	29, 31, 88
OFAUD1000	40, 53, 55, 68, 76, 91
OFCRY36	22, 89
OFFM2012	12, 29, 48, 88
OFGMRD08	10, 12, 29, 31, 48, 88
OFH33	9, 89
OFHD35	10, 90, 106
OFHD419	90, 106
OFHON1033	9, 12, 14, 23, 29, 48, 89
OFSU42	19, 88
OFSU1042	19, 88
OFT38	16, 89
OFTOY1038	16, 89
OFVW2013	68, 91
S40-300	101
S3054X-10	17, 54, 70, 101
S3054X-12	17, 54, 101
SCP2014	80
SP1412	13, 20, 30 ,42, 55, 101
SPR0558	23, 77, 80
SPR886	24, 77, 95
SR101	103
SU070	20, 101
SU200T	18
SU250	18
SU3625	18
SU6514	19

TOOL #	PAGE #
SU7250	18
SU7500	18
SU8015	10, 19, 93, 122
SU8252	18
T4306	58
T10050	62
T10052	63
T10066	65
T10068A	64
T10100	62
T10107B	70, 101
T10115	61
T10252	62
T10355	64
T10368	61
T10389	57, 105
T10518A	57, 105
T10531	64
T40001-6	63
T40001-7	63
T40009	61
T40011	61
T40026	61
T40028	63
T40057	68
T40058	63
T40069	61
T40079	60
T40149	67
T40196	64
T40243	60
T40267	60
T40271	64
TA18	39, 67
TM1215	16, 46, 52, 108
TM1415	16, 46, 52, 108

TOOL #	PAGE #
TM12125	9, 19
TOY18B	15
TOY105	16, 101
TOY185	17
TOY200	17
TOY211	17
TOY288	16
TOY300	15, 94
TOY640	15, 22, 94, 108, 123
TOY647LG	15, 93, 123
TOY730	15, 94, 124
TOY1914	16
TSE10TP5	99, 107
V410	40, 56, 93, 124
V450	12, 30, 43, 56
V500	55
V3032	47, 55
V5720	56
VB414	56, 94, 124
VTC100	74
VW20T	58
VW87-1	60
VW87-2	60
VW133SI	66
VW4006	63
VW5220	63, 101
VW93005	39, 57, 104
VW10352	63
VW10549	68
WSC15	81, 104
WSFLC	81
WSFLCPLUS	81