



# ATD-3664

## R1234yf Piercing Design Recharge Kit

### Owner's Manual



#### FEATURES

- Charge A/C systems using R1234yf pierce designed cans

#### SAFETY WARNING AND PRECAUTIONS



#### OPERATING INSTRUCTIONS

1. Connect can tap fitting to hose and coupler assembly.
2. Connect refrigerant can to the bottom of can tap, turn counterclockwise.
3. Turn handle clockwise to pierce the refrigerant can.
4. Turn counterclockwise to flow refrigerant.
5. First time use, purge air in hose.
6. Connect coupler to low side of system, refrigerant will flow into the system.
7. Properly discard can when empty.

#### PARTS LIST

| ITEM# | PART#    | DESCRIPTION   |
|-------|----------|---|
| 1     | 85510-YF | R1234yf 1/2" ACME-LH thread piercing design can tap valve |
| 2     | 67534    | R1234yf low side quick coupler 12 mm-F x 14 mm            |
| 3     | 83181    | R1234yf 18" blue hose                                     |