



**Replacement third brake light with emergency warning mode for Ford  
Super Duty trucks 1999-2015.**

Part# FTB01

Your new AtomicLED third brake light will work the same as your factory light in brake light and cargo light mode, only brighter and more efficient. When you turn the warning mode on it will act as a warning light.

**Installation Instructions:**

Remove the two factory screws holding the factory third brake light to the truck, set the two screws aside for later. Remove the factory light and unplug from factory wiring. Plug the factory wiring harness in to your new Atomic third brake light. Next, run a fuse-protected wire from a 12v switch (if your truck does not have aux. up fitter switches, Use the included on/off switch) to the red wire on your new Atomic light. The blue wire is used to change the flash patterns when in warning mode (there are 22 flash patterns). Connect 12v from a fuse protected circuit to the included momentary switch, then from the switch to the blue wire on your new Atomic light. When the light is in warning mode, press the momentary switch to advance to the next pattern. The blue wire does not have to be connected if you do not wish to change the flash pattern. Lastly use the two factory screws to install your new Atomic third brake light to your truck.

Discover a comprehensive collection of custom and factory signal lights on our website.