




**Installation Manual v1.1:  
P/N 202-930-2272  
[Aurora 3000 Turbo](#)  
2003-2007 Dodge 5.9 Cummins**

**Please read all instructions before installation**

1. Removed the factory intake pipe shown in figure 1.



**Figure 1**

2. Remove the intercooler boot coming off of the turbo charger to the intercooler pipe.
3. Loosen the exhaust clamp for the factory turbo and exhaust elbow. Shown in figure 2.



**Figure 2**

4. Remove the oil feed line fitting and drain line fitting from the factory charger.
5. Unbolt the factory turbo from the manifold.
6. With the factory turbo removed you will see two alignment studs in the exhaust elbow shown in figure 3. Using a pair of pliers pull these out to allow fitment of the 3000 and the factory exhaust elbow.




**Figure 3**

7. Bolt up the Aurora 3000 in place with the manifold using the new supplied hardware.



**Figure 4**

8. Tighten back down the oil feed and drain lines. Note: Do not forget to replace the old drain tube gasket with the new supplied gasket.



**Figure 5**




9. Line up the exhaust elbow and Aurora 3000 then tighten the clamp down so secure the exhaust in place.



**Figure 6**


10. Reinstall the factory intercooler pipe and tighten the clamps down.



**Figure 7**

11. Remove the W/G solenoid from the compressor housing and plug it back into the factory wiring harness. Secure the solenoid by zip tying it up in place on the factory harness.

12. Reinstall the factory intake tube shown in figure 8.



**Figure 8**