

INSTALLATION INSTRUCTIONS

CAMARO CONSOLE POD

For 1968-69 Chevy Camaro

2650-1159



1. Remove your existing Center Console. The gear shift cover plate must also be removed.
2. Remove the front console cover plate. For cars with the factory gauge option you must disconnect the gauge wiring. **WARNING:** The Ammeter wiring **MUST** be properly disconnected (according to manufacturer specifications) to avoid danger of short circuit or fire.
3. Install new gauges into Console Pod and run the wiring through the center console.
4. Install Console Pod in the center console using supplied screws and washers. Reinstall the center console. **WARNING: Do not overtighten screws. This may cause the threaded bushings to crack or break off.**

NOTE

Due to normal manufacturing processes you may have “flashing” (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the “flashing.”



Looking for dependable gauges and dashboards? Rely on Auto Meter for quality and long-lasting products.