

## **INSTALLATION INSTRUCTIONS**

### **REPLACEMENT CAMARO PILLAR**

2650-1539-00

1. **DISCONNECT THE BATTERY BEFORE STARTING ANY WORK.** Not only are we doing electrical, but you're right next to the side airbag.



2. To start, pull the factory A pillar down. It pops out, but don't try to pull it all the way down.



3. There is a safety strap that needs to be removed to pull the pillar away. The screwdriver is pressing into the point where it is released in this picture.



4. Original A-Pillar removed.



5. The safety strap is then removed from the factory pillar. The tab on the back is depressed and it slides right out.



6. It's then re-installed into the new pillar the exact same way.

7. Install and wire gauges according to the wiring instructions included with each gauge.



8. The safety strap is then reattached to the bracket behind our pillar to secure the new mount.



9. The completed installation.