

INSTALLATION INSTRUCTIONS 2 $\frac{1}{16}$ " Ford Super Duty Triple Dash Pods Model 15016



1. Remove stereo head unit from the dashboard per manufacturer's instructions. This may require the use of a special "DIN" tool. Contact auto manufacturer for details. Disconnect stereo wiring harness and antenna wire from back of stereo.
2. Position dash pod in the desired mounting location to mark where four retaining holes will be drilled. Drill four holes in dashboard using a $\frac{9}{32}$ inch drill bit.
3. Install the gauges in the dash pod and run wiring choosing the following two options:

Option 1: Run wiring out the back of the pod through the pre-molded wire channel, down the back of the dashboard, and through the firewall.

Option 2: Make a small hole in the dash underneath the Dash Pod and run wiring down and out through the firewall.

NOTE: Installing this Dash Pod with mechanical pressure gauges may require 12ft. nylon tubing kit model 3226 (not for use with fuel pressure gauges). 12ft. capillary tubing may also be needed on mechanical temperature gauges.

4. Use included hardware to secure the Dash Pod to the top of the dashboard. Reconnect stereo wiring and reinstall stereo unit.

NOTE

Due to normal manufacturing processes you may have "flashing" (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the "flashing."