

# INSTALLATION INSTRUCTIONS

## Steering Column Pods

2650-1156



1. Determine how gauge wiring will be run:
  - A. Some pod models have a tunnel (mouse hole) for wiring.
  - B. Others will require you to create an opening in the stock steering cover for wiring to pass through (Porsche/Boxster).
2. Cut studs off gauge close to housing. Insert gauge in pod (press fit).
3. Install/Wire gauge using instructions that came with each gauge.
4. Install Pod on top of steering column.
  - A. To use transfer tape - tape should be placed on sides of column, NOT on the top.
  - B. To use ratchet fasteners - place steering pod in desired mounting location. Drill a  $\frac{3}{16}$ " hole through the steering pod and OEM column on both the left and right side. Press in ratchet fasteners.

### SERVICE

For service send your product in a well packed shipping carton to the address below. Please include a note explaining what the problem is along with your phone number. Please specify when you need the product back. Normal repairs take approximately ten (10) working days. If you are sending product back for Warranty adjustment, you must include a copy (or original) of your sales receipt from the place of purchase.

Learn more about gauges and dashboards we have.