

INSTALLATION INSTRUCTIONS

Dash Pod

2650-1704-00



-
1. Determine how gauge wiring will be run:
 - A. Some pod models have a tunnel (mouse hole) for wiring.
 - B. Others will require you to create an opening in the trim or dash for wiring to pass through.
 2. Most gauges include mounting studs that will have to be cut off or bent inwards for clearance in the pod. The standard gauge brackets normally used for mounting will not be used as the gauge is a press fit into the pod.
 3. Install/Wire gauge per gauge installation instructions
 4. Attach Pod to Dash using one of the following methods:
 - A. No-drill tape method: The pod can simply be pressed on and attached using the included double sided tape
 - B. Ratchet Fasteners: This method is more permanent and secure, but will require removal of the factory trim piece. Once removed, hold the pod onto the trim as it would be mounted in the vehicle. Drill four 3/16" diameter holes (two in front, two in back) through the pod and trim. Press in Ratchet Fasteners.

SERVICE

For service send your product in a well packed shipping carton to the address below. Please include a note explaining what the problem is along with your phone number. If you are sending product back for Warranty adjustment, you must include a copy (or original) of your sales receipt from the place of purchase.

Learn more about gauges and dashboards we have.