

# INSTALLATION INSTRUCTIONS

## Windshield Pod

2650-1160



### Windshield Pod Directions:

Read directions before starting installation

Part# (Dual 18016), (Triple 18017), (Quad 18018)

Fits 99-04 Ford Super Duty and 03-05 Dodge Ram

- 1) Apply hook and loop fastener to rear of Pod as shown in. (photo 1)
- 2) Clean window area where hook and loop fastener attaches.
- 3) Install gauges and wiring into pod.
- 4) Peel backing off hook and loop fastener.

**Note:** In steps 5 and 6 be careful not to let hook and loop fastener touch windshield.

- 5) Insert top edge of pod back into the space between the windshield and the metal roof edge, located under the headliner.
- 6) Feed wiring under headliner for several inches and slide pod into position above rear view mirror. (Photo 2 and 3)
- 7) Push pod firmly up against the head liner.
- 8) With pod firmly against head liner, press bottom of pod against windshield, apply firm pressure to bond hook and loop fastener to window.

**Note:** Hold firm pressure for at least one minute.

Continue running wiring under headliner and down a-pillar.



(Photo 1)



(Photo 2)



(Photo 3)

Learn more about gauges and dashboards we have.