

INSTALLATION INSTRUCTIONS

Steering Column Pods

2650-1156



-
1. Determine how gauge wiring will be run:
 - A. Some pod models have a tunnel (mouse hole) for wiring.
 - B. Others will require you to create an opening in the stock steering cover for wiring to pass through (Porsche/Boxster).
 2. Cut studs off gauge close to housing. Insert gauge in pod (press fit).
 3. Install/Wire gauge using instructions that came with each gauge.
 4. Install Pod on top of steering column.
 - A. To use transfer tape - tape should be placed on sides of column, NOT on the top.
 - B. To use ratchet fasteners - place steering pod in desired mounting location. Drill a $\frac{3}{16}$ " hole through the steering pod and OEM column on both the left and right side. Press in ratchet fasteners.
-

Learn more about gauges and dashboards we have.