



1951-1952 CHEVY CAR BILLET ALUMINUM DASH INSERT

Model 7038

1. Place 1-2 O-rings around each gauge casing. O-rings should be pushed down to the gauge bezel.
2. Place one of aluminum dash inserts in the stock dash. Place a gauge behind the dash insert & secure using one of the mounting panels. The mounting panel will attach the stock dash studs using three 10-24 nuts.
3. Repeat step 2 for the other side.
4. Wire your gauges (refer to instructions provided by gauge manufacturer).

Discover other custom gauges on our website.