

### INSTALLATION

1. Remove the factory upper corner trim panel and the factory "A" Pillar cover.
2. Prior to installing the pillar mount, it is recommended that the gauge wiring/tubing be routed at this time. Make sure to leave enough wiring/tubing to allow for the gauges to be connected later, and then pushed into the pillar mount.
3. Insert the bottom of the pod into the dash area.
4. Align the upper bracket/ratchet fastener and insert it into the factory hole. Pushing from the backside of the bracket, fully seat the ratchet fastener into the hole as seen below.
5. Reinstall the factory upper corner trim panel.
6. At this time the gauges can be connected and pushed into the gauge holes. Please note that the gauges are pressure fit and will not use the standard in-dash gauge mounting brackets that were likely included with your gauges.

