

INSTALLATION INSTRUCTIONS

Jeep Dash Pod Installation

For 2018+ Jeep JL Wrangler



Designed for rectangular rocker switches (*Not included) that fit 0.96" x 1.9" cutouts and Mini CBs (*Not included) that are no wider than 4.5" x 1.75"

1. Disconnect the Negative battery cable.
2. Remove the rubber tray liner.
3. Pre-wire the switches. Tip: Using a small piece of masking tape to label the wires will help make it easier to finish the wiring later.
4. Make sure that the rubber gasket included with most switches is installed; this will help keep the switches from rattling.
5. Run the wires through the corresponding openings and push the switches in until they "click" in place.
6. Attach 2 pieces of the included 3M™ Dual-Lock™ to the top of CB by pushing firmly in a location that will best secure the CB. Tip: cleaning the surface that the 3M™ Dual-Lock™ will be adhered to with alcohol beforehand and letting it dry will help adhesion.
7. Click in a piece of 3M™ Dual-Lock™ into each of the 2 previously installed pieces, making sure they are fully seated.
8. Remove the backing tape from these 2 pieces of 3M™ Dual-Lock™ and carefully slide the CB into the large rectangular cutout, then position the CB where desired. Then place the pod on a flat surface and push firmly on the bottom of the CB to adhere. Tip: it might be easier to insert the CB from the bottom and push CB through the cutout from back if the height of the 3M™ Dual-Lock™ pieces interfere.
9. Attach wires and antenna to the CB and route the switch wires to your desired location.
10. Insert the bottom making sure the "grill" portion is under the CB. The "grill" allows CBs that have a bottom firing speaker to still be heard.
11. Attach a piece of the included 3M™ Dual-Lock™ to the underneath of the cubby, make sure to push firmly.
12. Click in a piece of 3M™ Dual-Lock™ into the installed piece, making sure it is fully seated. Tip: cleaning the surface that 3M™ Dual-Lock™ will be adhered to with alcohol beforehand and letting it dry will help adhesion.
13. Make sure the bottom of the dash tray has been cleared of debris and cleaned with alcohol.
14. Remove the backing tape from these 2 pieces of 3M™ Dual-Lock™ and carefully slide the entire pod into the dash tray's large rectangular section. Make sure to push the bottom of the cubby firmly to best adhere the 3M™ Dual-Lock™.
15. Finish wiring the switches and CB per the instruction included by their manufacturer.
16. Reconnect the Negative battery cable.

