



NOTE: due to normal manufacturing processes you may have “flashing” (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the “flashing.”

1. Remove the two allen screws on the lower left and right of the vent cover (PHOTO 1)
2. Pull straight back on cover. Carefully use a screwdriver or putty knife at the rear of the cover to apply forward pressure.
3. Wire and install gauges into pod. The gauges are a pressure fit and do not require additional brackets or hardware to hold them into the pod.
4. Run wiring through the cutout located on the left side of the pod.
5. Place pod on dash and press down on back to snap pod in place (PHOTO 2)
6. Reinstall the vent cover over the front lip of the pod (PHOTO 3). Be sure the pins on the back of the cover are in the holes on the dash and the allen screws are reinstalled.

(PHOTO 1)



(PHOTO 2)



(PHOTO 3)

