

**NOTE:** Due to normal manufacturing processes you may have “flashing” (small fibers of plastic) around the pod holes. Once the gauge(s) are installed in the pod you will not be able to see the “flashing”.

1. Remove radio/AC control cover. The cover is press fit.
2. Run wiring for gauges.
3. The right side of the radio opening will need to be filed for gauge clearance. You will also need to cut the threaded studs off the back of the gauge for clearance.
4. Once clearance is made, use provided template to locate the holes before drilling (see image to the right). Holes are  $7/16$ ". You may need to file the hole(s) for adjustment.
5. Place the part into the opening and place speed nut washer with the u-shape down toward the part, then screw in the  $7/16$ " machine screw into place.  
**DO NOT OVER TIGHTEN.**
6. Reinstall radio/AC control cover.

