



- Dry with a clean towel.
- The ideal installation temperature is between 65° 110°F (18°-43°C)



## Care and Cleaning

• Wash only with mild soap & dry with a clean cloth.

## Congratulations!

You have purchased one of the many quality Auto Ventshade<sup>™</sup> branded products offered by Lund International, Inc. We take the utmost pride in our products and want you to enjoy years of satisfaction from your investment. We have made every effort to ensure that your product is top quality in terms of fit, durability, finish and ease of installation.







Feel the difference with AVS.

Learn more about rain guards and wind deflectors we have.