

# AX-CHRYCAM-1

## Chrysler Backup Camera Retention

### 2011-2016

#### FEATURES

- Retains the factory back-up camera to an aftermarket radio.

#### INTERFACE COMPONENTS

- AX-CHRYCAM-1 harness

#### APPLICATIONS

##### CHRYSLER

300 2011-2014

##### DODGE

Charger 2011-2014

Dart 2014\*

Journey 2011-2016

\* With premium amp, at the tuner brain behind the glove box.

#### TOOLS REQUIRED

- Cutting Tool • Tape • Crimping Tool
- Connectors (example: butt connectors, bell caps, etc.)

**CAUTION!** All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

#### Connections to be made

- Connect the **Black** wire to chassis ground.
- Connect the *female* **Yellow** RCA jack to the aftermarket radios backup camera input.

