Installation Instructions for AX-HON24RVC-6V

AX-HON24RVC-6V **Honda** (without touchscreen) 2015-up

INTERFACE FEATURES

- Retains the factory AUX-IN jack
- Retains the factory backup camera to an aftermarket radio
 - Includes the AX-CAM6V 12-volt to 6-volt converter.

INTERFACE COMPONENTS

AX-HON24RVC-6V harness
AX-CAM6V 12-volt to 6-volt converter


APPLICATIONS

HONDA	
Fit	2015-up
Pilot	2016-up
Ridgeline	2017-up

TOOLS REQUIRED

- Wire cutter Crimping tool Solder gun Tape
- Connectors (example: butt connectors, bell caps, etc.)

CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.



Feel the difference with Axxess.

Installation Instructions for AX-HON24RVC-6V

Connections to be made

- Connect the Black wire of the AX-CAM6V to chassis ground.
- Connect the Red wire labeled "Camera Power 6V" to the Blue/Red wire of the AX-CAM6V.
- Connect the reverse wire from the aftermarket radio, to the reverse signal in the vehicle, and also to the Blue/White wire of the AX-CAM6V.
- Connect the **Yellow** RCA jack to the rear camera input of the aftermarket radio.

IMPORTANT

If you are having difficulties with the installation of this product, please call our Tech Support line. Before doing so, look over the instructions a second time, and make sure the installation was performed exactly as the instructions are stated. Please have the vehicle apart and ready to perform troubleshooting steps before calling.



(AXXESS) Axxess Integrate

Learn more about car audio and electronics on our website.