

Hyundai/Kia <b>Data Interface with SWC 2010–up*</b>						TABLE OF CONTENTS           Connections to be made
INTERFACE FEATURES         • Provides NAV outputs (parking brake, reverse, speed sense)         • Retains audio controls on the steering wheel         • Retains BlueLink         • Requires the AX-HYKIA-SPDIF (sold separately)					Programming the AX-HYKIA1-SWC	
AX-HYKIAI-SWC interface     AX-HYKIAI-SWC harness  APPLICATIONS			<ul> <li>16-pin harness with stripped leads</li> <li>Female 3.5mm connector with stripped leads</li> </ul>		• Wire cutter • Crimp tool • Solder gun • Tape • Connectors (example: butt-connectors, bell caps, etc.)	
HYUNDAI Elantra Genesis Coupe * Santa Fe * Santa Fe Sport * * Without NAV	2011-2013 2013-2016 2013-2016 2013-2016	Sonata * Sonata Hybrid * Tucson	2011-2016 2011-2015 2010-2015	<b>KIA</b> Optima Sorento * Sorento (with UVO) * Sportage	2011-2015 2014-2016 2012-2013 2011-2016	CAUTION! All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

# **CONNECTIONS TO BE MADE**

#### From the 16-pin harness with stripped leads to the aftermarket radio:

- Connect the **Red** wire to the accessory wire.
- If the vehicle comes equipped with a factory amplifier, connect the **Blue/White** wire to the amp turn-on wire.
- If the aftermarket radio has a mute wire, connect the **Brown** wire to it. If the mute wire is not connected, the radio will turn off when BlueLink is activated.
- Connect the Gray wire to the right front positive speaker output.
- Connect the Gray/Black wire to the right front negative speaker output.
- Connect the White wire to the left front positive speaker output.
- Connect the White/Black wire to the left front negative speaker output.

The following (2) wires are only for a multimedia/navigation radio that requires these wires.

- Connect the Green/Purple wire to the reverse wire.
- Connect the Light Green wire to the parking brake wire.
- Tape off and disregard the following (7) wires, they will not be used in this application: Blue/Pink, Blue/White\*, Green, Green/Black, Orange/White, Purple, Purple/Black

\* Non-amplified models

#### From the AX-HYKIA1-SWC harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the Yellow wire to the battery wire.
- Connect the **Blue** wire to the power antenna wire.
- If the aftermarket radio has an illumination wire, connect the **Orange** wire to it.
- Connect the Green wire to the left rear positive speaker output.
- Connect the Green/Black wire to the left rear negative speaker output.
- Connect the **Purple** wire to the right rear positive speaker output.
- Connect the Purple/Black wire to the right rear negative output.

The following (1) wire is only for a multimedia/navigation radio that requires these wires.

- Connect the **Blue/Pink** wire to the VSS/speed sense wire.
- Connect the Red and White RCA jacks to the audio AUX-IN jacks of the aftermarket radio.
- The 14-pin harness will only be used for models that come equipped with a factory amplifier. Connect the AX-HYKIA-SPDIF (sold separately) to this connector.



# **CONNECTIONS TO BE MADE**

#### 3.5mm jack steering wheel control retention:

- The 3.5mm jack is to be used to retain audio controls on the steering wheel control.
- For the radios listed below, connect the *female 3.5mm connector with stripped leads*, to the male 3.5mm SWC jack from the AX-HYKIA1-SWC harness. Any remaining wires tape off and disregard:
  - Eclipse: Connect the steering wheel control wire, normally Brown, to the Brown/White wire of the connector. Then connect the remaining steering wheel control wire, normally Brown/White, to the Brown wire of the connector.
  - Metra OE: Connect the steering wheel control Key 1 wire (Gray) to the Brown wire.
  - Kenwood or select JVC with a steering wheel control wire: Connect the Blue/Yellow wire to the Brown wire.
  - XITE: Connect the steering wheel control SWC-2 wire from the radio to the Brown wire.
  - Parrot Asteroid Smart or Tablet: Connect the 3.5mm jack into the AX-SWC-PARROT (sold separately), and then connect the 4-pin connector from the AX-SWC-PARROT into the radio.

Note: The radio must be updated to rev. 2.1.4 or higher software.

• **Universal "2 or 3 wire" radio:** Connect the steering wheel control wire, referred to as Key-A or SWC-1, to the **Brown** wire of the connector. Then connect the remaining steering wheel control wire, referred to as Key-B or SWC-2, to the **Brown/White** wire of the connector. If the radio comes with a third wire for ground, disregard this wire.

**Note:** After the interface has been programmed to the vehicle, refer to the manual provided with the radio for assigning the SWC buttons. Contact the radio manufacturer for more information.

• For all other radios: Connect the 3.5mm jack from the AX-HYKIA1-SWC harness, into the jack on the aftermarket radio designated for an external steering wheel control interface. Please refer to the aftermarket radios manual if in doubt as to where the 3.5mm jack goes to.

# **INSTALLING THE AX-HYKIA1-SWC**

#### With the key in the off position:

- Connect the 16-pin harness with stripped leads, and the AX-HYKIA1-SWC harness, into the interface.
- For models equipped with a factory amplifier, connect the AX-HYKIA-SPDIF (sold separately) to the HYKIA2-SWC interface.

Attention! Do not connect the AX-HYKIA1-SWC harness to the wiring harness in the vehicle just yet.

**Attention!** If retaining steering wheel controls, ensure that the jack/wire is connected to the radio before proceeding. If this step is skipped, the interface will need to be reset for the steering wheel controls to function.

# **PROGRAMMING THE AX-HYKIA1-SWC**

For the steps below, the L.E.D. located inside the interface can only be seen while active. The interface does not need to be opened to see the L.E.D.

- Start the vehicle.
- Connect the AX-HYKIA1-SWC harness to the wiring harness in the vehicle.
- The L.E.D. will initially turn on solid **Green**, then turn off for a few seconds while it auto detects the radio installed.
- The L.E.D. will then flash **Red** up to (18) times indicating which radio is connected to the interface, and then turn off for a couple of seconds. Pay close attention to how many **Red** flashes there are. This will help in troubleshooting, if need be. Refer to the L.E.D. feedback section for more information.
- After a couple seconds the L.E.D. will turn on solid **Red** while the interface auto detects the vehicle. The radio will shut off at this point. This process should take 5 to 30 seconds.
- Once the vehicle has been auto detected by the interface, the L.E.D. will turn on solid **Green**, and the radio will come back on, indicating programming was successful.
- Test all functions of the installation for proper operation, before reassembling the dash.
- If the interface fails to function, refer to Resetting the AX-HYKIA1-SWC.

**Note:** The L.E.D. will turn on solid **Green** for a moment, and then turn off under normal operation after the key has been cycled.

### L.E.D. feedback

The (18) **Red** L.E.D. flashes represent which brand radio the AX-HYKIA1-SWC is connected to. Each flash represents a different radio manufacturer. For example, if you are installing a JVC radio, the AX-HYKIA1-SWC will flash **Red** (5) times, and then stop. Following is a legend that dictates which radio Manufacturer corresponds to which flash.

### L.E.D. feedback legend

1 flash - Eclipse (Type 1) †	10 flashes - Clarion (Type 2)
2 flashes - Kenwood ‡	11 flashes - Metra OE
3 flashes – Clarion (Type 1) †	12 flashes - Eclipse (Type 2)
4 flashes – Sony / Dual	13 flashes - LG
5 flashes - JVC	14 flashes - Parrot **
6 flashes - Pioneer / Jensen	15 flashes - XITE
7 flashes - Alpine *	16 flashes - Philips
8 flashes - Visteon	17 flashes - TBD
9 flashes - Valor	18 flashes - JBL

- Note: If the AX-HYKIA1-SWC flashes Red (7) times, and you do not have an Alpine radio connected to it, that means the ASWC-1 does not detect a radio connected it. Verify that the 3.5mm jack is connected to the correct steering wheel jack/wire in the radio.
- \*\* Note: The AX-SWC-PARROT is required (sold separately).
- \* Note: If you have a Clarion radio and the steering wheel controls do not work, change the radio type to the other Clarion radio type; same for Eclipse. Refer to the "Programming Information" document online.
- If you have a Kenwood radio and the L.E.D. feedback comes back as showing as a JVC radio, change the radio type to a Kenwood. Refer to the "Programming Information" document online.



**Attention:** The Axxess Updater App can also be used to program the following (3) sub-sections as well, pending that the interface has been initialized and programmed.

## Changing radio type

If the LED flashes do not match the radio you have connected, you must manually program the AX-HYKIA1-SWC to tell it what radio it is connected to.

- 1. After (3) seconds of turning the key on, press and hold the Volume-Down button on the steering wheel until the L.E.D. in the AX-HYKIA1-SWC goes solid.
- **2.** Release the Volume-Down button; the L.E.D. will go out indicating we are now in Changing Radio Type mode.
- **3.** Refer to the Radio Legend to know which radio number you would like to have programmed.
- **4.** Press and hold the Volume-Up button until the L.E.D. goes solid, and then release. Repeat this step for the desired radio number you have selected.
- **5.** Once the desired radio number has been selected, press and hold the Volume-Down button on the steering wheel until the L.E.D. goes solid. The L.E.D. will remain on for about (3) seconds while it stores the new radio information.
- **6.** Once the L.E.D. goes off, the Changing Radio Type mode will then end. You can now test the steering control wheel controls.

**Note:** If at any time the user fails to press any button for a period longer than (10) seconds, this process will abort.

#### **Radio legend**

1. Eclipse (Type 1)	7. Alpine	13. LG
2. Kenwood	8. Visteon	14. Parrot
3. Clarion (Type 1)	9. Valor	15. XITE
4. Sony/Dual	10. Clarion (Type 2)	16. Philips
5. JVC	11. Metra OE	17. TBD
6. Pioneer/Jensen	12. Eclipse (Type 2)	18. JBL

## Remapping the steering wheel control buttons

Once the AX-HYKIA1-SWC has been programmed, the button assignment for the steering wheel controls may be reassigned if so desired. For example, if the Seek-Up button is preferred to be the Mute button instead. Follow the steps below to remap the steering wheel control buttons:

**1.** Ensure the AX-HYKIA1-SWC is visible so you can see the L.E.D. flashes to confirm button recognition.

Tip: Turning the radio off is recommended.

- 2. Within the first twenty seconds of turning the ignition on, press and hold the Volume-Up button on the steering wheel until the L.E.D. goes solid.
- **3.** Release the Volume-Up button, the L.E.D. will then go out; The Volume-Up button has now been programmed.
- **4.** Follow the list in the Button Assignment Legend to reference the order in which the steering wheel control buttons need to be programmed.

**Note:** If the next function on the list is not on the steering wheel, press the Volume-Up button for (1) second until the L.E.D. comes on, and then release the Volume-Up button. This will tell the AX-HYKIA1-SWC that this function is not available and it will move on to the next function.

**5.** To complete the remapping process, press and hold the Volume-Up button on the steering wheel until the L.E.D. in the AX-HYKIA1-SWC goes out.

## **Button assignment legend**

1. Volume-Up	10. Band		
2. Volume-Down	11. Play/Enter		
3. Seek-Up/Next	12. PTT (Push to Talk)		
4. Seek-Down/Prev	13. On-Hook		
5. Source/Mode	14. Off-Hook		
6. Mute	15. Fan-Up *		
7. Preset-Up	16. Fan-Down *		
8. Preset-Down	17. Temp-Up *		
9. Power	18. Temp-Down *		

\* Not applicable in this application

**Note:** Some radios may not have these commands. Please refer to the manual provided with the radio, or contact the radio Manufacturer for specific commands recognized by that particular radio.

### Dual assignment instructions (long button press)

The AX-HYKIA1-SWC has the capability to assign (2) functions to a single button, except Volume-Up and Volume-Down. Follow the steps below to program the button(s) to the desired setting.

**Note:** Seek-Up and Seek-Down come pre-programmed as Preset-Up and Preset-Down for a long button press.

- **1.** Turn the key to the ignition but do not start the vehicle.
- **2.** Press and hold the desired steering wheel control button for (10) seconds, or until the L.E.D. flashes rapidly. At this point release the button; the L.E.D. will then go solid.
- 3. Press and release the Volume-Up button the number of times corresponding to the new button number selected. Refer to the Dual Assignment Legend. The L.E.D. will flash rapidly while the Volume-Up button is being pressed, and then go back to a solid L.E.D. once released. Proceed to the next step once the Volume-Up button has been pressed the desired number of times.

**Caution:** If more than (10) seconds elapses between pressing the Volume-Up button, this procedure will abort, and the L.E.D. will go out.

**4.** Press the desired button to store it to memory. The L.E.D. will now go out indicating the new information has been stored to memory.

**Note:** These steps must be repeated for each button desired to assign a dual assignment feature to. To reset a button back to its default state, repeat Step 1, then press the Volume-Down button. The L.E.D. will go out, and the dual assignment feature for that button will be erased.



# STEERING WHEEL CONTROL SETTINGS (CONT.)

### Dual assignment legend

1.	Not allowed	6.	ATT/Mute
2.	Not allowed	7.	Preset-Up
3.	Seek-Up/Next	8.	Preset-Down
4.	Seek-Down/Prev	9.	Power
5.	Mode/Source	10.	Band

Play/Enter
 PTT
 On-Hook

14. Off-Hook

- 16. Fan-Down\*
  - 17. Temp-Up \*

15. Fan-Up \*

18. Temp-Down\*

# TROUBLESHOOTING

### **Resetting the AX-HYKIA1-SWC**

- 1. The **Blue** reset button is located inside the interface, between the two connectors. The button is accessible outside the interface, no need to open the interface.
- 2. Press and hold the reset button for two seconds, and then let go to reset the interface.
- 3. Refer to "Programming the Interface" from this point.

\* Not applicable in this application

