



NISSAN BLUETOOTH BYPASS

The following Nissan Vehicles come equipped with a Bluetooth module that must be bypassed when installing an ASWC-1 (sold separately) in order to retain the Bluetooth buttons on the steering wheel.

APPLICATIONS

350Z	2007-2009	Cube	2009-2014	Leaf	2012-2015	Quest	2011-2015	Versa	2007-2016
370Z (without nav)	2010-2014	Frontier	2008-2011	Maxima	2006-2014	Rogue	2008-2013	Versa Note	2014-2015
370Z	2015-2016	Frontier (with amp)	2013-2015	NV200	2013-2017	Sentra	2007-2015	Xterra	2007-2015
Altima	2007-2012	Juke	2011-2014	NV2500	2012-2013	Titan	2008-2014		

BLUETOOTH MODULE LOCATIONS

350Z 2007-2009	Top of Trunk	Frontier 2008-2011	Under front seat	Maxima 2006-2014	Under rear deck in trunk	Titan 2008-2014	Under front passenger seat
370Z 2010-2014 (w/o nav)	Top of Trunk	Frontier 2013-2015 (w/ amp)	Under front seat	NV200 2013-2017	Behind glovebox		
370Z 2015-2016	Top of Trunk	Juke 2011-2014	Behind glovebox	NV2500 2012-2013	Behind glovebox	Versa 2007-2016	Right side of trunk
Altima 2007-2012	Rear deck	Leaf 2012-2015	Trunk right hand side of luggage compartment	Rogue 2008-2013	Trunk left side luggage compartment	Versa Note 2014-2015	Right side of trunk
Cube 2009-2014	Under front passenger seat			Sentra 2007-2015	Behind glovebox	Xterra 2007-2015	Under front passenger seat

Installation Instructions on the back

INSTALLING

1. Install and program the ASWC-1, then test all buttons for proper function.

Note: *Bluetooth buttons will not work until Step 2 is done.*

For ASWC-1 vehicle instructions, please refer to the AXXESS

2. Locate the Bluetooth module, disconnect the 32-pin harness, and then connect the AX-NIS32BT to the harness removed.
3. Test that the Bluetooth buttons now function.

Note: *Ensure that the phone is paired to the aftermarket radio.*

