

## AX-TOY285WC Plug and Play Harness for the ASWC-1 (sold separately) 2012-up

### FEATURES

- Plug and play harness for the ASWC-1 (sold separately)
- Retains the factory AUX-IN jack

### INTERFACE COMPONENTS

- AX-TOY285WC harness

### TOOLS REQUIRED

- Cutting tool • Crimping tool • Tape • Connectors (example: butt-connectors, bell caps, etc.)

### APPLICATIONS

#### SCION

iC 2014-2015

#### SUBARU

Forester (w/ nav)  
2014-2015

Forester (w/ SD based nav)  
2012-2013

Impreza WRX (w/ nav)  
2013-2014

Legacy 2015

Legacy (w/ HK amp)  
2012-2013

Outback 2015

Outback (w/ HK amp)

2012-2013

WRX (w/ nav) 2015

XV Crosstrek (w/ nav)  
2013-2014

#### LEXUS

CT 200h 2011-2015

#### TOYOTA

4-Runner 2013-2015

Avalon 2013-2015

Camry 2012-2015

Corolla 2013-2015

Corolla (w/ nav) 2011-2015

FJ Cruiser (w/ nav) 2013

Highlander 2013-2015

Matrix (w/ USB) 2013

Prius V 2012-2015

Prius C 2012-2015

Prius 2012-2015

Rav-4 2012-2015

Sequoia (w/ nav) 2013-2015

Tacoma 2013-2015

Tundra 2014-2015

Venza 2013-2015

Yaris Hatchback  
2012-2015

**CAUTION!** All accessories, switches, climate controls panels, and especially air bag indicator lights must be connected before cycling the ignition. Also, do not remove the factory radio with the key in the on position, or while the vehicle is running.

## Installation Instructions for AX-TOY28SWC

### Connections to be made

#### From the AX-TOY28SWC harness to the aftermarket radio:

- Connect the **Black** wire to the ground wire.
- Connect the **Red** wire to the accessory wire.
- Connect the **Red** and **White** RCA jacks to the audio AUX-IN jacks (if so equipped).

*The following (2) wires are for aftermarket multimedia/navigation radios that provide these wires (if not required, tape them off and disregard them):*

- Connect the **Light Green** wire to the parking brake wire (if applicable).
- Connect the **Green/Purple** wire to the reverse wire (if applicable).

#### Installing the AX-TOY28SWC

- With the key in the off position, connect the AX-TOY28SWC harness into the ASWC-1 (sold separately), and then into the vehicle.
- Follow the instructions included with the ASWC-1 (sold separately) for connections to the 3.5mm jack.
- With all connections completed, reconnect the negative battery terminal.

#### Programming the ASWC-1 (sold separately)

##### When using the ASWC-1 to retain steering wheel audio controls:

- Turn the key to ignition; the L.E.D. in the ASWC-1 (sold separately) will flash fast.  
**Note:** *If your vehicle has a RETURN button on the steering wheel, press and hold that button during this process.*
- After about 20 seconds the L.E.D. will light up solid indicating the ASWC-1 (sold separately) has been programmed. If the L.E.D. does not light up solid, or the steering wheel controls do not work, refer to the instructions included with the ASWC-1 (sold separately) for troubleshooting.

#### IMPORTANT WARNING

This product includes instructions for installation which must be carefully followed. The instructions are worded in such a manner to assume that the installer is capable of completing these type of electronic installations. If you are unclear as to what you are instructed to do or believe that you do not understand the instructions so as to properly and safely complete the installation you should consult a technician who does have this knowledge and understanding.

Failure to follow these instructions carefully and to install the interface as described could cause harm to the vehicle or to safety systems on the vehicle. Interference with certain safety systems could cause harm to persons as well.