

## AX-VW92-CAM

### Volkswagen/Skoda Camera Retention Interface

### 2008-2015\*

\* For vehicles equipped with RNS510 (MFD3), RNS315, Columbus (Skoda), or RCD510 (with 26-pin connector)

#### INTERFACE FEATURES

- Allows the factory camera to be used with an aftermarket radio.
- Plug-and-play, no cutting of wires required.

#### APPLICATIONS

##### VOLKSWAGEN

Amarok	2010-2014
EOS	2009-2014
Golf	2008-2014
Jetta	2009-2014
Passat	2010-2015

Polo	2008-2014
Scirocco	2008-2015
Tiguan	2009-2015
Touran	2010-2015
Transporter	2009-2014

##### SKODA

Octavia	2009
Superb	2008-2015

#### Connections to be made

- Connect the **Black** wire to chassis ground.
- Connect the **Yellow** wire to battery power.
- Connect the **Blue** wire to reverse power (switched).
- Connect the **Yellow** RCA jack to the aftermarket radios backup camera input jack.

#### Installing the Interface

- Connect the AX-VW92-CAM to the wiring harness in the vehicle located at the radio location (26-pin connector).