

## CHRYSAV

### Introduction

The CHRYSAV is designed to provide an audio/video input to the OEM overhead video screen from the aftermarket radio, and provide the audio/video input from the rear seat control panel to the aftermarket radio.

#### Note:

- The CHRYSAV is designed to work with the overhead video monitors that **do not** have the DVD player built in.
- This harness **must** be used along with an Axxess interface. Please visit [axsessinterfaces.com](http://axsessinterfaces.com) for more information.

### APPLICATIONS

#### CHRYSLER

Town & Country	2008-up
----------------	---------

#### DODGE

Durango	2008-2013
Grand Caravan	2008-up
Journey	2009-2010
Ram 1500	2009-2011
Ram 2500/3500	2010-2011

#### JEEP

Grand Cherokee	2008-2013
----------------	-----------

#### RAM

1500/2500/3500	2012
----------------	------

#### VOLKSWAGEN

Routan	2009-2013
--------	-----------

### INTERFACE COMPONENTS

- CHRYSAV harness

### TOOLS REQUIRED

- Cutting Tool • Tape • Crimping Tool
- Connectors (i.e. butt-connectors, bell caps, etc.)

### INSTALLATION INSTRUCTIONS

*Important: Before beginning any of the following, disconnect the negative battery terminal to prevent an accidental short circuit.*

#### From the 22-pin harness

- Connect the "A/V 1" RCAs to the aftermarket radios audio/video input. Plug **Yellow** in to video-in, **Red** to right audio-in, and **White** to left audio-in.
- Connect the "A/V 2" RCAs to the aftermarket radios audio/video output. Plug **Yellow** in to video-out, **Red** to right audio-out, and **White** to left audio-out.
- Connect the **Yellow** RCA to the aftermarket radios backup camera input of the aftermarket radio.
- Connect the loose **Black** wire to ground.

