



baja designs[®]
The Scientists of Lighting

'09-'18 Dodge Ram 1500 (2019 Classic) A-Pillar mount kit Instructions





baja designs
The Scientists of Lighting

Silverado Universal 20" S8/OnX6 bracket kit

Tools Required

4mm Allen wrench (Ball hex preferred)

10mm Socket wrench

Masking tape

Writing instrument

1. Begin by gently pulling back the rubber cowling nearest the bottom corner of the windshield. Notice the 10mm hex head upper fender fastener. Remove the bolt with a 10mm socket wrench and this threaded hole will be used to mount the A Pillar bracket.



2. Place masking tape as shown.





baja designs
The Scientists of Lighting

3. Place the M6 Button head bolt through a ¼" washer and the slotted hole on the inside of the bracket. While applying mild pulling force to the top of the fender as shown, use the 4mm Allen wrench to carefully thread the bolt into the hole. Take care not to cross thread the factory threaded hole. If it becomes difficult to tighten while a decent portion of the threads are still exposed, completely remove and try again until it goes in smoothly.



4. Once it is confirmed that the threads are engaged properly, reverse the bolt until the bracket has a small amount of play. Place the rubber pad inbetween the bracket and the fender. Trace the outline of the sides of the bracket and the top of the fender. Cut pad and remove adhesive backing. Adhere pad to inside of upper fender. Torque the bolt snug. Repeat steps 1 through 4 for the opposite side of the vehicle.



Re-torque all fasteners after 100 miles.

See the instructions supplied with the wiring harness to complete wiring needs.

Your install is now complete! Thank you for choosing Baja Designs.

Discover other off-road lights on our website.