



ITEM NO.	PART NUMBER	QTY./SIDE
1	44-7102 OEM Tundra 07-13 & Tacoma 05-11	1
2	20-1287 1-4-20 0.875inch bolt	2
3	20-1026 6mm oversized washer	2
4	20-1278 1-4-20 Extruded U Nut 1.25inch long	2
5	20-1493 M4 x 10 Socket hd	4

Instructions:

1. Remove stock fog lights. To do this you must unclip the tabs on both sides of the light and pull the light out through the front of the bumper.
2. Next remove the front bezel of the squadron light and securely mount it to the supplied fog pocket bracket using the M4 socket head bolts. **Torque bolts to 25 in/lbs.** Failure to do so could result in cracked lens or improper seal.
3. Install the extruded U-nut onto the bracket in the same direction as shown above. When installing the kit onto the truck we found it to be much more efficient to hold the U-nut (with a small piece of tape or rubber band) in the same orientation as pictured above; This helped the holes align quicker and a much faster install time.
4. Next install kit into fog light pocket and use the two bolts to fasten the fog light kit to the fog pocket. Adjust the kit to a depth that suits your needs and then securely tighten the two bolts.
5. Finally use plug and play wiring supplied to connect the lights to the factory wiring harness.