

with Installation Instructions

Owner's Manual

Banks A-Pillar Mount Gauge Mounting

2015+ Ford F-150
2017+ Ford Super Duty

THIS MANUAL IS FOR USE WITH SYSTEM 63338

BANKS

General Installation Practices

1. Before starting work, familiarize yourself with the installation procedure by reading all of the instructions.
2. Disconnect the negative (ground) cable from the battery (or batteries, if there are two) before beginning work.
3. Route and tie wires and hoses a minimum of 6" away from exhaust heat, moving parts and sharp edges. Clearance of 8" or more is recommended where possible.
4. During installation, keep the work area clean. Do not allow anything to be dropped into intake, exhaust, or lubrication system components while performing the installation, as foreign objects will cause immediate engine damage upon start-up.

Tools Required:

- Phillips screwdriver
- 1/4" or 3/8" drive ratchet with 10 mm socket

What's Included

Item #	Description	Part #	QTY
1	Pillar Mount Kit, Single Gauge	63338-01	1
2	Owner's Manual	96423	1

Figure 2



A-Pillar Mount Installation

1. Open the two bolt covers on the factory grab handle and remove the two bolts with a 10mm socket. See **Step 1**.

Step 1



2. Remove stock pillar by pulling towards you and sliding up, releasing the two tabs from the dash. Disconnect speaker wire harness to fully remove stock pillar. See **Step 2**.

Step 2



3. Run the applicable iDash wiring up through the stock pillar location in preparation for the Banks Pillar. Remove speaker from stock pillar and reinstall onto Banks pillar using the supplied 4-40 screws. See **Step 3**.

Step 3



4. Install supplied snap nut onto the bottom end of the top slot. Reconnect speaker harness and reinsert tabs into the lower portion of the Banks pillar into the dash near the windshield. See **Step 4**.

Step 4



5. Connect iDash before fully installing the Banks pillar. Insert supplied black screw into Banks pillar and align with previously installed snap nut. Finish install by tightening screw into snap nut. Take care to not overtighten screw. **Step 5**.

Step 5

