

BANKS FORD 6.0L POWERSTROKE TUNER MODULE
Supplemental Instructions for Improved Harness Connector Retention
FOR USE WITH SYSTEMS 61023, 63749, 63743, 63747, 63745 and 63748.

1. Be sure both 46-pin harness connectors are fully seated and latched into their respective receptacles on the Banks module.
2. Install the supplied 1/8" wide x 11" long BLACK cable ties around each connector housing and locking lever as shown in Figures 1 & 2 below (one cable tie per connector).
3. Before fully tightening, make sure the cable ties are situated below both rear lower corners (**Figure 1**) and also under the front rib/ridge of the connectors (**Figure 2**).
4. Securely tighten both cable ties and cut off any excess.

Figure 1




Figure 2

