



BBK Phenolic Spacer Kits

Part # 1506,1508,1520,1530,1549



Special Tools

Required:

- No special tools required

Install Time:

Approximately
1 Hour

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

- Disconnect the throttle duct hose from the throttle body.

STEP 2

- Disconnect the throttle linkage from the throttle body and also the kick-down linkage if applicable.

STEP 3

- Disconnect the wire connectors from the upper manifold and also the vacuum lines on the underside of the upper intake.

STEP 4

- Remove the cover plate from the upper intake if equipped. Next remove the six bolts from the upper intake manifold.

STEP 5

- Lift off the upper intake and discard the gasket, also making sure both surfaces are free from dirt and grease.

STEP 6

- Next install the phenolic spacer by placing a new gasket on both sides of the spacer.

STEP 7

- Use the new bolts provided and tighten in a criss-cross pattern beginning with the center bolts.

STEP 8

- Next simply reverse the previous steps.