



BBK Phenolic Spacer Kits **Part # 1506, 1508, 1520, 1549**

I N S T A L L A T I O N I N S T R U C T I O N S

- Step 1** Disconnect the throttle duct hose from the throttle body.
- Step 2** Disconnect the throttle linkage from the throttle body and also the kickdown linkage if applicable.
- Step 3** Disconnect the wire connectors from the upper manifold and also the vacuum lines on the underside of the upper intake.
- Step 4** Remove the cover plate from the upper intake if so equipped. Next remove the six bolts from the upper intake.
- Step 5** Lift off the upper intake and discard the gasket, also making sure both surfaces are free from dirt and grease.
- Step 6** Next install the phenolic spacer by placing a new gasket on both sides of the spacer.
- Step 7** Use the new bolts provided and tighten to 14-24 lbs. in a criss-cross pattern beginning with the center bolts.
- Step 8** Next simply reverse the previous steps.